

Installation & Field Guide

RoadLenz Intelligent Mobility | Powered by Bigfox Engineering Private Limited

Scope

This document covers the standard field installation procedure for RoadLenz hardware. Always follow vehicle manufacturer guidance and local electrical safety rules.

Before you begin

- â€¢ Confirm the part number against the packing list and order.
- â€¢ Verify vehicle make, model, year and battery rating.
- â€¢ Prepare the toolkit: wire strippers, crimpers, multimeter, zip ties, heat shrink.
- â€¢ Confirm network coverage at the installation site.

Procedure

1. Disconnect the negative battery terminal.
2. Select a bracket position with an unobstructed view of the lane ahead and no dashboard glare.
3. Clean the windshield area and attach the bracket with 3M VHB tape plus the screw clip.
4. Route the power harness along the A-pillar into the fuse box; tap an always-on and an ignition-switched feed.
5. Connect GPS antenna to the sun visor location and route the cable through the seal.
6. Restore power, verify boot on the display, and confirm a network connection in the app.
7. Calibrate: drive 500 m straight on a marked road and complete ADAS calibration.
8. Record the serial number and installation date in the customer record; take 3 photos.

Demo sample content â€” replace with verified documentation before launch.

support@roadlenz.in | www.roadlenz.in