

Assignment – 2.4

Q - 1. Connect a USB webcam to your computer, install any required drivers, and verify that the webcam works by opening the default camera app and capturing a photo.

Connect and Test a USB Webcam:

1. Connect the **USB webcam** to the computer.
2. Wait for Windows to **detect the webcam** automatically.
3. If required, install the **webcam driver**.
4. Open the **Camera app** from the Start menu.
5. Check that the webcam video appears on the screen.
6. Click the **Take Photo** button to capture a photo.
7. Check the saved photo to confirm that the **webcam is working properly**.

Q - 2. Set up a local printer (USB or network), install the correct driver, and print a test page to confirm successful installation.

Set Up a Local Printer:

1. Connect the printer to the computer using a **USB cable** or connect it to the **same Wi-Fi network**.
2. Turn **ON** the printer.
3. Open **Settings → Bluetooth & devices → Printers & scanners**.
4. Click **Add device**.
5. Select your printer and click **Add device**.
6. Windows will install the required **printer driver**.
7. Open the printer settings and select **Print a test page**.
8. If the test page prints successfully, the printer is **installed and working correctly**.

Q - 3. Simulate a connectivity issue by unplugging the printer's USB cable, then use Windows Device Manager to identify and resolve the 'printer not detected' problem.

Fix “Printer Not Detected” Problem:

1. **Unplug** the printer's USB cable.
2. Open **Device Manager**:
 - Press **Windows + X**
 - Select **Device Manager**.
3. Look for the printer under **Printers** or **Print queues**.
4. Check for a **yellow warning icon** ().
5. **Reconnect** the printer's USB cable.
6. In Device Manager, click **Action → Scan for hardware changes**.
7. Wait for Windows to detect the printer again.
8. If needed, **update or reinstall the printer driver**.
9. Print a **test page** to confirm the printer is working.

Q - 4. A user reports that their webcam video is not displaying in Zoom, but it works in the default camera app. Troubleshoot and resolve the issue so the webcam works in both applications.

Troubleshoot Webcam in Zoom:

1. **Close other apps** – Close Camera, Teams, Skype, or any other app that may be using the webcam.
2. **Open Zoom** and sign in.
3. Go to **Settings → Video**.
4. Under **Camera**, select the correct webcam.
5. **Check permissions:**
 - Open **Windows Settings → Privacy & security → Camera**.
 - Turn on **Camera access**.
 - Turn on **Let apps access your camera**.
 - Make sure Zoom is allowed to use the camera.
6. **Restart Zoom** after changing the settings.
7. If it still does not work, **restart the computer**.
8. Open Zoom again and check **Settings → Video**.