		STANDA VALVE, COCK, STRAINER, P	RD SY	MBOL FTING AND) INSTRUMENT
	灭	GLOBE STOP STR.		, j	ELOW CONT. O MANY PROGRESS
	N	GLOBE STOP ANGLE			FLOW CONT. 2-WAY DISC/DIAL
		GLOBE SDNR STR.		.0,	REMOTE HYD. B'FLY LUG
	I	GLOBE SDNR ANGLE	-		REMOTE HYD. B'FLY WAFER
	<u>X</u>	GATE RISING	-	.0	REMOTE HYD. B'FLY FLANGE
	M	GATE NON RISING	-	- X	REMOTE PNEU. B'FLY LUG
		FLAP CHECK			REMOTE PNEU. B'FLY WAFER
	j.	SWING CHECK		(S)	REMOTE PNEU. B'FLY FLANGE
				M	REMOTE ELEC. B'FLY LUG
		LIFT CHECK STR.		No.	REMOTE ELEC. B'FLY WAFER
		LIFT CHECK ANGLE			REMOTE ELEC. B'FLY FLANGE
	<u> </u>	BALL CHECK WITHOUT SPRING	-	虚	SURFACE DROP
	₩	BALL CHECK WITH SPRING		*	PRESS. VACUUM
	M	BUTTERFLY LUG		*	PRESS. VACUUM HIGH VELOCITY
	M	BUTTERFLY WAFER		甲	PRESS. VACUUM BREAKER
	网	BUTTERFLY FLANGE		2	GAS FREEING COVER
		HOSE CONN. GLOBE STR.			FLAME ARRESTER
	X	HOSE CONN. GLOBE ANGLE		ф	ORIFICE PLATE
	浏	SAFETY STR.		JA .	ORIFICE VALVE
	赵	SAFETY ANGLE		H 21 4	STRAINER SIMPLEX STR.
	闵	SELF CLOSING STR. SPRING		1	STRAINER SIMPLEX LA
	2	SELF CLOSING ANG. SPRING		<u> </u>	STRAINER SIMPLEX LB
	\boxtimes	NEEDLE STR.		⊬ _1	MUD BOX STR.
	Ø	NEEDLE ANGLE		ð	MUD BOX ANGLE
	180	NEEDLE 3-WAY TEST		D ₁	ROSE BOX
	1201	COCK 2-WAY			STEAM TRAP WITH DRAIN VALVE
	闷	COCK 3-WAY L-TYPE		Ŧ	SOUNDING CAP S/C WEIGHT
	函	COCK 3-WAY T-TYPE		T	SOUNDING CAP NORMAL
	函	COCK 4-WAY		r T	SOUNDING CAP DECK PIECE
	$\overline{\bowtie}$	PRESS CONTROL REDUCING	7.		AIR PIPE GOOSE NECK
	\$	QUICK CLOSING STR.		D83	AIR VENT FLOAT A SCR.
	d.	QUICK CLOSING ANG.		國	AIR VENT FLOAT A
FILENAME	· L DID	CTD DIAIC		1	· ····· VEIVI I EO/II / I

STANDARD SYMBOL								
VALVE, COCK, STRAINER, PIPE FITTING AND INSTRUMENT								

		11	T	
	AIR VENT FLOAT B SCR.			
P	AIR VENT FLOAT B			
#	COUPLING DRESSER			200
크	COUPLING SLEEVE			
- 111-	COUPLING FLANGED DRESSER			
OPEN CLOSE	SPECTACLE FLANGE			
-11	FLANGED BLIND			
人	BELL MOUTH			
11-11	SPOOL PIECE			
D	REDUCER			
₽ [™]	EJECTOR			
HQ.	HAND PUMP			
	OFF PAGE CONNECTOR			
. 🕣	CENTRIFUGAL PUMP			
0	SCUPPER PIECE			3
$\overline{\mathbb{A}}$	DECK STAND NORMAL			
Ā	DECK STAND LOCAL HYD.			
4	FULL DISCHARGE OVERBOARD			
	NOT CONN. CROSSING PIPE			1
+	CONNECTED CROSSING PIPE '			
П	BOSS			
且	BOSS WITH PLUG			
0	PRESSURE INDICATOR			
•	COMPOUND GAUGE			
•	PRESSURE TRANSMITTER			
•	THERMOMETER			
LHA	LEVEL ALARM HIGH			
LAL	LEVEL ALARM LOW			
M	HOSE BALL VALVE			