

ADVANCED COMPUTER ARCHITECTURE



Khoa Khoa học và Kỹ thuật Máy tính BM Kỹ thuật Máy tính


Trần Ngọc Thịnh http://www.cse.hcmut.edu.vn/~tnthinh

©2013, dce

dce

Memory Hierarchy Design






Processor-DRAM Performance Gap Impact

- To illustrate the performance impact, assume a single-issue pipelined CPU with CPI = 1 using non-ideal memory.
- Ignoring other factors, the minimum cost of a full memory access in terms of number of wasted CPU cycles:

Year	CPU speed MHZ	CPU cycle ns	Memory Access	Minimum CPU memory stall cycles or instructions wasted	
1986:	8	125	190	190/125 - 1 = 0.5	
1989:	33	30	165	165/30 - 1 = 4.5	
1992:	60	16.6	120	120/16.6 - 1 = 6.2	
1996:	200	5	110	110/5 - 1 = 21	
1998:	300	3.33	100	100/3.33 - 1 = 29	
2000:	1000	1	90	90/1 - 1 = 89	
2002:	2000	.5	80	80/.5 - 1 = 159	
2004:	3000	.333	60	60.333 - 1 = 179	





dce Addressing the Processor-Memory Performance GAP

- Goal: Illusion of large, fast, cheap memory.
 Let programs address a memory space that scales to the disk size, at a speed that is usually as fast as register access
- Solution: Put smaller, faster "cache" memories between CPU and DRAM. Create a "memory hierarchy".



Common Predictable Patterns

Two predictable properties of memory references:

- <u>Temporal Locality:</u> If a location is referenced, it is likely to be referenced again in the near future (e.g., loops, reuse).
- Spatial Locality: If a location is referenced it is likely that locations near it will be referenced in the near future (e.g., straightline code, array access).



ı,

dce

Caches

Caches exploit both types of predictability:

- Exploit temporal locality by remembering the contents of recently accessed locations.
- Exploit spatial locality by fetching blocks of data around recently accessed locations.



Simple view of cache



- The processor accesses the cache first
- Cache hit: Just use the data
- Cache miss: replace a block in cache by a block from main memory, use the data
- The data transferred between cache and main memory is in blocks, and controlled by independent hardware



9

dce

Simple view of cache

- · Hit rate: fraction of cache hit
- Miss rate: 1 Hit rate
- Miss penalty: Time to replace a block + time to deliver the data to the processor



Simple view of cache

- Example: For(i = 0; i < 10; i++) S = S + A[i];
- No cache: At least 12 accesses to main memory (10 A[i] and Read S, write S)
- With Cache: if A[i] and S is in a single block (ex 32-bytes), 1 access to load block to cache, and 1 access to write block to main memory
- Access to S: Temporal Locality
- Access to A[i]: Spatial Locality (A[i])



1

Replacement Block Number 0123456789012345678901 Memory Cache CPU need this

- · Cache cannot hold all blocks
- Replace a block by another that is currently needed by CPU



dçe

Basic Cache Design & Operation Issues

- Q1: Where can a block be placed cache?
 (Block placement strategy & Cache organization)
 - Fully Associative, Set Associative, Direct Mapped.
- Q2: How is a block found if it is in cache? (Block identification)
 - Tag/Block.
- Q3: Which block should be replaced on a miss? (Block replacement)
 - Random, LRU, FIFO.
- Q4: What happens on a write? (Cache write policy)
 - Write through, write back.



dce

Q1: Where can a block be placed?

Block Number 0 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6

Set Number

Cache




Fully Associative anywhere


(2-way) Set Associative anywhere in set 0 (12 mod 4)

01234567

Direct Mapped only into block 4 (12 mod 8)




Block 12



Direct-mapped Cache


- Address: N bits (2^N words)
- Cache has 2^k lines (blocks)
- Each line has 2^b words
- Block M is mapped to the line M % 2^k
- Need t = N-k-bTag bits to identify mem. block
- · Advantage: Simple
- Disadvantage: High miss rate
- What if CPU accesses block N0, N1 and N0 % 2^k = N1 % 2^k?







- Access N0, N1 where N0 % $2^k = N1 \% 2^k$
- Replace a block while there are many rooms available!









Fully associative cache

- CAM: Content Addressable Memory
- Each block can be mapped to any lines in cache
- Tag bit: t = N-b. Compared to Tag of all lines
- Advantage: replacement occurs only when no rooms available
- Disadvantage: resource consumption, delay by comparing many elements



2

Set-Associative Cache Tag Index Block Offset b V Tag Data Block V Tag Data Block Word or Byte HIT

W-way Set-associative Cache

- Balancing: Direct mapped cache vs Fully associative cache
- Cache has 2^k sets
- Each set has 2^w lines
- Block M is mapped to one of 2^w lines in set M
 2^k
- Tag bit: t = N-k-b
- Currently: widely used (Intel, AMD, ...)



2

4K Four-Way Set Associative Cache: **MIPS Implementation Example Block** Address Tag Offset Field Index **Field** 1024 block frames Each block = one word 4-way set associative 1024 / 4= 256 sets Can cache up to 254 2^{32} bytes = $\overset{\cdot}{4}$ GB of memory Set associative cache requires parallel tag matching and more complex hit logic which may increase hit time 4-to-1 multiplexor Tag = 22 bits Index = 8 bits Mapping Function: Cache Set Number = index= (Block address) MOD (256)

Q2: How is a block found?

- Index selects which set to look in
- Compare Tag to find block
- Increasing associativity shrinks index, expands tag. Fully Associative caches have no index field.
- Direct-mapped: 1-way set associative?
- Fully associative: 1 set?

Memory Address

Block Address	Block	
Tag	Index	Offset



21

dce

What causes a MISS?

- Three Major Categories of Cache Misses:
 - Compulsory Misses: first access to a block
 - <u>Capacity Misses</u>: cache cannot contain all blocks needed to execute the program
 - Conflict Misses: block replaced by another block and then later retrieved - (affects set assoc. or direct mapped caches)
 - Nightmare Scenario: ping pong effect!



Block Size and Spatial Locality Block is unit of transfer between the cache and memory 4 word block, Word0 b=2block address offset_b Split CPU address 32-b bits b bits $2^b = block size a.k.a line size (in bytes)$ Larger block size has distinct hardware advantages less tag overhead · exploit fast burst transfers from DRAM · exploit fast burst transfers over wide busses What are the disadvantages of increasing block size? Fewer blocks => more conflicts. Can waste bandwidth.

dce

Q3: Which block should be replaced on a miss?

- · Easy for Direct Mapped
- Set Associative or Fully Associative:
 - Random
 - Least Recently Used (LRU)
 - · LRU cache state must be updated on every access
 - true implementation only feasible for small sets (2way, 4-way)
 - pseudo-LRU binary tree often used for 4-8 way
 - First In, First Out (FIFO) a.k.a. Round-Robin
 - · used in highly associative caches
- Replacement policy has a second order effect since replacement only happens on misses



Q4: What happens on a write?

- · Cache hit:
 - write through: write both cache & memory
 - · generally higher traffic but simplifies cache coherence
 - write back: write cache only (memory is written only when the entry is evicted)
 - · a dirty bit per block can further reduce the traffic
- Cache miss:
 - no write allocate: only write to main memory
 - write allocate (aka fetch on write): fetch into cache
- Common combinations:
 - write through and no write allocate (below example)
 - write back with write allocate (above Example)



29

dce

Reading assignment 1

- Cache coherent problem in multicore systems
 - Identify the problem
 - Algorithms for multicore architectures
- Reference
 - eecs.wsu.edu/~cs460/cs550/cachecoherence.pdf
 - ... More on internet



Reading assignment 2

- Cache performance
 - Replacement policy (algorithms)
 - Optimization (Miss rate, penalty, ...)
- Reference
 - Hennessy Patterson Computer Architecture. A Quantitative
 - www2.lns.mit.edu/~avinatan/research/cache.pdf
 - ... More on internet

