Table of	* Contents:	2	LTC7851 Demo Bo Quad-Phase 5V,	pard 45A Buck Converter		5		
A	2. Power Input	Power Input Power_Input.sch						A
	3. +5V Control	POS5_Control.sch						
	4. +5V Phase 1	POS5_Phase_1 POS5_Phase_1.sch						
	5. +5V Phase 2	POS5_Phase_2 POS5_Phase_2.sch						
	6. +5V Phase 3	POS5_Phase_3 POS5_Phase_3.sch						
В	7. +5V Phase 4	POS5_Phase_4.sch						В
	8. +5.5V MNG	P0S5P5_MNG P0S5P5_MNG.sch						
	9. Power Output	Power_Output Power_Output.sch						
	10. Mechanical	Mechanical Mechanical.sch						
c	11. Active Load 1	Active_Load_1.sch						С
	12. Active Load 2	Active_Load_2 Active_Load_2.sch						
	13. Active Load 3	Active Load 3 Active_Load_3.sch						
	14. Loop Response	Loop Response Loop_Response.sch						
D								D
				Sheet: / File: LTC7851_Demo.sc  Title:				
				Size: A Date KiCad E.D.A. kicad (5.	e: .0.1)-3		Rev:	

























