



DIGITAL

CHARGING and ON/OFF


USB-C Connector




USB-TO-UART




+3.3V LDO Converter +3V7 < VIN < +5V




PLAYBACK SWITCH




ESP-32




BOOT and RESET BUTTONS




VOLUME SWITCH



IO EXPANDER




HIGH SIDE SWITCHING




ANALOG & DISPLAY/SDCARD


VS1053 POWER FILTERS




VS1053 DAC




+1.8V LDO Converter +3V7 < VIN < +5V




+3.3V LDO Converter +3V7 < VIN < +5V



TFT&SD-CARD HEADERS



Audio Jack



Title		
File	Number	Revision
Date	9-08-2026	Sheet of
File	C:\Users\AFINAL\VERSION\SchDoc	Drawn By:

