

Operating System Support for PI Motion Controller

Controller	Platform	PCI driver	USB driver	Low level library	High level library	Terminal program	PIMikroMove	LabVIEW	MATLAB	NanoCapture	Installation package	Additional software
C-413	32-Bit		1		1	1	1	1	1		1	
	64-Bit		1		1	✓1	√ 1	1	1		1	
C-663	32-Bit		✓		1	1	1	1	1		1	
	64-Bit		1		1	√ ¹	√ ¹	1	√ ²		1	
C-663.11	32-Bit		✓		✓	1	1	1	1		✓	
	64-Bit		✓		1	√ ¹	√ ¹	✓	√ ²		1	
C-702	32-Bit				1	1	✓	✓	0		1	
	64-Bit				√ ¹	√ ¹	√ ¹	1	O ²		-	
C-843	32-Bit	✓		1	✓	1	✓	1	1		1	StateViewer
	64-Bit	1		√ 1	1	√ 1	√ 1	1	√ ²		1	StateViewer ¹
C-863	32-Bit		✓		✓	1	1	1	1		✓	
	64-Bit		✓		1	√ ¹	√ ¹	✓	√ ²		1	
C-863.11	32-Bit		1		✓	1	✓	1	✓		1	
	64-Bit		1		✓	√ 1	√ 1	1	√ ²		1	
C-867	32-Bit		✓		1	✓	✓	✓	✓		1	
	64-Bit		✓		1	√ ¹	√ ¹	✓	√ ²		1	
C-877	32-Bit		✓		✓	✓	✓	✓	✓		✓	
	64-Bit		✓		✓	√ ¹	√ ¹	✓	√ ²		✓	
C-884	32-Bit		✓		✓	✓	✓	✓	✓		✓	
	64-Bit		✓		✓	✓	✓	✓	√ ²		✓	
C-885	32-Bit		✓		✓	✓	✓	✓	✓		✓	
	64-Bit		✓		✓	1	✓	1	√ ²		✓	
C-887	32-Bit		✓		✓	✓	✓	✓	✓		1	Firmware Simulation, Working space simulation tool
	64-Bit		✓		1	√ ¹	√ ¹	1	√ ²		1	Firmware Simulation, Working space simulation tool ¹
C-891	32-Bit		✓		✓	1	1	1	✓		✓	
	64-Bit		✓		✓	✓	✓	✓	√ ²		1	
D-710	32-Bit		✓								1	PIOneAdjust
	64-Bit		✓								✓	PIOneAdjust ¹
E-517	32-Bit		✓		✓	✓	✓	✓	✓		1	
	64-Bit		✓		✓	√ ¹	√ ¹	✓	√ ²		-	
E-518	32-Bit		✓		✓	✓	✓	✓	✓		1	
	64-Bit		✓		✓	√ ¹	√ ¹	✓	√ ²		-	
E-609	32-Bit		✓								1	E-609 ConfigurationTool
	64-Bit		1								✓	E-609 ConfigurationTool ¹



Controller	Plattform	PCI driver	USB driver	Low level library	High level library	Terminal program	PIMikroMove	LabVIEW	MATLAB	NanoCapture	Installation package	Additional software
E-621 ³ E-625 ³ E-665 ³ E-816 ³	32-Bit		✓		✓	✓	1	✓	✓		✓	
E-621 ³ E-625 ³ E-665 ³ E-816 ³	64-Bit		✓		√ ¹	√ 1	√ 1	1	√ ²		-	
E-709	32-Bit		✓		1	✓	✓	✓	✓	✓	✓	
	64-Bit		✓		1	√ ¹	√ ¹	✓	√ ²	√ ¹	✓	
E-710	32-Bit				✓	✓	-	✓	0	✓	✓	PZTControl
	64-Bit				✓	√ ¹	-	✓	O ²	√ ¹	-	
E-712	32-Bit		✓		✓	✓	✓	✓	✓	✓	✓	
	64-Bit		✓		✓	√ ¹	√ 1	✓	√ ²	√ ¹	✓	
E-725	32-Bit		✓		✓	✓	✓	✓	✓	✓	✓	
	64-Bit		✓		✓	√ ¹	√ ¹	✓	√ ²	√ ¹	-	
E-753	32-Bit				✓	✓	✓	✓	✓	✓	✓	
	64-Bit				✓	√ ¹	√ ¹	✓	√ ²	√ ¹	-	
E-754	32-Bit		✓		✓	✓	✓	✓	✓		✓	
	64-Bit		✓		✓	√ ¹	√ ¹	✓	√ ²		-	
E-755	32-Bit				✓	✓	✓	✓	0	✓	✓	
	64-Bit				✓	√ ¹	√ ¹	✓	O ²	√ ¹	-	
E-761	32-Bit	✓			✓	✓	✓	✓	0	✓	✓	
	64-Bit	✓			✓	√ ¹	√ ¹	✓	O ²	√ ¹	-	
E-861	32-Bit		✓		✓	✓	✓	✓	✓		✓	
	64-Bit		✓		✓	√ ¹	√ ¹	✓	√ ²		✓	
E-870	32-Bit		✓		✓	✓		✓	✓		✓	E870Control
	64-Bit		✓		✓	✓		✓	√ ²		✓	
E-871	32-Bit		✓		✓	✓	✓	✓	✓		✓	
	64-Bit		✓		✓	✓	✓	✓	√ ²		✓	
E-873	32-Bit		✓		✓	✓	✓	✓	✓		✓	
	64-Bit		✓		1	✓	✓	✓	√ ²		✓	
F-206	32-Bit				1	1	1	1	0		✓	Firmware Simulation, Force Calculation tool
	64-Bit				√ ¹	√ ¹	√ ¹	1	O ²		-	
M-8x0	32-Bit				1	1	✓	✓	0		1	Firmware Simulation, Working space simulation tool
	64-Bit				√ ¹	√ ¹	√ ¹	1	O ²		-	
Hydra/Pollux	32-Bit				✓	1	1	1	1		✓	
	64-Bit				1	√ ¹	√ ¹	✓	√ ²		✓	

[✓] Available

Updated: November 2016

Available as 32-Bit version. Drivers need to be specially built for the 64-bit platform. Applications like PIMikroMove can also be used as 32-bit version, as well as DLLs like the High Level Library (GCS DLL). Customers who build their own software especially for 64-bit will need native 64-bit libraries. They are welcome to ask for a beta version of those.

MATLAB requires a third party 64bit C++ Compiler. Such compilers are available for free and must be installed by the user.
A list of suitable compilers is provided by MathWorks: http://www.mathworks.com/support/compilers/R2014b/index.html

O A beta version is available on request

Not available

E-816 is the interface module built in E-621, E-625 and E-665 and is used for communication with the host-software