Nimbus Pro User Manual. Page 1: Overview. The Nimbus Pro measures temperature, humidity, pressure, wind speed and direction, rainfall and UV index. It reports to the display bridge every 60 seconds.

Nimbus Pro User Manual. Page 2: Setup. Charge the 3,400 mAh pack for 4 hours before first use. Align the arrow on the wind vane with true north; the app has a compass helper. Level the station with the built-in bubble.

Nimbus Pro User Manual. Page 3: Maintenance. Clean the rain gauge funnel every 3 months and after storms; leaves and insects block it. Wipe the solar panel monthly. Replace the anemometer bearings every 3 years.

Nimbus Pro User Manual. Page 4: Troubleshooting. Error E12 means the rain gauge is blocked: clean the funnel. Error E31 means the wind sensor is not turning: check for ice or debris. Error E40 means the battery is too cold to charge.