# Discrete-time variable

## Diego Trapero

## **Table of contents**

1	Sampling	2
2	Signal reconstruction	4
3	Sample and hold	4
4	AD Converters	4
5	DA Converters	4
6	Z transform	4
7	Digital filters	4
	7.1 IIR filters	
	7.2 FIR filters	4
8	Reference	4
9	More	5

#### 1 Sampling

Signals

**Sampling** Sampling is the reduction of a continuous time signal to a discrete time signal by taking values at different instants of time.

Sampling at a constant rate: for functions that vary with time, let s(t) be a continuous function (or signal) to be sampled, and let sampling be performed by measuring the value of the continuous function every T units of time, which is called the sampling interval. Thus, the sampled function is given by the sequence s(nT), for integer values of n, n = 0, 1, 2, 3, ... #

- Sampling period,  $T_s$  is the time interval between samples.
- Sampling frequency  $f_s$  is the is the number of samples per time unit, or the sampling rate. It is the reciprocal of the period,  $f_s = 1/T_s$

Aliasing Aliasing is the effect that occurs when sampling a continuous signal, whereby frequency components higher than half the sampling frequency are transformed into lower frequency components. These components, or aliases, (which where a valid part of a signal, or noise) may appear in the band of the signal that we are interested in, thus making the reconstruction of the original signal impossible. From the time-domain point of view, aliasing occurs when we sample a continuous signal at a too low sample rate. The resulting sequence is an alias of the original signal, with lower frequency components.

• From the *time domain point of view*, aliasing occurs when trying to reconstruct a high frequency signal from the samples taken in a not high enough frequency. In this case, there are few low frequency values that can be used to reconstruct many different high frequency signals (all of them would output the same sequence when sampled), aliases of one another.

• From the frequency domain point of view, sampling a signal at sampling frequency  $f_s$  "folds" any frequency higher than  $f_s/2$  back into the frequency range  $0 - f_s/2$ . In other words, signal components with frequencies higher than  $f_s/2$  will produce the same samples as a signal with some frequency in the range  $0, f_s/2$ .  $f_s/2$  is known as Nyquist frequency or folding frequency. This effect is expressed in the form of the Nyquist theorem.

**Nyquist theorem** If s(t) is a continuous signal with finite bandwith, that contains no frequencies higher than  $f_{max}$ , it can be perfectly reconstructed from a sampling sequency taken at a sampling rate  $f_s \ge 2f_{max}$ .

- $f_{max}$  is the maximum frequency of the signal
- $f_s$  is the sampling frequency
- $f_s/2 = f_N$  is the Nyquist frequency

Shannon's enunciation: If a function x(t) contains no frequencies higher than B hertz, it is completely determined by giving its ordinates at a series of points spaced 1/(2B) seconds apart.

Aliased frequency of a real world frequency To obtain the aliased frequency of a high frequency component of a signal, substract  $f_s$  repeatedly from the frequency until you have a result in the range  $-f_s/2$ ,  $f_s/2$ . Then, take the absolute value. This rule defines different frequency zones that are considered to understand the problem of aliasing:

Choosing the sampling frequency If we have a signal with a known upper frequency of interest, we can double that frequency to get the Nyquist rate; that is, the sampling rate above wich you must sample in order to avoid aliasing.

- If the maximum frequency of the signal,  $f_{max}$  is known,  $f_s > 2f_{max}$
- If the maximum frequency is not known, but an histogram of the signal is available, we can determine the sampling frequency from the maximum slope point of the signal. This method gives very conservative results, often well above the minimum necessary  $f_s$  for the signal.

**Antialiasing filters** To avoid the problem of aliasing, a low-pass filter called antialising filter can be used before sampling to attenuate any frecuencies that may cause aliasing.

The filters represented in the figure are 1. An ideal (infinite order) filter, that only let frecuencies in the range  $[0, f_M]$  pass (the useful part of the signal). 2. A filter that let pass frecuencies, that let frecuencies between  $[0, f_N]$  pass (the complete alias-free zone). 3, A filter that let pass frecuencies between 0 and  $f_s - f_M$ . This filter let pass all the frecuencies before the aliases zones, where aliases may be mapped to the  $[0, f_M]$  range (the useful components of the signal). This is the most used filter because it is completely functional while having the minimum order.

Designing a Antialising Filter for sampling with a ADC

- 1. The gain in the  $[0, f_M]$  would ideally be 0dB (no gain/attenuation), to let the useful part of the signal pass unaltered. Other constant gain may be considered when increasing or decreasing the amplitude of the signal before the ADC is necessary.
- 2. All components after the  $f_s f_M$  frequency must be attenuated before the resolution of the ADC, so they cannot be registered. This will prevent any aliases mapping to the  $[0, f_M]$  band.

In the worst case, a signal with amplitude  $V_ref$ 

**Example** For a analog signal with  $f_{max} = 1000Hz$ , sampled at 5000 Hz, determine the order of the filter necessary to avoid aliasing in a 8 bits ADC.

- 2 Signal reconstruction
- 3 Sample and hold
- 4 AD Converters
- 5 DA Converters
- **6 Z** transform
- 7 Digital filters

#### Difference equation

$$y(n) = b_0(n) + b_1 x(n-1) + \dots + b_z(n-z) - a_1 y(n-1) - a_2 y(n-2) - \dots - a_p y(n-p)$$

- 7 IIR filters
- 7 FIR filters
- 8 Reference
  - $\bullet\,$  "Digital Signal Processing and the Microcontroller", Dale Grover, John Deller
  - "Instrumentación Electrónica", Miguel A. Pérez, Juan C. Álvarez, Juan C. Campo, Fco. Javier Ferrero, Gustavo J. Grillo. Editorial Thomson

- Wikipedia
- Sampling (signal processing), Wikipedia
- Butterworth filter, Wikipedia

### 9 More

Butterworth filter. Maximum flatness filter. The normalized Butterworth polynomials can be used to determine the transfer function for any low-pass filter cut-off frequency  $\omega_c$ , as follows

$$H(s) = \frac{G_0}{B_n(a)}$$
 , where  $a = \frac{s}{\omega_c}.$ 

To four decimal places, Butterworth polynomials are (expressed in quadratic factors)

Order	Polynomial $B_n(s)$
1	(s+1)
2	$s^2 + 1.4142s + 1$
3	$(s+1)(s^2+s+1)$
4	$(s^2 + 0.7654s + 1)(s^2 + 1.8478s + 1)$
5	$(s+1)(s^2+0.6180s+1)(s^2+1.6180s+1)$
6	$(s^2 + 0.5176s + 1)(s^2 + 1.4142s + 1)(s^2 + 1.9319s + 1)$
7	$(s+1)(s^2+0.4450s+1)(s^2+1.2470s+1)(s^2+1.8019s+1)$
8	$(s^2 + 0.3902s + 1)(s^2 + 1.1111s + 1)(s^2 + 1.6629s + 1)(s^2 + 1.9616s + 1)$

From Butterworth filter, Wikipedia