NanoEls H5

Z X Y: 5V ENA DIR STEP PULSE SCALE ENCODER: 5V GND B A

JSIGNAL: JB JY JX JZ

KEYBOARD: 5V GND CLK DATA

POWER JPOWER: 5V 5V GND GND

MISC: 5V GND I010 I011

Z X Y Y JSIGNAL KEYBOARD
ZPULSE XPULSE YPULSE JPOWER ENCODER
ZSCALE XSCALE YSCALE POWER MISC