To Enable or Disable Automatic Unlock:

Automatic Unlock¹ is an optional feature that will only be activated when it is programmed. It can be disabled at any time with the registered manager bypass key.

Press the "C" Key	\mathbf{C}
Press the "key symbol"	0-
Touch a registered Manager Bypass Key to the key slot until you hear audible feedback	F)
The LED will emit a solid red light	•
Press the "1" through "8" for the number of hours	1- 8
For example, if "3" is pressed Digilock will automatically unlock 3 hours after it was locked.	
OR	
Press "9" to disable the Automatic Unlock Feature	9
Press the "key symbol"	0-
A double tone signifies successful programming	u

¹ Warning: Automatic Unlock is an optional feature that functions only if it is activated. Digilock is shipped with this feature disabled. Activation of this feature is not recommended as it may pose liability issues depending on your facilities operation.