

Assembly Instructions

1. The Titan will arrive to your curbside in the crate as pictured in picture #1.
2. With scissors, cut the plastic straps and remove the top and side panels of the crate. Then remove the parts inside the crate and place near the desired assembly area.
3. After removing the contents, your crate should look like picture 3.
4. With someone's help, remove the top 4 bolts of the crate.
5. Lift and remove the partially assembled Titan frame. Remove the bottom 4 bolts of the crate and you are ready to begin assembly.
6. Have someone hold the frame in place.

Note: When assembling, always use washer with every bolt and nut.

7. Locate the bottom frame brace.
8. With the two sides of the frame in the upright position, insert the frame base and hand tighten the large bolts to each side on the front of the frame. (The #'s should match - #1 to #1, #2 to #2, etc.)

two pulleys →
no numbers

9. Attach pulley to the top of the frame. Match the # on the bottom of the pulley with the same # on top of the frame.
10. Insert and feed cables through the hollow arms of the lower pulley frame and pull them through the center. Insert and align pulley with top/bottom holes and insert bolt from top and fasten washer and nut from beneath. (It may be helpful to see final assembled part in step 12)

11. Cables should feed as shown (picture 11).

12. Align the lower pulley frame to the holes on the inside of the bottom frame brace and fasten bolts.

doing so -
would put
part on
backwards

is on
left side

should be
on right
to make
pulley

go
towards
front

13. With someone to hold the part in place, align the # on one end of the part pictured (13) with the equivalent # on the side frame. The pulley should be facing upwards and towards the front of the machine. Fasten with large bolts and washers.

14. Feed the cable through the pulley stand and then insert the pulley so that the cable rests on top. Insert small bolt and washer and tighten nut.

15. With steps 13 and 14 completed, the top of your Titan should appear as in picture 15.

16. Attach pulley (#11) to the top right side of the machine where its equivalent # appears. Use small bolt, washer and nut to fasten.

17. Locate the springs as shown in picture 17.

18. Insert the springs into the holes on the rear of the machine.

— Springs do not fit

19. Should appear as shown.

20. Assemble the counter balance system as shown in picture #20. The inner threads on one side of each rod should be facing towards the right of picture.

21. Insert the guide rods down through the springs and into the holes of the frame. Screw the guide rods into the threaded holes on top.

— right (front)
rod did not
fit.

Note: The counter-balance system works by inserting the locking pin from the top/center of the machine into the center hole of the smith carriage crossbar. When weight is added to the counter-balance system the smith carriage becomes lighter.

22. Attach the cables (from step 16) to the counter balance system by tightening the eye at the end of the cable between the washer and post, as pictured.

23. Insert the locking exercise handles (23A) into both sides of the smith carriage as shown in step 23B. Attach the center bar of the smith carriage (23C) to

(see
attached) →
not on instructions
that came with Titan

each side of the smith carriage as shown in step 23D. Align the matching #'s to assure proper assembly. The center pin and sticker (80 LBS.) should face the front of the machine. Before completely tightening these bolts, go back and tighten all bolts that were not previously tightened. Now tighten carriage bolts firmly.

160 sticker

24. Attach the lat pull down pulley (picture 25) to the upper frame cross bar (picture 24) and tighten bolts.
25. see step 24.
26. With assistance, attach the upper frame crossbar on the top and front side of the machine and fasten bolts. The pulley should be facing upwards toward the front of the machine.
27. Remove bolts, leaving the two washers, from outside of the smith carriage. Also remove the two upper bolts (not pictured), leaving the two washers in place. Repeat for the opposite side of the machine.
28. Align the four holes of the side panel with the bolts.
29. Place additional washers on the outside of the panel and fasten the nuts tightly as shown in step 30.
30. See step 29.
31. Remove nut and bolt from the weight posts.
32. Insert through side panel hole, as pictured. Align with the slot on the opposite side, place washer (use the 2 washers that were mailed in your packet), and hand-tighten. The post may have a slight angle; adjust so that the post angles upwards and firmly tighten bolt. Repeat for opposite side.
33. Remove screws and washers of the side panel, align with screw holes, replace screws and washers and fasten. Repeat for opposite side.
34. Follow steps 34a-d, remove nuts and washers, insert weight posts in holes at the rear of the machine, replace the washer and tighten the nuts.
35. Attach pulley (picture 35) to the part pictured in step 36a, as shown. Place washers and fasten bolts firmly.
36. Place part from 36a (pictured) to align with the holes just above the bottom frame brace at the front of the machine. Place washer and fasten bolts.
37. Attach the bench support post to the front of the machine, as shown. Hand-tighten bolts.
38. Hand-tighten bolts.
39. Place bench on center of support bar and rear roller as shown.
40. Insert the roller bars for the sliding bench.
41. Be sure to feed rod through the locking mechanism (as shown in 41a). Feed with the threaded hole first (as shown in 41b). Insert rods into the holes as shown in 41c.
42. Fasten washer and nuts to guide rods and hand-tighten.
43. Slide bench forward and insert rods into part (pictured in 43a) as shown in 43b. Fasten bolts as shown in 43c.
44. Attach the knee support to the end of the bench and fasten bolts.
45. Locate the two cables beneath the bench that extend between the two pulleys.
46. With a washer between the two cables, insert bolt and fasten cables as shown.
47. Be sure washer is placed between the two cables.
48. Do not allow the cables to sag. They must be straight!
49. Assemble the organizer rack as shown. (This is used to store the attachments when not in use).

44 to 1011. - Assembly should sag with upper frame should fall

2 - Washer, not bolt

Guide rod holes don't 11 holes up. Should mention to go back & tighten hand-tight bolts at this point

