


Insert simcard & connect power lan cable using computer Ip 192.168.0.128 is default ip addres


Login page etic m2m

RAS-C-100-LE

Click here to start the configuration wizard








Insert access point (APN)

Anp serch Googel




Insert your ip address ex 192.168.2.10


Or chnge pc ip add 192.168.2.4 default gate way 192.168.2.1




Press the next




Insert your information



## Select save & next



Note this information click apply configuration





Its shows product key copy and save this key

https://www.etictelecom.com/wp-content/uploads/2020/09/M2Me v221 en.zip


# DOWNLOD THIS LINK SOFTWARE


## Install the software






### Creat new site









Douable click pune

## User name admin




You feel password Press ok





Connected sussesfully



Ping is success fully done.