


Configuration of digital output and SMS alert TRB 141 FW VERSION

TRB1_R_00.07.02.7








General setting




Action setting








Condition







In this diagram pin no 14 and pin no 4 are will be short
I given the input on the pin no 7 is positive and pin no 10 negative
And got a output on pin no 5 and negative at pin no 10