LACP Link With BluBoxx Switch BBIES-M-GE2GF

1) Take BluBoxx Switch BBIES-M-GE2GF 2 port SFP Managed Switch
2) Default IP address is given in User Manual
3) Before connecting Switch to power supply please check Power Rating

Configuration

Steps 1

PC and device should be in same IP Network. Change PC IP if needed

Please Refer User Manual for IP address User name & Password
Default IP 192.168.0.100
User name-admin
Password –admin

Login to the device

LACP Link Aggregation

For Switch 1

Connect PC to switch 1 directly

Logging on the Switch 1

System Management ⟩ Configuration Management ⟩ Save

System Management ⟩ System Setting ⟩ System Restart

Test Report