

How to create ERPS Ring by using Ring Wizard (4 Switch)

- 1) Take 4 Managed Ethernet Switch And check All IP Address
- 2) Default IP address is given in User Manual
- 3) Before connecting Switch to power supply please check Power Rating

Configuration

Steps 1


PC and device should be in same IP Network. Change PC IP if needed

Please Refer User Manual for IP address User name & Password

Default IP 192.168.0.100 User name-admin

Password -admin

Login to the device










Step 2
Change device IP as per choice





And Click on Save

Repeat same process for remaining Switches



Ring Topology

Setup steps

Set ERPS Configuration on Switch 1

Connect PC to switch 1 directly

Logging on the Switch 1


Click On Ring

Ring Wizard

Total Switch No- 4 & Switch ID-1

Total Switch Number (3 ~ 30): 4 Switch ID: 1 Next


Click On Next




Select Any 2 Ports of your choice e.g (Port 1 & Port 2)

Click on Save Click on Ok Click on apply Then Click on Save





Click on apply



Click on OK

And Save




Set ERPS Configuration on Switch 2

Click on Ok

Connect PC to switch 2 directly

Click on set




Click on apply

Then Click on Save





Click on apply




Click On OK




Set ERPS Configuration on Switch 3

Connect PC to switch 3 directly








Click On OK




Set ERPS Configuration on Switch 4

Connect PC to switch 4 directly

Click On Ring Ring Wizard Total Switch No- 4 & Switch ID-4




Click on Save



Click on apply





Click On OK