Softing PROFIBUS-Tester V5 (BC-700-PB) licence activations steps






License key of license certificate copy

02-2A4ED5F5F1863299-F1863299-F1863299-C2107CEF-DC4E3E62-DC4E3E62DC4E3E62


Next

Open


Softing license manger & connect PROFIBUS-Tester pc



click softing interface



pest license key & click enable license.



License is activated completed.