

Modbus Gateway 3oneData GW1101-1D with Autonics Temperature Sensor

- 1) Take 3onedata GW1101-1D Modbus Gateway
- 2) Refer User Manual for Default IP address
- 3) Before connecting Device to Power supply please check Power Rating

Configuration


Steps 1

PC and device should be in same IP Network. Change PC IP if needed


Please Refer User Manual for IP address User name & Password

Default IP 192.168.1.254 User name-admin Password –admin Login to the device

Setup








BluBoxx Communication Pvt. Ltd.





Add The Device slave ID Or Range of slave ID for Multiple Devices



BluBoxx Communication Pvt. Ltd.

An ISO 9001:2015 Certified Company



Test Result

