


Winning Solutions...

BluBoxx Communication Pvt. Ltd.




Architecture







- WORKING TIME CONNECTIONS.
- □ GREEN CABLE IS D1+
- □ RED CABLE IS DO-



BBNP301 Configuration



- Open Browser and Logging to the BBNP301
- Login ip address is 192.168.1.254
- □ First power on BBNP301 & energy meter.
- Change computer ip address.
- example ip address 192.168.1.13
- □ subnet mask 255.255.255.0
- gate way 192.168.1.1

BBNP301 Configuration



- Open Browser and Logging to the BBNP301
- □ Login 192.168.1.254
- USERNAME:admin
- Password: admin
- open>>Main Menu>>Serial Port Configuration>>Operation
 Modes.
- Select mode: TCP SERVER MODE
- □ INSERT Local port Local port range 1-65535 (ex:-30000)

BBNP301 Configuration



- >>Main Menu>>Serial Port Configuration>>Communication
 Paramètres
- Insert all information of energymeter.
- Baud rate , Data bits, Stop bits, Parity ,
- □ Flow control, Interface
- □ Interface RS485/RS422 SELECT

www.bbcpl.in ⁷

Operation Modes

Port: COM1 ✓


COM1		
Mode	Tcp Server Mode ✓	
Max connection	1	
Local port	30000	(1-65535)
Password check	Disable ~	
Send message	Device name 🕶	
Cmd type	Disable ~	
TCP alive check time	60	(0-65535 s)
Inactivity time	0	(0-65535 s)
Ignore jammed IP	Enable ~	
Queue access	Enable v	
Response timeout	100	(10-65535 ms)
Frame break	100	(10-65535 ms)
Apply to all ports		
		Submit Cancel

Current Location>>Main Menu>>Serial Port Configuration>>Communication Parameters

Communication Parameters

Port: COM1 ✓

COM1




Data Packing 🔲

Apply to all ports 🔲

Submit

Cancel



MOD SCAN OUTPUT.

10

10

Contact Us



BluBoxx Communication Pvt. Ltd.

102/B, Surekha Apartment, Pune Satara Road, Pune-411037. Maharashtra, India.

Tel:-+91-7875432180 Email:-sales@bbcpl.in