



Connect USB to Serial converter to PC check the COM port assigned,



OPEN Putty and select serial and the assigned COM port and speed. Speed for BluBoxx sw is 115200. Click open,



Hit Enter

```
Username: admin
Password: *****
Switch>*Dec 05 2013 00:06:33: %AAA-5-LOGIN: New console connection for user admin, source 0.0.0.0
ACCEPTED
```

Username: admin Password: admin Hit Enter again

```
Username: admin
Password: *****
Switch> *Dec 05 2013 00:06:33: %AAA-5-LOGIN: New console connection for user admin, source 0.0.0.0
ACCEPTED

Switch> enable
Password: *****
Switch0# *Dec 05 2013 00:07:46: %AAA-6-INFO: User 'admin' enter privileged mode from console with level '15' success
```

It will ask for password. Password: admin, hit Enter

```
Username: admin
Password: *****

Switch> *Dec 05 2013 00:06:33: %AAA-5-LOGIN: New console connection for user admin, source 0.0.0.0

Password: *****

Switch> enable
Password: *****

Switch0# *Dec 05 2013 00:07:46: %AAA-6-INFO: User 'admin' enter privileged mode from console with level '15' success

Switch0# restore-defaults
System: restore factory defaults. Do you want to reboot now? (y/n)*Dec 05 2013 00:08:36: %SYSTEM-6
-INFO: Sysinfo variable 'resetdflt' is set to value '1'

*Dec 05 2013 00:08:37: %SYSTEM-6-INFO: Sysinfo variable 'web-remind' is set to value 'Y'

*Dec 05 2013 00:08:45: %SYSTEM-5-INFO: System restore to default

Y
Rebooting now...

*Dec 05 2013 00:08:45: %SYSTEM-4-REBOOT: System reboot
```

Give command restore-defaults then hit enter

Then type y it will reboot.

Switch has been factory reset press any key to continue

```
static route aging success
static route ping success
System Post Initial...OK
Port Post Initial...OK
Init Voice VLAN OUI Default Entry...OK
Init Voice VLAN OUI Default Entry...OK
Init Vizure illance VLAN OUI Default Entry...OK
Generating file "startup-config.cfg"...OK
====== Backup Config File Synchronize [Start] =====
===== Backup Config File Synchronize [end] ======

*Dec 05 2013 00:00:32: %SYSTEM-5-INFO: Logging is enabled
*Dec 05 2013 00:00:32: %SYSTEM-5-INFO: Sysinfo variable 'resetdefault' is set to value '0'
webs: Listening for HTTP requests at address 127.0.0.1
SSL: Initializing SSL
Press any key to continue
Username: admin
Password: *****
Switch>*Dec 05 2013 00:01:38: %AAA-5-LOGIN: New console connection for user admin, source 0.0.0.0
ACCEPTED
```