

	1	2	3	4	5	6	7	8
A	01_waveshare_header							
	: 01_waveshare_header.kicad_sch							
	02_i2s_differential							
	: 02_i2s_differential.kicad_sch							
B	03_mic_cable							
	: 03_mic_cable.kicad_sch							
C								
D								
E								
F	1	2	3	4	5	6	7	8

SCHEMATIC REVIEW ONLY – PCB/HIL release gates remain open		
digitie/canview		
Sheet: /		
File: controller–adapter.kicad_sch		
Title: CANView / controller–adapter		
Size: A3	Date: 2026–09–05	Rev: R1 REVIEW
KiCad E.D.A. 10.0.6	Id: 1/4	

Controller adapter ONLY: use onboard RTC0x51. Camera disabled/disconnected. GPIO38=BCLK,39=WS,40=I2S1 DIN.

J1
Waveshare 2x16 mating male

Pin	Signal	Pin	Signal
1	BAT_NC	17	GPIO45_NC
2	5V_IN	18	GPIO18_NC
3	GND	19	GPIO46_NC
4	GND	20	BOOT_NC
5	GPIO21_NC	21	GPIO47_NC
6	USB_DM_NC	22	RESET_NC
7	MIC_BCLK	23	GPIO48_NC
8	USB_DP_NC	24	PWR_NC
9	MIC_WS	25	RXD4A_NC
10	GPIO11_NC	26	SCL7_NC
11	MIC_SD	27	TXD43_NC
12	GPIO10_NC	28	SDA8_NC
13	GPIO41_NC	29	GND
14	GPIO9_NC	30	GND
15	GPIO42_NC	31	3V3_IN
16	GPIO17_NC	32	3V3_IN

C1
4.7u

C2
100n

SCHEMATIC REVIEW ONLY – PCB/HIL release gates remain open
digitlie/canview
Sheet: /01_waveshare_header/
File: 01_waveshare_header.kicad_sch
Title: CANView / 01_waveshare_header

Size: A3	Date: 2026-09-05	Rev: R1 REVIEW
KiCad E.D.A. 10.0.6		Id: 2/4

[digitie/canview](#)

Title: CANView / 01_waveshare_header

	7	8
--	---	---



