This shows the scenario of a user clearing the device's saved sessions. The user only need to press the clear button when the device and the display for recordings is on, and no session is running.

