

DIHWorld Audio

Utility / Observation Technical Manual

Current product versions, controls, presets, meters, and placement

DIHWorld Audio builds connected production systems around the Imhotep 369 Engine—a Triadic Harmonic Lattice—and Ma'at 357 / MomentumBend. Phi-derived control and the canonical Phi/2 ceiling preserve movement, balance, and musical intent without brickwall limiting.

This edition documents 1 current products. Release numbers are taken from the installed DIHWorld Audio Audio Units verified on 2026-09-05; they are product versions, not a shared catalog version.

Canon reference: normalized $\Phi/2 = 0.809016994$. MomentumBend shapes motion and containment; the ceiling is a canonical boundary, not permission for hard limiting.

Operating law: begin from reset or a purpose-matched preset, compare at equal loudness, change one system at a time, and judge the result in the full arrangement.

SESHAT

RELEASE	FAMILY	PLACEMENT
v1.0.6	Utility / Observation	Observation

Final observation and analysis lane with restored spacious panel layout and optional peak hold; Full Observation shows the complete meter set, while each named preset shows only the meter or panel relevant to that view. It is not a tone-shaping processor.

Recommended use: observation-first advisor/meter; translates phi score into guidance without altering audio

Customer formats: AU, VST3, Standalone

Exposed parameter surface

Parameter ID	Display name	Type
hold_peaks	Hold Peaks	Bool
gainmatch	Gain Match	Bool
channelmode	Channel Mode	Choice
dualmonolink	Dual Mono Link	Choice

Factory starting points

SESHAT FULL OBSERVATION • SESHAT PEAK / TRUE PEAK • SESHAT TRANSIENT IMPACT • SESHAT FIELD PRESSURE • SESHAT MOMENTUM
DRIFT • SESHAT PHI ALIGNMENT • SESHAT INTEGRITY GRID • SESHAT CROWN / MOONSHOT • SESHAT LUFS BODY • SESHAT CORRELATION
• SESHAT SOLFEGGIO ENERGY • SESHAT TRANSIENT HISTORY • SESHAT SIDE PRESSURE • SESHAT PRINT SCAN

Meters and visualizers

LUFS / BODY READ: Short-window perceptual loudness. Use for loudness context, not as the only delivery decision.

LEFT INPUT / RIGHT OUTPUT: Peak, RMS body, impact, and held peak. Shows entry and exit behavior; Hold Peaks retains the highest marker.

CORRELATION / MONO SAFETY: Left/right phase relationship. +1 is coherent, 0 is wide/uncorrelated, negative values risk cancellation.

SOLFEGGIO FREQUENCIES: Energy near the seven displayed resonant bands. Shows tonal concentration around 396 through 963 Hz.

IMPACT: Fast peak relative to the canon ceiling. Higher means stronger transient force.

FIELD: Body RMS plus stereo-side pressure. Higher means denser sustained spatial load.

MOMENTUM: Change in impact plus transient shape. Higher means faster, more active movement.

PHI ALIGNMENT: Proximity to DIH golden-ratio checkpoints. Higher means field pressure sits nearer a PHI reference point.

INTEGRITY: Similarity between impact and field pressure. Higher means transients and body remain proportionate.

CROWN: Weighted combined observation score. Summarizes impact, field, momentum, alignment, and integrity.

MOON: Transient shape plus momentum. Higher means stronger forward or launching behavior.

HF RISK: High-frequency energy imbalance. Higher values warn of potential harshness.

PHASE RISK: Correlation and side-energy danger. Higher values warn of mono cancellation.

LEVEL RISK: Peak/ceiling and transient danger. Higher values warn of insufficient headroom.

COMFORT: Alignment, integrity, and low-risk balance. Higher values indicate a more stable field.

ADVISOR: Combined risk recommendation. A diagnostic suggestion; it does not change audio.

REEL 1 - Impact: Transient-force rank. First reel; 396 is low and MOON is highest.

REEL 2 - Field: Sustained spatial-pressure rank. Second reel; numbers are symbolic stages, not Hz.

REEL 3 - Momentum: Motion/transient-change rank. Third reel; higher stages mean more movement.

REEL 4 - Alignment: PHI-alignment rank. Fourth reel; higher stages mean closer alignment.

REEL 5 - Moon: Forward-propulsion rank. Fifth reel; higher stages mean stronger launch.