

DIHWorld Audio

Creative Transform Technical Manual

Current product versions, controls, presets, meters, and placement

DIHWorld Audio builds connected production systems around the Imhotep 369 Engine—a Triadic Harmonic Lattice—and Ma'at 357 / MomentumBend. Phi-derived control and the canonical Phi/2 ceiling preserve movement, balance, and musical intent without brickwall limiting.

This edition documents 3 current products. Release numbers are taken from the installed DIHWorld Audio Audio Units verified on 2026-08-24; they are product versions, not a shared catalog version.

Canon reference: normalized $\Phi/2 = 0.809016994$. MomentumBend shapes motion and containment; the ceiling is a canonical boundary, not permission for hard limiting.

Operating law: begin from reset or a purpose-matched preset, compare at equal loudness, change one system at a time, and judge the result in the full arrangement.

SlotMachine

RELEASE	FAMILY	PLACEMENT
v2.2.6	Creative Transform	Creative Transform

Three-chamber creative host that combines source, opposition, and resolution through architecture, blend, morph, and containment.

Recommended use: creative transform

Customer formats: AU, VST3, Standalone

Exposed parameter surface

Parameter ID	Display name	Type
chamberA	Chamber A Source	Choice
chamberB	Chamber B Opposition	Choice
chamberC	Chamber C Resolution	Choice
architecture	Architecture	Float
blend	Blend	Float
morph	Morph	Float
containment	Containment	Float
channelmode	Channel Mode	Choice
dualmonolink	Dual Mono Link	Choice
gainmatch	Gain Match	Bool

Factory starting points

SLOT MACHINE CANON RESET [Stereo] • RELIC SPIN [Stereo] • IMPACT REROUTE [Stereo] • GOLDEN COLLISION [Stereo] • SOVEREIGN FLIP [Stereo] • WORMHOLE PRIZE [Stereo] • PARALLAX JACKPOT [Stereo] • FOCUSED CHAMBER [Stereo] • SLOT MACHINE CANON RESET [Mono] • RELIC SPIN [Mono] • IMPACT REROUTE [Mono] • GOLDEN COLLISION [Mono] • SOVEREIGN FLIP [Mono] • WORMHOLE PRIZE [Mono] • PARALLAX JACKPOT [Mono] • FOCUSED CHAMBER [Mono] • SLOT MACHINE CANON RESET [Dual Mono] • RELIC SPIN [Dual Mono] • IMPACT REROUTE [Dual Mono] • GOLDEN COLLISION [Dual Mono] • SOVEREIGN FLIP [Dual Mono] • WORMHOLE PRIZE [Dual Mono] • PARALLAX JACKPOT [Dual Mono] • FOCUSED CHAMBER [Dual Mono]

Meters and visualizers

- INPUT:** Input peak. Confirms level entering the three chambers.
- OUTPUT:** Output peak. Use for level matching.
- RMS:** Average program body. Shows sustained density.
- CREST:** Peak-to-RMS relationship. Higher values mean sharper transients; lower values mean denser material.

ARCHAEOLOGIST X

RELEASE	FAMILY	PLACEMENT
v2.0.6	Creative Transform	Creative Transform

Forensic recovery processor for excavation, recovery field, harmonic extraction, layer selection, gate, and parallel mix.

Recommended use: creative recovery/excavation

Customer formats: AU, VST3, Standalone

Exposed parameter surface

Parameter ID	Display name	Type
power	Power	Bool
gainmatch	Gain Match	Bool
excavation	Excavation Engine	Float
recovery	Recovery Field	Float
harmonic	Harmonic Extraction	Float
forensic	Forensic Layer	Float
gate	Gate	Float
mix	Mix	Float
output	Output	Float
profile	Profile	Choice
mode	Mode	Choice
channelmode	Channel Mode	Choice
dualmonolink	Dual Mono Link	Choice

Factory starting points

ARCHX CANON RESET [Stereo] • RELIC VOICE [Stereo] • DUST DETAIL [Stereo] • BODY RECOVERY [Stereo] • AIR SCRIPT [Stereo] • FORENSIC LENS [Stereo] • TEMPLE MEMORY [Stereo] • FULL EXCAVATION FIELD [Stereo] • ARCHX CANON RESET [Mono] • RELIC VOICE [Mono] • DUST DETAIL [Mono] • BODY RECOVERY [Mono] • AIR SCRIPT [Mono] • FORENSIC LENS [Mono] • TEMPLE MEMORY [Mono] • FULL EXCAVATION FIELD [Mono] • ARCHX CANON RESET [Dual Mono] • RELIC VOICE [Dual Mono] • DUST DETAIL [Dual Mono] • BODY RECOVERY [Dual Mono] • AIR SCRIPT [Dual Mono] • FORENSIC LENS [Dual Mono] • TEMPLE MEMORY [Dual Mono] • FULL EXCAVATION FIELD [Dual Mono]

Meters and visualizers

INPUT / OUTPUT: Live pre/post peak. Use for bypass and level matching.

EXCAVATION: Low/deep recovery activity. Shows energy being uncovered by excavation.

RECOVERY: Recovered-source contribution. Shows how much repaired material is active.

HARMONIC: Extracted harmonic activity. Shows reconstructed tonal information.

FORENSIC: Forensic layer/gate activity. Shows the selective analysis path at work.

Observation Field: Combined four-process activity. A process summary, not a spectrum.

SERQET

RELEASE	FAMILY	PLACEMENT
v1.0.3	Creative Transform	Creative Transform

Creative sting and width processor with intensity, venom saturation, convergence focus, and output control.

Recommended use: width/creative secondary

Customer formats: AU, VST3

Exposed parameter surface

Parameter ID	Display name	Type
STING	Width Reach	Float
VENOM	Movement Trace	Float
FOCUS	Prism Focus	Float
OUTPUT	Output Master	Float
gainmatch	Gain Match	Bool
channelmode	Channel Mode	Choice
dualmonolink	Dual Mono Link	Choice

Factory starting points

SERQET CANON WIDTH [Stereo] • SERQET VEIL MOTION [Stereo] • SERQET PRISM LENS [Stereo] • SERQET WIDE FIELD [Stereo] • SERQET BUS VEIL [Stereo] • SERQET CANON WIDTH [Mono] • SERQET VEIL MOTION [Mono] • SERQET PRISM LENS [Mono] • SERQET WIDE FIELD [Mono] • SERQET BUS VEIL [Mono] • SERQET CANON WIDTH [Dual Mono] • SERQET VEIL MOTION [Dual Mono] • SERQET PRISM LENS [Dual Mono] • SERQET WIDE FIELD [Dual Mono] • SERQET BUS VEIL [Dual Mono]

Meters and visualizers

RMS WIDTH: Input RMS feeding the width field. Shows source energy available for widening.

PRISM WIDTH: Measured side-field width. Higher values indicate a broader stereo prism.

OUTPUT FIELD: Post-process RMS energy. Use with RMS WIDTH for level context.

Prism visualizer: Width, motion, focus, and output state. The polygon is a spatial-state map, not a loudness target.