

DIHWorld Audio

Master Field Manual

Current product versions, controls, presets, meters, and placement

DIHWorld Audio builds connected production systems around the Imhotep 369 Engine—a Triadic Harmonic Lattice—and Ma'at 357 / MomentumBend. Phi-derived control and the canonical Phi/2 ceiling preserve movement, balance, and musical intent without brickwall limiting.

This edition documents 1 current products. Release numbers are taken from the installed DIHWorld Audio Audio Units verified on 2026-09-05; they are product versions, not a shared catalog version.

Canon reference: normalized $\text{Phi}/2 = 0.809016994$. MomentumBend shapes motion and containment; the ceiling is a canonical boundary, not permission for hard limiting.

Operating law: begin from reset or a purpose-matched preset, compare at equal loudness, change one system at a time, and judge the result in the full arrangement.

IMHOTEP

RELEASE	FAMILY	PLACEMENT
v1.0.1	Master Field	Master Field

Macro master-field builder for foundation, architecture, dimension, finish, tonal axis, I/O trim, and Flower of Life dispersal.

Recommended use: macro master-field structure and finish

Customer formats: AU, VST3, Standalone

Primary controls

Flower of Life Dispersal • Gain Match • Channel Mode • Foundation • Architecture • Dimension • Finish • Tonal Axis • Input Trim • Output Trim

Factory starting points

MASTER BUILDER CANON • CLEAN PRINT FRAME • FOUNDATION MONUMENT • VOCAL MASTER ORDER • DENSE MIX REBUILD • OPEN PYRAMID FIELD • TRANSIENT STONework • GREAT PYRAMID

Meters and visualizers

INPUT PEAK: Peak entering the master builder. Confirms headroom before macro shaping.

FIELD ACTIVITY: Combined foundation, architecture, dimension, and finish activity. Shows how strongly the macro field is engaged.

OUTPUT / PHI CEILING: Output level relative to containment. Persistent maximum readings mean less available headroom.