



GND1GND1	GND1	GND4	GND4
GND2 3V3 3.3V RST RST DI00 DI00 DI01	GND1 GND2 3.3V RST DI00 DI01 DI02 DI03	NSS MOSI MISO SCK	NSS SS MOSI MOSI MISO MISO SCK SCK DI05 DI04 GND3
DI02 DI03		DI05 DI04 GND3	