Manualslib.com - Easy to Read Manuals



Bosch Professional GSB 10 / 10 RE / 13 / 13 RE / 16 / 16 RE - Hammer Drill Manual

Contents

1. Safety instructions
    1.1. General Power Tool Safety Warnings
    1.2. Safety Warnings for Drills
2. Product Description and Specifications
    2.1. Intended Use
    2.2. Product Features
    2.3. Technical Data
3. Assembly
    3.1. Auxiliary Handle
    3.2. Changing the Tool
    3.3. Changing the Drill Chuck
    3.4. Dust/Chip Extraction
4. Operation
    4.1. Starting Operation
    4.2. Practical Advice
    4.3. GSB 16 RE
5. Maintenance and Servicing
    5.1. Maintenance and Cleaning
    5.2. After-sales Service and Advice on Using Products
6. Documents / Resources
    6.1. References
    6.2. In Other Languages
    6.3. Other ManualsLib Projects



Safety instructions

General Power Tool Safety Warnings

WARNING

Read all safety warnings, instructions, illustrations and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire and/ or serious injury.

Save all warnings and instructions for future reference.

The term "power tool" in the warnings refers to your mains operated (corded) power tool or battery-operated (cordless) power tool.

Work area safety

- **Keep work area clean and well lit.** Cluttered or dark areas invite accidents.
- **Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** Power tools create sparks which may ignite the dust or fumes.
- **Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.

Electrical safety

- **Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.** Unmodified plugs and matching outlets will reduce risk of electric shock.
- **Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electric shock if your body is earthed or grounded.
- **Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.
- **Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts.** Damaged or entangled cords increase the risk of electric shock.
- **When operating a power tool outdoors, use an extension cord suitable for outdoor use.** Use of a cord suitable for outdoor use reduces the risk of electric shock.
- **If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply.** Use of an RCD reduces the risk of electric shock.

Personal safety

- **Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** A moment of inattention while operating power tools may result in serious personal injury.
- **Use personal protective equipment. Always wear eye protection.** Protective equipment such as a dust mask, non-skid safety shoes, hard hat or hearing protection used for appropriate conditions will reduce personal injuries.
- **Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.**

Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.

- **Remove any adjusting key or wrench before turning the power tool on.** A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- **Do not overreach. Keep proper footing and balance at all times.** This enables better control of the power tool in unexpected situations.
- **Dress properly. Do not wear loose clothing or jewellery. Keep your hair and clothing away from moving parts.** Loose clothes, jewellery or long hair can be caught in moving parts.
- **If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.** Use of dust collection can reduce dust-related hazards.
- **Do not let familiarity gained from frequent use of tools allow you to become complacent and ignore tool safety principles.** A careless action can cause severe injury within a fraction of a second.

Power tool use and care

- **Do not force the power tool. Use the correct power tool for your application.** The correct power tool will do the job better and safer at the rate for which it was designed.
- **Do not use the power tool if the switch does not turn it on and off.** Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- **Disconnect the plug from the power source and/or remove the battery pack, if detachable, from the power tool before making any adjustments, changing accessories, or storing power tools.** Such preventive safety measures reduce the risk of starting the power tool accidentally.
- **Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.** Power tools are dangerous in the hands of untrained users.
- **Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use.** Many accidents are caused by poorly maintained power tools.
- **Keep cutting tools sharp and clean.** Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- **Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed.** Use of the power tool for operations different from those intended could

result in a hazardous situation.

- **Keep handles and grasping surfaces dry, clean and free from oil and grease.** Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.

Service

- **Have your power tool serviced by a qualified repair person using only identical replacement parts.** This will ensure that the safety of the power tool is maintained.

Safety Warnings for Drills

Safety instructions for all operations

- **Wear ear protectors when impact drilling.** Exposure to noise can cause hearing loss.
- **Use auxiliary handle(s), if supplied with the tool.** Loss of control can cause personal injury.
- **Hold the power tool by insulated gripping surfaces, when performing an operation where the cutting accessory or fasteners may contact hidden wiring or its own cord.** Cutting accessory contacting a "live" wire may make exposed metal parts of the power tool "live" and could give the operator an electric shock.

Safety instructions when using long drill bits

- **Never operate at higher speed than the maximum speed rating of the drill bit.** At higher speeds, the bit is likely to bend if allowed to rotate freely without contacting the workpiece, resulting in personal injury.
- **Always start drilling at low speed and with the bit tip in contact with the workpiece.** At higher speeds, the bit is likely to bend if allowed to rotate freely without contacting the workpiece, resulting in personal injury.
- **Apply pressure only in direct line with the bit and do not apply excessive pressure.** Bits can bend causing breakage or loss of control, resulting in personal injury.

Additional safety warnings

- **Switch the power tool off immediately if the application tool becomes blocked. Be prepared for high torque reactions which cause kickback.** The application tool becomes blocked when it becomes jammed in the workpiece or when the power tool becomes overloaded.

- **Hold the power tool securely.** When tightening and loosening screws be prepared for temporarily high torque reactions.
- **Secure the workpiece.** A workpiece clamped with clamping devices or in a vice is held more secure than by hand.
- **Use suitable detectors to determine if utility lines are hidden in the work area or call the local utility company for assistance.** Contact with electric lines can lead to fire and electric shock. Damaging a gas line can lead to explosion. Penetrating a water line causes property damage or may cause an electric shock.
- **Always wait until the power tool has come to a complete stop before placing it down.** The application tool can jam and cause you to lose control of the power tool.

Products sold in GB only:
Your product is fitted with an BS 1363/A approved electric plug with internal fuse (ASTA approved to BS 1362).
If the plug is not suitable for your socket outlets, it should be cut off and an appropriate plug fitted in its place by an authorised customer service agent. The replacement plug should have the same fuse rating as the original plug.
The severed plug must be disposed of to avoid a possible shock hazard and should never be inserted into a mains socket elsewhere.


Product Description and Specifications


Read all the safety and general instructions. Failure to observe the safety and general instructions may result in electric shock, fire and/or serious injury.
Please observe the illustrations at the beginning of this operating manual.


Intended Use

The power tool is intended for impact drilling in brick, concrete and stone, as well as for drilling in wood, metal, ceramic and plastic. Tools with electronic control and right/left rotation are also suitable for screwdriving and thread cutting.

Product Features







1. Keyless chuck[A)]
2. Front sleeve
3. Rear sleeve

4. "Drilling/impact drilling" selector switch
5. Lock-on button for on/off switch
6. On/off switch
7. Speed preselection thumbwheel (GSB 16 RE)
8. Rotational direction switch (GSB 10 RE/GSB 13 RE/ GSB 16 RE)
9. Button for depth stop adjustment[A)]
10. Wing bolt for attaching the auxiliary handle[A)]
11. Auxiliary handle (insulated gripping surface)[A)]
12. Depth stop[A)]
13. Handle (insulated gripping surface)
14. Chuck key[A)]
15. Keyed chuck[A)]
16. Universal bit holder[A)]
17. Screwdriver bit[A)B)]
18. Hex key[A)B)]
19. Open-ended spanner[A)B)]

A. **Accessories shown or described are not included with the product as standard. You can find the complete selection of accessories in our accessories range.**

B. **Commercially available (not included in the scope of delivery)**

Technical Data

Impact drill	**GSB...**	**10**	**10 RE**	**13**	**13 RE**	**16**	**16 RE**
Article number		**3 601...**	**B16 0..**	**B16 1..**	**B17 0..**	**B17 1.. B17 6..**	**B18 0..**	**B18 1.. B18 6..**
Rated power input	W	500	500	600	600	701	701
Power output	W	250	250	301	301	351	351
No-load speed		2600	0–	2800	0–	3000	0–

	min^{-1}		2600		2800		3000
Max. speed under load	min^{-1}	1610	1610	1570	1570	1640	1640
Impact rate	min^{-1}	25700	25700	25070	25070	26720	26720
Rated torque	Nm	1.5	1.5	1.8	1.8	2.0	2.0
Speed preselection		–	–	–	–	–	●
Right/left rotation		–	●	–	●	–	●
Spindle collar diameter	mm	43	43	43	43	43	43
Max. drilling diameter							
• Concrete	mm	10	10	13	13	16	16
• Steel	mm	8	8	10	10	12	12
• Wood	mm	20	20	25	25	30	30
Chucking capacity	mm	1.5–10	1.5–10	1.5–13	1.5–13	1.5–13	1.5–13
Weight according to EPTA-Procedure 01:2014	kg	1.5	1.5	1.8	1.8	1.9	1.9
Protection class		⧈/II	⧈/II	⧈/II	⧈/II	⧈/II	⧈/II

The specifications apply to a rated voltage [U] of 230 V. These specifications may vary at different voltages and in country-specific models.

Assembly

- **Pull the plug out of the socket before carrying out any work on the power tool.**

Auxiliary Handle

(see figure A) (GSB 13/ GSB 13 RE/GSB 16/GSB 16 RE)

- **Do not operate your power tool without the auxiliary handle (11)**.
- **Before any work, make sure that the wing bolt is tightened**. Loss of control can cause personal injury.


You can swivel the auxiliary handle **(11)** to any angle for a safe work posture that minimises fatigue.
Turn the wing bolt for adjusting the auxiliary handle anticlockwise and swivel the auxiliary handle **(11)** into the required position. Then retighten the wing bolt by turning it clockwise.

Setting the Drilling Depth (see figure A)
You can use the depth stop **(12)** to set the required drilling depth **X**.
Press the button for depth stop adjustment **(9)** and insert the depth stop into the auxiliary handle.
Pull the depth stop far enough out that the distance between the drill bit tip and the edge of the depth stop corresponds to the required drilling depth **X**.

Changing the Tool

Keyless Chuck (see figure B)
Hold the rear sleeve **(3)** of the keyless chuck **(1)** firmly and turn the front sleeve **(2)** in the rotational direction ❶ until the tool can be inserted. Insert the tool.
Hold the rear sleeve **(3)** of the keyless chuck **(1)** and firmly tighten the front sleeve **(2)** by hand in the rotational direction ❷ until it stops clicking. This will automatically lock the drill chuck.
The lock will disengage again if you turn the front sleeve **(2)** in the opposite direction to remove the tool.


Keyed Chuck



- **Wear protective gloves when changing tools.** The drill chuck may heat up significantly when it is used for long periods.

Open the keyed chuck **(15)** by turning it until the tool can be inserted. Insert the tool.
Insert the drill chuck key **(14)** into the corresponding holes of the keyed chuck **(15)** and clamp the tool evenly.

Screwdriving Tools




You should always use a universal bit holder **(16)** when using screwdriver bits **(17)**. Only use screwdriver bits that fit the screw head.
For screwdriving, make sure the "drilling/impact drilling" selector switch **(4)** is always set to the "drilling" symbol.

Changing the Drill Chuck

- **Pull the plug out of the socket before carrying out any work on the power tool.**


Removing the Drill Chuck



To remove the keyless chuck **(1)**, clamp a hex key **(18)** in the keyless chuck **(1)** and position an open-ended spanner **(19)** (width across flats: 12) against the spanner flat of the drive spindle.
Place the power tool on a firm surface, e.g. a work bench. Hold the open-ended spanner **(19)** in place and loosen the keyless chuck **(1)** by turning the hex key **(18)** in the rotational direction ❶. A tightly seated keyless chuck can be loosened with a light blow on the long shaft of the hex key **(18)**.
Remove the hex key from the keyless chuck and completely unscrew the keyless chuck

from the power tool.
The keyed chuck **(15)** can be removed in the same way as described for the keyless chuck.

Fitting the Drill Chuck



The keyless chuck/keyless chuck with securing ring/keyed chuck is mounted in reverse order.

⚠ **The drill chuck must be tightened using a tightening torque of approx. 30–35 Nm.**

Dust/Chip Extraction

Dust from materials such as lead-containing coatings, some wood types, minerals and metal can be harmful to one's health. Touching or breathing-in the dust can cause allergic reactions and/or lead to respiratory infections of the user or bystanders. Certain dust, such as oak or beech dust, is considered carcinogenic, especially in connection with wood-treatment additives (chromate, wood preservative). Materials containing asbestos may only be worked by specialists.

- Provide for good ventilation of the working place.
- It is recommended to wear a P2 filter-class respirator.

Observe the relevant regulations in your country for the materials to be worked.


- **Avoid dust accumulation at the workplace.** Dust can easily ignite.


Operation

Starting Operation

- **Pay attention to the mains voltage. The voltage of the power source must match the voltage specified on the rating plate of the power tool. Power tools marked with 230 V can also be operated with 220 V.**
- **Products that are only sold in AUS and NZ:** Use a residual current device (RCD) with a nominal residual current of 30 mA or less.

Setting the Rotational Direction
(GSB 10 RE/GSB 13 RE/GSB 16 RE)





The rotational direction switch **(8)** is used to change the rotational direction of the power tool. However, this is not possible while the on/off switch **(6)** is being pressed.
Right rotation: To drill and to drive in screws, press the rotational direction switch **(8)** through to the left stop.
Left Rotation: To loosen and unscrew screws and nuts, press the rotational direction switch **(8)** through to the right stop.

Setting the Operating Mode
Drilling and screwdriving



Set the selector switch **(4)** to the "drilling" symbol.

Impact drilling



Set the selector switch **(4)** to the "impact drilling" symbol.
The selector switch **(4)** clicks into place and can also be actuated when the motor is running.

Switching on/off
To **start** the power tool, press and hold the on/off switch **(6)**.
Press the lock-on button **(5)** to **lock** the on/off switch **(6)** in this position.
To **switch off** the power tool, release the on/off switch **(6)**; or, if the switch is locked with

the lock-on button **(5)**, briefly press the on/off switch **(6)** and then release it.

Setting the Speed/Impact Rate (GSB 10 RE/GSB 13 RE/GSB 16 RE)
You can adjust the speed of the power tool when it is on by pressing in the on/off switch **(6)** to varying extents.
A light pressure on the on/off switch **(6)** results in a low rotational speed. Increased pressure on the switch causes an increase in speed.

Preselecting the Speed/Impact Rate (GSB 16 RE)
You can preselect the required speed/impact rate using the speed preselection thumbwheel **(7)**, even during operation. The required speed/impact rate is dependent on the material and the work conditions and can be determined by practical trials.

Practical Advice

- **Pull the plug out of the socket before carrying out any work on the power tool.**
- **Only apply the power tool to the screw/nut when the tool is switched off.** Rotating tool inserts can slip off.

After working at a low speed for an extended period, you should operate the power tool at the maximum speed for approximately three minutes without load to cool it down.
To drill into tiles, set the selector switch (4) to the "drilling" symbol. After drilling through the tile, set the selector switch to the "impact drilling" symbol and drill with impact.
Use carbide drill bits when working with concrete, stone and masonry.
When drilling into metal, only use sharpened HSS drills (HSS = high-speed steel) which are in perfect condition. The Bosch accessory range guarantees appropriate quality.
Using the drill bit sharpener (accessory), you can effortlessly sharpen twist drill bits with a diameter of 2.5–10 mm.

GSB 16 RE

Use a drill stand (accessory) for jobs that require particular precision.
The power tool vice, which is available as an accessory, enables the workpiece to be securely clamped. This prevents the workpiece from turning and any accidents this could cause.

Maintenance and Servicing

Maintenance and Cleaning

- **Pull the plug out of the socket before carrying out any work on the power tool.**
- **To ensure safe and efficient operation, always keep the power tool and the**

ventilation slots clean.

In order to avoid safety hazards, if the power supply cord needs to be replaced, this must be done by Bosch or by a customer service centre that is authorised to repair Bosch power tools.

After-sales Service and Advice on Using Products

Our after-sales service can answer questions concerning product maintenance and repair, as well as spare parts. You can find exploded drawings and information on spare parts at: **www.bosch-pt.com**
The Bosch product use advice team will be happy to help you with any questions about our products and their accessories.
www.powertool-portal.de, the internet portal for tradespeople and DIY enthusiasts.
In all correspondence and spare parts orders, please always include the 10-digit article number given on the type plate of the product.

Cambodia
Robert Bosch (Cambodia) Co., Ltd
Unit 8BC, GT Tower, 08th Floor, Street 169,
Czechoslovakia Blvd, Sangkat Veal Vong
Khan 7 Makara, Phnom Penh
VAT TIN: 100 169 511
Tel.: +855 23 900 685
Tel.: +855 23 900 660
www.bosch.com.kh

People's Republic of China
China Mainland
Bosch Power Tool (China) Co. Ltd.
Bosch Service Center
567, Bin Kang Road
Bin Kang District
Hangzhou, Zhejiang Province
China 310052
Tel.: (0571) 8887 5566 / 5588
Fax: (0571) 8887 6688 x 5566# / 5588#
E-mail: bsc.hz@cn.bosch.com
www.bosch-pt.com.cn

HK and Macau Special Administrative Regions
Robert Bosch Co. Ltd.
21st Floor, 625 King's Road
North Point, Hong Kong
Customer Service Hotline: +852 2101 0235

Fax: +852 2590 9762
E-mail: info@hk.bosch.com
www.bosch-pt.com.hk

India
Bosch Service Center
69, Habibullah Road, (next to PSBB School), T. Nagar
Chennai–600077
Phone: (044) 64561816
Bosch Service Center Rishyamook
85A, Panchkuin Road
New Delhi–110001
Phone: (011) 43166190
Bosch Service Center 79,
Crystal Bldg., Dr. Annie Besant Road, Worli
Mumbai–400018
Phone: (022) 39569936 / (022)39569959 / (022) 39569967 / (022) 24952071

Indonesia
PT Robert Bosch
Palma Tower 10th Floor
Jalan RA Kartini II-S Kaveling 6
Pondok Pinang, Kebayoran Lama
Jakarta Selatan 12310
Tel.: (21) 3005-5800
www.bosch-pt.co.id

Malaysia
Robert Bosch Sdn. Bhd.(220975-V) PT/SMY
No. 8A, Jalan 13/6
46200 Petaling Jaya
Selangor
Tel.: (03) 79663194
Toll-Free: 1800 880188
Fax: (03) 79583838
E-mail: kiathoe.chong@my.bosch.com
www.bosch-pt.com.my

Pakistan
Robert Bosch Middle East FZE – Pakistan Liaison Office
2nd Floor Plaza # 10, CCA Block, DHA Phase 5
Lahore, 54810
Phone: +92(303)4444311
E-mail: Faisal. Khan@bosch.com

Philippines

Robert Bosch, Inc.
28th Floor Fort Legend Towers,
3rd Avenue corner 31st Street,
Fort Bonifacio, Global City,
1634 Taguig City
Tel.: (632) 8703871
Fax: (632) 8703870
www.bosch-pt.com.ph

Singapore
Powerwell Service Centre Ptd Ltd
Bosch Authorised Service Centre (Power Tools)
4012 Ang Mo Kio Ave 10, #01-02 TECHplace
Singapore 569628
Tel.: 6452 1770
Fax: 6452 1760
E-mail: ask@powerwellsc.com
www.powerwellsc.com
www.bosch-pt.com.sg

Thailand
Robert Bosch Ltd.
Liberty Square Building
No. 287, 11 Floor
Silom Road, Bangrak
Bangkok 10500
Tel.: 02 6393111
Fax: 02 2384783
Robert Bosch Ltd., P. O. Box 2054
Bangkok 10501
www.bosch.co.th
Bosch Service – Training Centre
La Salle Tower Ground Floor Unit No.2
10/11 La Salle Moo 16
Srinakharin Road
Bangkaew, Bang Plee
Samutprakarn 10540
Tel.: 02 7587555
Fax: 02 7587525

Vietnam
Branch of Bosch Vietnam Co., Ltd in HCMC
14th floor, Deutsches Haus, 33 Le Duan
Ben Nghe Ward, District 1, Ho Chi Minh City
Tel.: (028) 6258 3690
Fax: (028) 6258 3692 - 6258 3694

Hotline: (028) 6250 8555
E-mail: tuvankhachhang-pt@vn.bosch.com
www.bosch-pt.com.vn

Armenia, Azerbaijan, Georgia, Kyrgyzstan, Mongolia, Tajikistan, Turkmenistan, Uzbekistan
TOO "Robert Bosch" Power Tools, After Sales Service
Rayimbek Ave., 169/1
050050, Almaty, Kazakhstan
Service e-mail: service.pt.ka@bosch.com
Official website: www.bosch.com, www.bosch-pt.com

Bahrain
Hatem Al Juffali Technical Equipment Establishment.
Kingdom of Bahrain, Setra Highway, Al Aker Area
Phone: +966126971777-311
Fax: +97317704257
E-mail: h.berjas@eajb.com.sa
Egypt
Unimar
20 Markaz kadmat
El tagmoa EL Aoul – New Cairo
Phone: +20 2224 76091-95
Phone: +20 2224 78072-73
Fax: +20222478075
E-mail: adelzaki@unimaregypt.com

Iran
Robert Bosch Iran
3rd Floor, No 3, Maadiran Building
Aftab St., Khodami St., Vanak Sq.
Tehran 1994834571
Phone: +9821 86092057

Iraq
Sahba Technology Group
Al Muthana airport road
Baghdad
Phone: +9647901906953
Phone Dubai: +97143973851
E-mail: bosch@sahbatechnology.com

Jordan
Roots Arabia – Jordan
Nasser Bin Jameel street, Building 37 Al Rabiah
11194 Amman

Phone: +962 6 5545778
E-mail: bosch@rootsjordan.com

Kuwait
Al Qurain Automotive Trading Company
Shuwaikh Industrial Area, Block 1, Plot 16, Street 3rd
P.O. Box 164 – Safat 13002
Phone: 24810844
Fax: 24810879
E-mail: josephkr@aaalmutawa.com
Lebanon
Tehini Hana & Co. S.A.R.L.
P.O. Box 90-449
Jdeideh
Dora-Beirut
Phone: +9611255211
E-mail: service-pt@tehini-hana.com
Libya
El Naser for Workshop Tools
Swanee Road, Alfalah Area
Tripoli
Phone: +218 21 4811184
Oman
Malatan Trading & Contracting LLC
P.O. Box 131
Ruwi, 112 Sultanate of Oman
Phone: +968 99886794
E-mail: malatanpowertools@malatan.net

Qatar
International Construction Solutions W L L
P.O. Box 51,
Doha Phone: +974 40065458
Fax: +974 4453 8585
E-mail: csd@icsdoha.com

Saudi Arabia
Juffali Technical Equipment Co. (JTECO)
Kilo 14, Madinah Road, Al Bawadi District
Jeddah 21431
Phone: +966 2 6672222 Ext. 1528
Fax: +966 2 6676308
E-mail: roland@eajb.com.sa

Syria
Dallal Establishment for Power Tools

P.O. Box 1030
Aleppo
Phone: +963212116083
E-mail: rita.dallal@hotmail.com

United Arab Emirates
Central Motors & Equipment LLC, P.O. Box 1984
Al-Wahda Street – Old Sana Building
Sharjah
Phone: +971 6 593 2777
Fax: +971 6 533 2269
E-mail: powertools@centralmotors.ae

Yemen
Abualrejal Trading Corporation
Sana'a Zubiery St. Front to new Parliament Building
Phone: +967-1-202010
Fax: +967-1-279029
E-mail: tech-tools@abualrejal.com

Ethiopia
Forever plc
Kebele 2,754, BP 4806,
Addis Ababa
Phone: +251 111 560 600
E-mail: foreverplc@ethionet.et

Ghana
C.WOERMANN LTD.
Nsawam Road/Avenor Junction, P.O. Box 1779
Accra Phone: +233 302 225 141

Kenya
Robert Bosch East Africa Ltd
Mpaka Road P.O. Box 856
00606 Nairobi

Nigeria
Robert Bosch Nigeria Ltd.
52–54 Isaac John Street P.O. Box
GRA Ikeja – Lagos

Republic of South Africa
Customer service
Hotline: (011) 6519600
Gauteng – BSC Service Centre

35 Roper Street, New Centre
Johannesburg
Tel.: (011) 4939375
Fax: (011) 4930126
E-mail: bsctools@icon.co.za

KZN – BSC Service Centre
Unit E, Almar Centre
143 Crompton Street
Pinetown
Tel.: (031) 7012120
Fax: (031) 7012446
E-mail: bsc.dur@za.bosch.com

Western Cape – BSC Service Centre
Democracy Way, Prosperity Park
Milnerton
Tel.: (021) 5512577
Fax: (021) 5513223
E-mail: bsc@zsd.co.za

Bosch Headquarters
Midrand, Gauteng
Tel.: (011) 6519600
Fax: (011) 6519880
E-mail: rbsa-hq.pts@za.bosch.com

Tanzania
Diesel & Autoelectric Service Ltd.
117 Nyerere Rd., P.O. Box 70839
Vingunguti 12109, Dar Es Salaam
Phone: +255 222 861 793/794

Australia, New Zealand and Pacific Islands
Robert Bosch Australia Pty. Ltd.
Power Tools
Locked Bag 66
Clayton South VIC 3169
Customer Contact Center
Inside Australia:
Phone: (01300) 307044
Fax: (01300) 307045
Inside New Zealand:
Phone: (0800) 543353
Fax: (0800) 428570
Outside AU and NZ:
Phone: +61 3 95415555
www.bosch-pt.com.au
www.bosch-pt.co.nz

Documents / Resources

References

- Home | Bosch Power Tools
- [redacted] Bosch [redacted] | [redacted] Bosch [redacted]
- 博世电动工具 | 博世专业
- 博世電動工具 | 博世專業
- Bosch Power Tools | Bosch Professional
- Bosch Power Tools | Bosch Professional
- Bosch Power Tools | Bosch Professional
- Home | Bosch Authorised Service Centre | Powerwell Service Centre
- Bosch Power Tools | Bosch Professional
- บ๊อช ประเทศไทย | บ๊อช ประเทศไทย
- Home | Bosch Power Tools
- Invented for life | Bosch Global
- Bosch power tools for trade and industry | Bosch Professional
- Bosch power tools for trade and industry | Bosch Professional

Available languages

Deutsch Français Español Mexicano Dutch Italiano Dansk Norsk Polski Suomi Português Español (Latinoamérica) Русский Български Čeština ε λ λ η ν ι κ ά English (UK) Eesti Hrvatski Magyar Bahasa indonesia Қазақша Lietuvių Português (Brasil) Română Română (Moldova) Slovenčina Slovenščina Shqip Kiswahili Türkçe O‘zbekcha

Other ManualsLib Projects

- www.manualslib.com

www.manualslib.de
www.manualslib.es
www.manualslib.fr
www.manualslib.nl
www.manualslib.mx
www.manualslib.tech 30+ languages