Embedded Systems with ARM Cortex-M3 Microcontrollers in Assembly Language and C

Structured Programming

Dr. Yifeng Zhu Electrical and Computer Engineering University of Maine


Spring 2015

Divide and Conquer

"Nothing is particularly hard if you divide it into small jobs."


Henry Ford, Founder of Ford Motor

Three basic control structures





Top-Down Design


Top-Down Design




- Find all Armstrong numbers less than 10,000
- Given a positive integer that has n digits, it is an Armstrong number if the sum of the nth powers of its digits equals the number itself.
- For example, 371 is an Armstrong number since we have $371 = 3^3 + 7^3 + 1^3$.









Top-Down Design Example: Counting digits

