Computer Labs: I/O and Interrupts 2° MIEIC

Pedro F. Souto (pfs@fe.up.pt)

October 7, 2019

I/O Operation

- ► I/O devices are the interface between the computer and its environment
- Most of the time, the processor is not synchronized with its environment
 - I/O operations are asynchronous wrt the processor operation
- Usually, I/O devices are much slower than the processor
 - The processor must wait for an I/O device to complete its current operation before it requests the I/O device a new one

How Does the Processor Know that an I/O op is done?

Polling The processor polls the I/O device, i.e. reads a status register, to find out

Response time Highly variable – depends on what the processor has to do between consecutive polls.

Bandwidth May be high, if:

- the interface bus is fast
- the I/O device has a high-bandwidth or a large buffer, e.g. a disk
- and the processor polls the I/O device frequently

How Does the Processor Know that an I/O op is done?

Polling The processor polls the I/O device, i.e. reads a status register, to find out

Response time Highly variable – depends on what the processor has to do between consecutive polls.

Bandwidth May be high, if:

- the interface bus is fast
- the I/O device has a high-bandwidth or a large buffer, e.g. a disk
- and the processor polls the I/O device frequently

Interrupts The I/O device notifies the processor, via the interrupt mechanism

Response time Usually responsive – depends on the time:

- ► interrupts are disabled or
- higher priority interrupts take to be served

Bandwidth Medium to low. It depends on the amount of data ready to transfer on each interrupt




Lab 2: timer_test_int()

What to do? Print one message per second, for a time interval whose duration is specified in its argument, by using:

- ► Timer 0 interrupts
- ► LCF function:

```
void timer_print_elapsed_time()
```

PC Interrupt HW: Priority Interrupt Controller (PIC)



PC Interrupts: IRQ Lines and Vectors

PIC 1	PIC 2	Device	Vector
IRQ0		Timer	0x08
IRQ1		Keyboard	0x09
IRQ2		PIC2	0x0A
	IRQ0	Real Time Clock	0x70
	IRQ1	Replace IRQ2	0x71
	IRQ2- IRQ7	Reserved	0x72-0x77
IRQ3		Serial port COM2	0x0B
IRQ4		Serial port COM1	0x0C
IRQ5		Reserved/Sound card	0x0D
IRQ6		Floppy disk	0x0E
IRQ7		Parallel port	0x0F

IRQ line Determined by the HW designer (IBM)

Vector Specified also by IBM, but can be configured at boot time. All that is needed is:

- 1. Configure the PIC
- 2. Configure the IDT (Interrupt Descriptor Table)



Interrupt Handlers (IH)

- IHs are executed by the HW upon an interrupt
 - ► They run asynchronously wrt other code
 - They take no arguments
 - They return no values
- IHs used to be written in assembly
 - Need to perform I/O operations

 But nowadays, they are usually written in C (for reasons of portability)

Terminology Interrupt handlers are also called interrupt service routines (ISR) and are part of the respective **device driver**

Interrupt Handling in Minix 3

- ► In Minix, device drivers are implemented as user-level processes, rather than at the kernel-level
 - This was an important design decision in Minix 3

Interrupt Handling in Minix 3

- ▶ In Minix, device drivers are implemented as user-level processes, rather than at the kernel-level
 - This was an important design decision in Minix 3

Issue How do you do interrupt handling?

 Interrupt handling requires performing operations that usually require special privileges

Interrupt Handling in Minix 3

- ▶ In Minix, device drivers are implemented as user-level processes, rather than at the kernel-level
 - This was an important design decision in Minix 3

Issue How do you do interrupt handling?

 Interrupt handling requires performing operations that usually require special privileges

Solution

- Perform only the bare minimum in the kernel: this is done by the generic interrupt handler
- Device specific operations are performed by the device drivers themselves at user level
 - Using kernel calls to perform privileged operations

Minix 3: The Generic Interrupt Handler (GIH)

- 1. Notifies all the device drivers (DD) **interested** in an interrupt, when that interrupt occurs
- 2. If possible, acknowledges the interrupt by issuing the EOI command to the PIC.
- 3. Issues the IRETD instruction
- Issue 1 How does the GIH know that a DD is interested in an interrupt?
- Issue 2 How does the GIH notify a DD?
- Issue 3 How does a DD receive the notification of the GIH?
- Issue 4 How does the GIH know if it can send the ${\tt EOI}$ to the PIC?
- Issue 5 If the GIH does not send the EOI, when and how is the EOI sent to the PIC and by whom?

How does the GIH know that a DD is interested in an interrupt?

How does the GIH know that a DD is interested in an interrupt?

Answer The DD tells it, using kernel call:

```
int sys_irqsetpolicy(int irq_line, int policy, int *hook_id)
where
```

irq_line is the IRQ line of the device
policy use IRQ_REENABLE to inform the GIH that it can
give the EOI command

► This answers Issue 4: How does the GIH know if it can send the EOI to the PIC?

hook_id is both:

input an id to be used by the kernel on interrupt notification output an id to be used by the DD in other kernel calls on this interrupt

sys_irqsetpolicy() can be viewed as an interrupt notification subscription



How does the GIH notify the DD of the occurrence of an interrupt?

How does the GIH notify the DD of the occurrence of an interrupt?

Answer It uses the standard interprocess communication (IPC) mechanism used to communicate:

- between processes;
- between the (micro) kernel and a process

More specifically, it uses notifications

Minix 3 IPC This is essentially a message based mechanism

- Processes send and receive messages to communicate with one another
- ▶ A notification is a special kind of message, used to communicate from the kernel to a user process.

Issue 3 (1/2)

How does the DD receive the notification of the GIH?

Issue 3 (1/2)

How does the DD receive the notification of the GIH?
Short Answer Just use the IPC mechanism.
Useful Answer Use some library calls provided by the libdrivers library

```
1: #include <lcom/lcf.h>
 2: int ipc status;
 3: message msg;
 4: while(1) { /* You may want to use a different condition */
 5:
        /* Get a request message. */
 6:
        if( (r = driver_receive(ANY, &msq, &ipc_status)) != 0 ) {
 7:
            printf("driver_receive failed with: %d", r);
 8:
            continue;
 9:
10:
        if (is_ipc_notify(ipc_status)) { /* received notification :
11:
            switch (_ENDPOINT_P(msq.m_source)) {
12:
            case HARDWARE: /* hardware interrupt notification */
13:
                if (msg.m_notify.interrupts & irq_set) { /* subscri
14:
                     ... /* process it */
15:
16:
                break:
17:
            default:
18:
                break; /* no other notifications expected: do noth
19:
20:
        } else { /* received a standard message, not a notification
21:
            /* no standard messages expected: do nothing */
2.2:
23: }
                                            4 D > 4 B > 4 E > 4 E > 9 Q P
```

Why: msg.m_notify.interrupts?

Interrupt handlers take no arguments (and return no values)

Answer True, but usually an IH knows which interrupt request it is handling

 Minix 3 allows a DD to subscribe notifications on several interrupt lines

What is its value?

Answer It is based on the input value of hook_id passed by the DD in the corresponding sys_irqsetpolicy().

- ► If a given interrupt is pending then the corresponding hook_id bit of msg.m_notify.interrupts is set.
- ▶ Why not just the hook_id?

What should irq_set value be?

irq_set is used as a mask to test which interrupts are pending

Issue 3 (2/2)

Key Observation In Minix 3, a DD is an event driven service that receives and processes messages

- either interrupt notifications from the kernel (GIH)
- or service requests from other processes

However, the programs in LCOM are not DD: they do not receive requests from other processes

Lab 2: timer_test_int()

What to do? Print one message per second, for a time interval whose duration is specified in its argument.

- 1. Subscribe Timer 0 interrupts
- 2. Print message at 1 second intervals, by calling the LCF function:

```
void timer_print_elapsed_time()
```

3. Unsubscribe Timer 0 at the end

How to design it? It is not easy to come up with an API that can be used in the project

- ► Implement int timer_subscribe_int() to hide from other code i8254 related details, such as the IRQ line used
 - ► It returns, via its argumens, the bit number, that will be set in msg.m_notify.interrupts upon a TIMER 0 interrupt
- Implement the interrupt handler also in timer.c
- ► Implement the "interrupt loop" in timer_test_int()

Issue 5 (and Last)

What if the GIH does not send the EOI?

Issue 5 (and Last)

What if the GIH does not send the EOI?

► I.e., if a DD does not set the IRQ_REENABLE policy in its interrupt subscription request (sys_irqsetpolicy())

Answer The DD will have to do it, as soon as possible

- ► In most cases, you'll want to set the IRQ_REENABLE policy
 - ► In Lab 2, certainly

How can a DD send the EOI to the PIC?

- ▶ By calling sys_irqenable(int *hook_id)
 - Note that here hook_id should point to the value returned by the kernel in sys_irqsetpolicy()

That is, the EOI will be sent by the kernel, upon request of the DD.

Minix 3: Other Interrupt Related Kernel Calls

- sys_irqrmpolicy(int *hook_id) Unsubscribes a
 previous interrupt notification, by specifying a pointer to the
 hook_id returned by the kernel in sys_irqsetpolicy()
- sys_irqdisable(int *hook_id) Masks an interrupt line
 associated with a previously subscribed interrupt notification,
 by specifying a pointer to the hook_id returned by the
 kernel in sys_irqsetpolicy()

Minix 3: Interrupt Sharing

- Minix 3 already includes its own Timer 0 IH
- By subscribing interrupts on IRQ line 0, the IH of your driver will not replace the IH of the kernel
 - Upon an interrupt generated by Timer 0, the kernel:
 - 1. executes its own IH, and
 - notifies your driver
- This behavior stems from the need to share the interrupt lines among devices
 - In systems with the PIC (i8259), there are only 15 interrupt lines available
 - ► And many of them are actually hardwired, e.g. IRQ 0, which means that they cannot be shared among devices

IMP Using two IH for the same device is seldom what you want

But is just what we need for Lab 2.

Further Reading

► Using Interrupts