## Combining Multiple Carts to One Dock

## Step 1:

- 1. Attach second pair of tail cables as shown below
- 2. Route cables into frame of dock
- 3. Ensure Anderson connections are elevated off ground and covered

Tools: 9/16" socket Socket wrench 9/16" wrench



