



Notes: A shorting block must be installed between TDI and TDO on J7 to complete the scan chain when the JTAG signals are being driven from a peripheral board position rather than the JTAG Interface Header

Shorting blocks are installed on pins 2-3 of JP1 and JP2 to bypass the the serial configuration rom (IC9).


Shorting blocks should be installed on MODE0 and MODE1 of J8 to select Slave Serial Mode when configuring from the ROM

Digilent S3 Board		
Copyright 2004, Digilent Inc.	Engineer: CC	
TITLE: S3 Board	Author: GMA	
Document Number: 500-044	Rev: E.3	
Release Date: 12/17/2004	Sheet: 4/8	






Digilent S3 Board	
Copyright 2004, Digilent Inc.	Engineer: CC
TITLE: S3 Board	Author: GMA
Document Number: 500-044	Rev: E.3
Release Date: 12/17/2004	Sheet:6/8



Keyboard PS2 connector



			Ve	A Po	rt
RED	R57 		——[:	<u> </u>	L
GRN	270 R58 			2 3 1 5 6 7 8	
BLUE	R59 	_ ;		5	
	270			B 9 10	
			→:	11	
HS US				13 14	
				เร่	\vdash
GND					-

●FID1	●FID3
●FID2	●FID4

Digilent S3 Board		
Copyright 2004, Digilent Inc.	Engineer: CC	
TITLE: S3 Board	Author: GMA	
Document Number: 500-044	Rev: E.3	
Release Date: 12/17/2004	Sheet:7/8	

