

## NOTES:

[1] COMP AND CESSB, WHEN USED, INCLUDE BANDPASS FILTERING ON THE OUTPUT THAT MATCHES THE MAIN TRANSMIT FILTER.

[2] COMP MUST BE ACTIVATED, EVEN AT 0DB, FOR CESSB TO WORK.

[3] CESSB ONLY WORKS PROPERLY WHEN LINEAR PHASE FILTERS ARE SELECTED.

[4] ALC 0DB LIMIT MAY BE SAFELY EXCEEDED BY SEVERAL DB IF DESIRED; THE RESULTANT SOFT CLIPPING ACTS AS ADDITIONAL COMPRESSION ON THE SIGNAL.

