CONCRETE GARDEN SIGN WITH LEAF IMPRINTS

Step-by-Step DIY Guide

Hand-Script a Heart-Shaped Garden Sign with a Beautiful Leaf Wreath

The finished heart-shaped concrete garden sign — 'grow' in hand-lettered script with a pressed leaf wreath

made-by-hand.com

About This Project

This charming heart-shaped garden sign combines concrete casting with two beautiful decorative techniques: hand-lettered script carved directly into wet concrete, and a wreath of small leaves pressed into the surface to create permanent botanical imprints. The result is a garden decoration that looks like it came from a high-end boutique — but costs almost nothing to make. Perfect as a gift, a garden marker, or a decorative accent nestled among plants. Each one is completely unique.

Difficulty	Easy to Intermediate (lettering takes a little practice)
Active time	20–30 minutes per sign
Curing time	24 hours minimum
Mold shape	Heart-shaped silicone mold (~15 cm wide)
Cost per sign	$2–5 USD (excluding mold)
Best for	Gifts, garden decor, craft markets, plant markers

Materials & Tools

#	Item	Notes
1	Heart-shaped silicone mold	~14–16 cm wide, 3–4 cm deep. Silicone is essential — rigid molds make demolding
2	Craft concrete or fine sand mix	Fine-grain mix for crisp detail. Portland cement + fine sand (2:1) also works beautiful
3	Water	Clean tap water. Mix ratio: 2.5 parts concrete to 1 part water.
4	Small round leaves (fresh)	Maidenhair fern, eucalyptus, baby's breath, or any small-leafed plant. Fresh leaves p
5	Fine paintbrush or pointed stylus	For writing text into the wet concrete. A firm watercolour brush (size 2–4) or a woode
6	Mixing container + stirrer	A small plastic cup and stick is enough for one sign.
7	Nitrile gloves	Protect your hands from alkaline wet concrete.
8	Outdoor spray sealer	A light coat seals the concrete and intensifies the colour. Matte finish looks most natu
9	Acrylic paint (optional)	Green paint brushed into the leaf imprints and wiped off the raised surfaces creates a
10	Fine sandpaper (220 grit)	For smoothing edges after curing. Optional but gives a more polished finish.
11	Cooking spray / petroleum jelly	Light coat inside the mold for easy demolding.

■ ***Leaf tip:*** *Pick your leaves right before you need them — fresh, pliable leaves press much more crisply than wilted ones. Maidenhair fern and small eucalyptus sprigs give the most beautiful, delicate imprints.*

Step-by-Step Instructions

Step 1 — Mix & Fill the Mold

Pressing and smoothing the concrete into the heart-shaped silicone mold with bare hands

Lightly coat the inside of the silicone mold with cooking spray or petroleum jelly. Mix your concrete to a smooth, slightly stiff consistency — thicker than a normal pour, more like modelling clay or stiff brownie batter. This thicker mix holds the pressed leaf and text details much better than a runny mix.

- Mix 2.5 parts concrete to 1 part water — aim for a clay-like consistency, not pourable.
- Press the concrete firmly into the mold by hand, working it into all corners and edges.
- Fill to the top of the mold and press down firmly — no air pockets underneath.
- Smooth the surface with your fingertips, dampened slightly with water.
- Tap the mold gently on the table a few times to settle the concrete and release bubbles.

> ■ ***Tip:*** *A slightly stiffer mix (less water) holds the detail of letter carving and leaf pressing far better than a wet, pourable mix. If the concrete slumps back into carved letters, the mix is too wet.*

Step 2 — Write Your Text with a Brush or Stylus

Writing 'grow' in cursive script into the wet concrete surface using a fine paintbrush

While the concrete is still workable (within the first 15–20 minutes), use a fine paintbrush, pointed stick, or wooden skewer to write your chosen word or message directly into the wet surface. Draw the letters by dragging the tool through the concrete — it carves a groove that captures the script permanently.

- Practice your lettering on paper first — write lightly and confidently in one flowing motion.
- Use the tip of the brush or stylus to draw, not press — you only need 2–3 mm depth.
- Cursive / script lettering looks most natural and organic in concrete.
- If you make a mistake, smooth the surface with a damp fingertip and re-carve — you have time.
- Popular words: grow, bloom, garden, thrive, wild, roots, home — or a plant name.

> ■ ***Tip:*** *Write slightly larger than you think necessary — the letters look smaller once the sign is in the garden. Leave enough room around the text for the leaf wreath border.*

Step 3 — Press the Leaf Wreath

Pressing small eucalyptus / maidenhair leaves around the text to form a wreath border

Now for the most meditative and beautiful part: arrange small leaves in a wreath or border pattern around your text. Press each leaf firmly into the concrete surface so it sits flush — at least half the leaf's thickness should be embedded in the concrete. Work your way around the edge, overlapping leaves slightly for a full, lush look.

- Start at the top of the heart and work clockwise — this keeps the arrangement even.
- Overlap each leaf slightly over the one before it, like fish scales or roof tiles.
- Mix different leaf sizes if available — larger leaves at the base, smaller toward the top.
- Press each leaf with your fingertip firmly and evenly — don't just rest them on the surface.
- Small sprigs with multiple leaves (like maidenhair fern) fill space beautifully with minimal effort.
- Step back occasionally to check the arrangement looks balanced from above.

> ■ ***Design tip:*** *A closed wreath circle around the text looks the most finished and decorative. A half-wreath at the bottom is simpler but equally lovely.*

Step 4 — Cure for 24 Hours

Leave the filled mold completely undisturbed for 24 hours at room temperature. The leaves will remain pressed into the surface while the concrete hardens around them. Cover loosely with a plastic bag or cloth to slow the curing and prevent cracking.

- Keep out of direct sun — shaded outdoors or indoors at room temperature is ideal.

- Do NOT touch or move during curing — even small disturbances shift the leaves and blur the lettering.
- In cold weather (below 12°C), cure indoors for a full 48 hours.
- The concrete will feel solid after 8–10 hours but needs 24h for safe demolding strength.

■ ***Tip:*** *Make several signs at once — the setup and cleanup time is the same whether you make one or five. Try different words, different leaf arrangements, and slight variations in the concrete consistency.*

Step 5 — Demold & Remove Leaves

Peeling the silicone mold away — two heart-shaped signs with leaf and text imprints revealed

After 24 hours, gently flex the silicone mold from all sides to loosen the sign, then peel it back slowly. The concrete sign should come out clean. Now carefully peel the pressed leaves off the concrete surface — their detailed imprints will remain permanently in the concrete.

- Flex and peel the mold slowly — don't rush or pull hard or the edges may chip.
- Peel leaves off gently — start from the stem end and pull toward the tip.
- Any tiny leaf fragments stuck in the concrete can be picked out with a toothpick.
- Rinse the sign under water to clean out leaf debris from the imprints.
- Sand any sharp edges lightly with 220-grit sandpaper while slightly damp.

> ■ ***Tip:*** *The leaf imprints will look stunning at this point — but they get even better after painting and sealing in the next step.*

Step 6 — Paint the Leaf Imprints & Seal

Applying green acrylic paint into the leaf imprints and sealing all four finished signs

To bring the leaf wreath to life, brush green acrylic paint over the entire surface, then immediately wipe off the excess with a damp cloth. The paint settles into the leaf grooves and text, highlighting every detail, while the smooth raised concrete surface wipes clean. Once dry, seal with an outdoor spray sealer.

- Use a mid-tone green — not too bright, not too dark. Sage green or olive works beautifully.
- Brush the paint on generously, then wipe off within 30 seconds while still wet.
- For the text, use a fine brush to paint just the lettering in a contrasting dark colour.
- Let paint dry fully (1–2 hours) before applying the sealer.
- Apply 2 thin coats of outdoor spray sealer, letting each coat dry between applications.
- The sealer deepens the concrete colour and makes the sign weather-resistant.

■ ***Colour tip:*** *Try sage green for leaves + dark charcoal for the text lettering for the most elegant result. The contrast makes the sign readable even from a distance.*

Step 7 — Place in Your Garden

The finished sign nestled in the garden bed among growing plants — perfectly at home

Your garden sign is ready! Place it flat on the soil among plants, prop it against a pot, or press it slightly into the earth at an angle. The sealed concrete is weather-resistant and will last outdoors for years.

- Press the bottom edge slightly into the soil for stability in windy spots.
- Place near the plant the sign names, or use as a general garden quote marker.
- Works beautifully propped against flower pots, terracotta pots, or garden walls.
- In very cold climates, bring inside over winter to extend its life — concrete can crack with repeated freeze-thaw if porous.

The Finished Garden Sign

Hand-lettered, leaf-wreathed, and completely unique — a garden sign made entirely by hand

Pro Tips & Variations

★ Practice lettering before you carve	Write your word on paper 10–15 times in the same style before touching the concrete. Confident, flowing strokes look far better than slow, hesitant lines in concrete. Light pressure gives the cleanest groove.
★ Try different mold shapes	Oval, rectangular, circular, and shield-shaped molds all produce beautiful signs. A rectangular sign works well as a raised bed label or herb garden marker. Round signs look stunning as stepping stones.
★ Use a stamp for perfect lettering	Not confident in freehand? Press alphabet rubber stamps into the wet concrete for crisp, consistent lettering. Available cheaply at craft stores. Press straight down and pull straight up — don't rock the stamp.
★ Personalize for every garden	Beyond 'grow': try herb names (basil, thyme, lavender), family names, coordinates of a special place, or a short poem. In spring, 'bloom' and 'thrive' are perennial bestsellers at craft fairs.
★ Make a matching set	Cast 4–6 signs in one session with different words — 'grow', 'bloom', 'roots', 'wild'. Bundle them with jute twine as a gift set. Sets of 3 signs retail for $30–50 at craft markets.
★ Add a hanging hook	Before the concrete cures, press a bent piece of wire or a small metal D-ring into the back of the sign. Once cured, it can be hung on a fence, gate, or wall.
★ Experiment with different leaves	Fern fronds create dramatic feathery imprints. Bay leaves leave bold, clean outlines. Fennel or dill create lacy, intricate patterns. Pressed flat flowers (pansies, violas) also imprint beautifully.
★ Protect the lettering with wax	After sealing, rub a small amount of clear beeswax polish into the carved lettering and buff lightly. This adds an extra layer of protection and makes the text pop visually.

Troubleshooting

✗ Problem: Lettering fills back in / won't hold shape

✓ **Solution:** The concrete mix is too wet. Mix a stiffer batch with less water — it should hold its shape when you carve into it, not slump back. Work faster too — the concrete becomes firmer as it sets.

✗ Problem: Leaf imprints are too faint / not visible

✓ **Solution:** Leaves weren't pressed deeply enough. Press each leaf firmly with your full fingertip — it should be half-submerged in the concrete, not just resting on top. Freshly picked, pliable leaves also imprint more crisply than older leaves.

✗ Problem: Leaves are stuck to the cured concrete

✓ **Solution:** Carefully pick them off with a toothpick or dental pick. Soaking the sign in water for 10 minutes first softens any dried plant matter.

✗ Problem: Sign cracked after demolding

✓ **Solution:** Demolded too early or concrete was too dry/thin at the edges. Wait the full 24h and ensure even 2–3 cm thickness across the sign. Small cracks can be filled with a paste of cement + water and left to dry.

✗ Problem: Paint is covering the imprints instead of filling them

✓ **Solution:** You applied too much paint or didn't wipe it off quickly enough. Apply a thinner wash and wipe immediately. For a cleaner result, thin the acrylic paint with a little water (1:1) before brushing on.

✗ Problem: Text is hard to read in the finished sign

✓ **Solution:** The lettering was too shallow or too thin. Next time, carve deeper (3–4 mm) and use a slightly wider stylus. Also, painting the text a contrasting dark colour dramatically improves readability.

Thank you for your purchase!

Every garden tells a story. A sign made by hand tells it better. We hope your garden grows beautifully.

made-by-hand.com