DIY CONCRETE

GARDEN GNOMES

Cast, Sculpt & Paint Charming Garden Guardians from Concrete

Step-by-Step Professional Guide

made-by-hand.com

ABOUT THIS PROJECT

Garden gnomes are one of the most beloved outdoor decorations — and now you can cast your own from concrete using professional silicone molds. This guide walks you through every step: mixing the perfect concrete slurry, filling detailed molds, carving surface textures while the concrete is still green, and finishing with paint for a realistic look. The result is a set of durable, weather-resistant gnome sculptures that will last for years.

Difficulty	Intermediate
Time	2–3 hours active + 24h curing
Cost	$15–$30 per gnome
Result	3–6 gnome sculptures
Durability	Weather-resistant, 10+ years

MATERIALS & TOOLS

ITEM	QUANTITY	NOTES
Concrete mix (fine-grain)	5 kg	Use craft/decorative mix for sharp detail
Silicone gnome molds	1–3 molds	Multi-piece molds for 3D figures
Mold release agent	1 can	Spray or brush-on; prevents sticking
Water	As needed	Ratio ~0.35 water/cement for detail work
Mixing bucket & trowel	1 set	Stiff mix — not too wet
Carving/sculpting tools	1 set	Dental pick, palette knife, small chisel
Acrylic paint set	1 set	Grey, blue, white, brown, skin tones
Exterior sealer	1 can	Protects paint from UV & rain
Sandpaper	120 & 220 grit	Smooth rough edges after demolding
Safety glasses & gloves	1 pair each	Concrete is alkaline — protect skin & eyes

STEP-BY-STEP PROCESS

01 PREPARE YOUR MOLDS

Multi-part silicone mold ready for concrete

Inspect your silicone gnome molds for any damage or debris. Assemble multi-part molds and secure them with rubber bands or clamps. Apply mold release spray generously inside every cavity — pay extra attention to deep recesses (the hat tip, beard texture, glasses). Let the release agent dry for 5 minutes before pouring.

★ PRO TIP Cold temperatures slow curing. Work above 15°C for be

02 MIX THE CONCRETE

Mixing concrete to a smooth, lump-free consistency

Use a fine-grain craft concrete or decorative cement mix for sharp facial detail. Add water gradually — the ideal mix is thicker than pancake batter but still pourable. A water-to-cement ratio of around 0.35 gives crisp detail without crumbling. Mix thoroughly for 3–4 minutes until completely lump-free. A slightly gray, glossy surface indicates correct hydration.

★ PRO TIP Add a tiny amount of concrete pigment to the mix for an the mold.

03 POUR INTO THE MOLD

Pouring concrete steadily into the center of the mold

Pour the concrete mix into the mold slowly, starting at the center. Tap and vibrate the mold on your work surface to release air bubbles — this is critical for sharp facial features and eliminates pitting. Fill to just below the mold rim, then use a palette knife to level the back face. Do not overfill or the seam line will be very visible.

★ PRO TIP Vibrate for 30 seconds after filling. Tap the underside of times.

04 INITIAL SET — WAIT FOR GREEN STAGE

Concrete reaching the green (firm but workable) stage

Leave the filled mold undisturbed for 30–90 minutes depending on temperature. The concrete is ready for carving when it holds a fingerprint but doesn't stick to your finger — this is called the "green stage." At this point the surface is firm enough to carve but still soft enough for detail work. Do not rush this step; carving too early causes collapse.

★ PRO TIP Cover with a damp cloth to slow the set in hot weather, time.

05 SCULPT & CARVE DETAILS

Using a carving tool to engrave fine details into green concrete

Carefully demold the gnome at the green stage. Use a dental pick, palette knife, or fine chisel to refine facial features: deepen the eye sockets, sharpen the hat brim, define beard strands, and add texture to the hat. Work quickly but confidently — the window is 15–30 minutes before the concrete gets too hard. Smooth rough areas with a damp brush. Any carved marks at this stage are permanent.

★ PRO TIP Keep a spray bottle of water nearby. Lightly misting the 5–10 minutes of workability.

06 ADD COLOR INSERTS & ACCENTS

Pressing colored concrete into recessed areas for the jeans detail

While still in the green stage, press tinted concrete into recessed areas — blue-tinted mix for jeans, darker grey for the coat, light mix for the hat. This creates natural color variation baked into the concrete itself, not just painted on the surface. Press firmly and smooth with a damp finger. Remove any overlap carefully with the palette knife.

★ PRO TIP Oxide pigments (iron oxide blue/red/yellow) are UV-stab paints alone.

07 FULL CURE — 24 TO 48 HOURS

Gnomes resting in a shaded area during the curing period

Place the sculpted gnomes in a shaded, humid area to cure. Avoid direct sunlight — rapid drying causes surface cracking. Lightly mist with water every few hours during the first 24 hours to ensure slow, even hydration (this is called "wet curing"). Full structural strength is reached after 28 days, but the piece is handleable after 48 hours.

★ PRO TIP Place a plastic bag loosely over the gnomes while curin reduce cracking risk.

08 SAND & REFINE

Sanding the cured gnome to remove mold lines and rough spots

After full cure, use 120-grit sandpaper to remove mold seam lines and any rough bumps. Follow with 220-grit for a smooth finish where needed. Use a small file or rotary tool for tight areas like between the beard strands. Wipe away all dust with a damp cloth and allow to fully dry before painting.

★ PRO TIP Don't over-sand detail areas. Light passes are enough - carved texture.

09 PAINT & FINISH

Detailed paint work on the cured gnome

Apply a base coat of grey or stone-tone acrylic paint all over. Once dry, dry-brush lighter grey/white over raised surfaces to simulate weathered stone. Paint the beard white, jeans denim blue, hat with earthy tones. Use a tiny brush for the eyes and glasses. Finish with a wash of diluted dark brown paint to fill recesses and add age. Seal with 2 coats of outdoor matte sealer to protect from UV and rain.

★ PRO TIP For the most realistic stone look, apply a thin wash of da white over the top. The contrast creates incredible depth

10 DISPLAY IN THE GARDEN

Finished concrete gnomes arranged along a garden path

Place your gnomes in the garden once the sealer is fully dry (at least 24 hours). Group them in odd numbers (3, 5) for a natural look. Position along stepping stone paths, near flower beds, or partially hidden in shrubs. Anchor taller gnomes with a ground stake pushed through the base hole to prevent tipping in wind. Touch up paint annually and reapply sealer every 2–3 years to maintain the finish.

★ PRO TIP Create a "gnome village" by varying the sizes and positi gnomes with your handmade concrete ones for an eclec

PRO TIPS & TRICKS

Perfect Mix Consistency	The single most important factor is concrete consistency. Too wet = no detail, cracks on drying. Too dry = won't flow into mold recesses. Test by lifting a spoonful — it should hold its shape but slowly slump. Like thick yogurt.
Multiple Pours for Hollow Gnomes	For larger molds, pour a thin shell (2–3 cm) rather than a solid fill. Rotate the mold to coat all walls, then pour excess out. This saves material, reduces weight, and speeds drying. Hollow gnomes are less prone to cracking.
Repair Chips & Cracks	Mix a small amount of Portland cement with water to a thick paste. Use as a filler for any chips that occur during demolding. Blend with a damp brush while still wet. Color-match with pigment.
Aged Stone Effect Without Painting	Mix grey oxide pigment into the concrete for a natural stone base color. After curing, apply a watery mix of black cement over the whole piece and immediately wipe back with a damp sponge — residue settles into recesses and creates an instant "antique" weathered look.
Storing Molds	Clean silicone molds immediately after demolding with warm water and a soft brush. Store flat, away from direct sunlight. UV degrades silicone over time. Lightly dust with talc before storage to prevent sticking.

TROUBLESHOOTING

PROBLEM	CAUSE	SOLUTION
Gnome cracked during curing	Too much water in mix; dried too fast	Use lower water ratio; wet-cure with damp cloth for 24h; av
Surface pitting / bubbles	Air trapped in mix during pour	Vibrate mold vigorously after pour; tap base 30+ times; use
Lost fine detail in beard/hat	Mix too wet; demolded too late	Thicker mix; demold at green stage and carve; use dental p
Concrete stuck to mold	Insufficient mold release; demolded too early	Apply more mold release; wait fully 24h; gently flex silicone
Paint peeling after rain	No sealer or wrong type used	Apply 2 coats of exterior acrylic sealer; reapply every 2 sea
Gnome feels too heavy	Solid fill used on large mold	Use shell-casting technique: pour thin layer, rotate, pour ou
Seam line visible	Poor mold assembly or overfilling	Sand with 120-grit; fill with cement paste; blend with match

Thank you for choosing Made By Hand!

If you enjoyed this guide, please leave a review and share your gnome photos in our community. More step-by-step concrete & stone guides available at made-by-hand.com