## CENG3420 Computer Organization & Design

Ryan Chan

March~7,~2025

#### Abstract

This is a note for **CENG3420 Computer Organization & Design** for self-revision purpose ONLY. Some contents are taken from lecture notes and reference book.

Mistakes might be found. So please feel free to point out any mistakes.

Contents are adapted from the lecture notes of CENG3420, prepared by Bei Yu, as well as some online resources.

## Contents

1	Introduction	<b>2</b>
	1.1 The Manufacturing Process of Integrated Circuit	2
	1.2 Power	2
2	Instruction Set Architecture (ISA)	3
	2.1 Organization	3
	2.2 Instruction Set Architecture	3
	2.3 RISC-V	4
3	Arithmetic Instructions	5
	3.1 Introduction to RISC-V	5
	3.2 Arithmetic and Logical Instructions	6
	3.3 Data Transfer Instruction	8
4	Control Instruction	10
	4.1 Introduction to Register	10
	4.2 Control Instructions	10
5	Logic basis	12
6	Arithmetic Logic Unit	13
7	Datapath	14
8	Floating Number	15
9	Pipeline	16
<b>10</b>	More on Pipeline	17
11	Performance	18
12	Memory	19
<b>13</b>	Cache	20
14	Cache Disc	21
	Virtual Machine	22
	Instruction-Level Parallelism	23
TO	THISTI UCTION-DEVEL FARAMENSIN	⊿ડ

### Introduction

This course is about how computers work.

#### 1.1 The Manufacturing Process of Integrated Circuit

For this chapter, only a few calculations need to be considered:

- 1. Yield = The proportion of working dies per wafer.
- 2. Cost per die =  $\frac{\text{Cost per wafer}}{\text{Dies per wafer}} \times \text{Yield}$
- 3. Dies per wafer  $\approx \frac{\text{Wafer area}}{\text{Die area}}$  (since wafers are circle)

4. Yield = 
$$\frac{1}{\left[1 + \left(\frac{\text{Defects per area} \times \text{Die area}}{2}\right)\right]^{2}}$$

**Remark.** Note that the defects on average = Defects per unit area  $\times$  Die area.

#### 1.2 Power

Power = Capacitive load 
$$\times$$
 Voltage<sup>2</sup>  $\times$  Frequency

**Example.** For a simple processor, the capacitive load is reduced by 15%, voltage is reduced by 15%, and the frequency remains the same. Then, how much power consumption can be reduced?

Solution:

$$1 - (1 - 15\%) \times (1 - 15\%) \times 1 = 27.75\%$$

Thus, 27.75% of the power consumption can be reduced.

## Instruction Set Architecture (ISA)

#### 2.1 Organization

Computer components include the processor, input, output, memory, and network. The primary focus of this course is on the processor and its interaction with the memory system. However, it is impossible to understand their operation by examining each transistor individually due to their enormous quantity. Therefore, abstraction is necessary.

Both the control unit and datapath need circuitry to manipulate instructions — for example, deciding the next instruction, decoding, and executing instructions.

There is also system software, such as the operating system and compiler, which translate programs written in high-level languages into machine instructions.

For example, after a program is written in a high-level language (like C), the compiler translates it into assembly language. Then, the assembler converts the assembly code into machine code (object code). The machine code is stored in memory, and the processor's control unit fetches an instruction from memory, decodes it to determine the operation, and signals the datapath to execute the instruction. The processor then fetches the next instruction from memory, and this cycle repeats.

#### 2.2 Instruction Set Architecture

The instruction set architecture (ISA) is the bridge between hardware and software. It is the interface that separates software from hardware and includes all the information necessary to write a machine language program, such as instructions, registers, memory access, I/O, etc.

To put it simple, ISA is a formal specification of the instruction set that is implemented in the machine hardware. It defines how software can control the hardware by specifying the instructions, registers, memory addressing modes, and I/O operations that the processor can execute.

Assembly language instructions are the language of the machine. We aim to design an ISA that makes it easy to build hardware and compilers while maximizing performance and minimizing cost. Therefore, in this course, we focus on the RISC-V ISA.

In a Reduced Instruction Set Computer (RISC), we have fixed instruction lengths, a load-store instruction set, and a limited number of addressing modes and operations. Thus, it is optimized for speed.

There are four design principles in RISC-V:

- 1. Simplicity favours regularity.
- 2. Smaller is faster.
- 3. Make the common case fast.
- 4. Good design demands good compromises.

### 2.3 RISC-V

There are five Instruction Categories:

- 1. Load and Store instruction
- 2. Bitwise instructions
- 3. Arithmetic instructions
- 4. Control transfer instructions
- 5. Pseudo instructions

	31	25	24	20	19		15	14	12	11		7	6		0
R-Type		funct7	rs2			rs1		fun	act3		$\operatorname{rd}$			opcode	
	31			20	19		15	14	12	11		7	6		0
I-Type		imm[11	:0]			rs1		fun	act3		$\operatorname{rd}$			opcode	
	31	25	24	20	19		15	14	12	11		7	6		0
S-Type		imm[11:5]	rs2			rs1		fun	ct3	iı	mm[4:0]			opcode	
				•											
	31								12	11		7	6		0
U-Type			imm[31:	12]							$\operatorname{rd}$			opcode	

Register names	ABI Names	Description
x0	zero	Hard-Wired Zero
x1	ra	Return Address
x2	$_{ m sp}$	Stack Pointer
x3	gp	Global Pointer
x4	tp	Thread Pointer
x5	t0	Temporary / Alternate Link Register
x6-7	t1 - t2	Temporary Register
x8	s0 / fp	Saved Register / Frame Pointer
x9	s1	Saved Register
x10-11	a0 - a1	Function Argument / Return Value Registers
x12-17	a2 - a7	Function Argument Registers
x18-27	s2 - s11	Saved Register
x28-31	t3 - t6	Temporary Register

## **Arithmetic Instructions**

#### 3.1 Introduction to RISC-V

Previously, we had the RV32I Unprivileged Integer Register table:

Register names	ABI Names	Description					
x0	zero	Hard-Wired Zero					
x1	ra	Return Address					
x2	sp	Stack Pointer					
x3	gp	Global Pointer					
x4	tp	Thread Pointer					
x5	t0	Temporary / Alternate Link Register					
x6-7	t1 - t2	Temporary Register					
x8	s0 / fp	Saved Register / Frame Pointer					
x9	s1	Saved Register					
x10-11	a0 - a1	Function Argument / Return Value Registers					
x12-17	a2 - a7	Function Argument Registers					
x18-27	s2 - s11	Saved Register					
x28-31	t3 - t6	Temporary Register					

There are some important registers to note:

Return address (ra): Used to save the function return address, usually PC + 4.

Stack pointer (sp): Holds the base address of the stack. It must be aligned to 4 bytes.

Global pointer (gp): Holds the base address of the location where global variables reside.

Argument registers (a0–a7): Used to pass arguments to functions.

Also, we have the RV32I base types:

	31	25	24		20	19		15	14	12	11		7	6		0
R-Type		funct7		rs2			rs1		fun	ct3		$\operatorname{rd}$			opcode	
	31				20	19		15	14	12	11		7	6		0
I-Type		imm[11	:0]				rs1		fun	ct3		rd			opcode	
	31	25	24		20	10		15	14	12	11		7	6		0
S-Type		imm[11:5]		rs2	20	10	rs1			ct3		nm[4:0]		-	opcode	
	31									12	11		7	6		0
U-Type			in	nm[31:	12]							$\operatorname{rd}$			opcode	

Here, the opcode (7 bits) specifies the operation. rs1 (5 bits) is the register file address of the first source operand. rs2 (5 bits) is the register file address of the second source operand. rd (5 bits) is the register file address of the destination for the result. imm (12 bits or 20 bits) is the immediate value field. funct (3 bits or 10 bits) is the function code that augments the opcode.

Note that the rs1 and rs2 fields are kept in the same place, which causes the imm field in S-type instructions to be separated into two parts.

#### 3.2 Arithmetic and Logical Instructions

Here, we introduce some simple arithmetic and logical instructions.

#### 3.2.1 Arithmetic Instructions

In RISC-V, each arithmetic instruction performs a single operation and specifies exactly three operands, all of which are contained in the datapath's register file.

For example, we have:

```
add t0, a1, a2 # t0 = a1 + a2
sub t0, a1, a2 # t0 = a1 - a2
```

which can be understood as:

```
destination = source1 op source2
```

These instructions follow the R-type format.

#### 3.2.2 Immediate Instructions

Small constants are often used directly in typical assembly code to avoid load instructions. RISC-V provides special instructions that contain constants. For example:

```
addi sp, sp, 4  # sp = sp + 4
slti t0, s2, 15  # t0 = 1 if s2 < 15
```

These instructions follow the I-type format. The constants are embedded within the instructions, limiting their values to the range from  $-2^{11}$  to  $2^{11} - 1$ .

If we want to load a 32-bit constant into a register, we must use two instructions:

```
lui t0, 1010 1010 1010 1010 1010b
ori t0, t0, 1010 1010 1010b
```

Here, lui loads the upper 20 bits with an immediate value, and ori sets the lower 12 bits using an immediate value.

If a number is signed, then 1000 0000 ... represents the most negative value, and 0111 1111 ... represents the most positive value, since the first bit is used to distinguish between signed and unsigned values.

#### 3.2.3 Shift Operations

We need operations to pack and unpack 8-bit characters into a 32-bit word, and we can achieve this by using shift operations. We can shift all the bits left or right:

```
slli t2, s0, 8 # t2 = s0 << 8 bits
srli t2, s0, 8 # t2 = s0 >> 8 bits
```

These instructions follow the I-type format. The above shifts are called logical because they fill the vacancy with zeros. Notice that a 5-bit shamt field is enough to shift a 32-bit value  $2^5 - 1$  or 31 bit positions.

#### 3.2.4 Logical Operations

There are numbers of bitwise logical operations in RISC-V ISA. For example:

R format:

```
and t0, t1, t2  # t0 = t1 & t2

or t0, t1, t2  # t0 = t1 | t2

xor t0, t1, t2  # t0 = t1 & (not t2) + (not t1) & t2
```

I format:

```
andi t0, t1, 0xFF00 # t0 = t1 & 0xFF00
ori t0, t1, 0xFF00 # t0 = t1 | 0xFF00
```

```
Example.
    .global _start
   .text
                                            a1 = 10100, a2 = 10111
   _start:
                                            Line 7: t0 = 10100 \& 10111 \rightarrow
                                                                                10100
           li a1, 20
                                            Line 8:
                                                      t1 = 10100 \mid 10111
                                                                                10111
           li a2, 23
6
                                                      t2 = 10100 ^ 10111
                                            Line 9:
                                                                           ->
                                                                                00011
            and t0, a1, a2
                                                      t3 = 10100 & 10010
                                                                               10000
                                            Line 10:
            or t1, a1, a2
                                            Line 11: t4 = 10111 100001 -> 110111
            xor t2, a1, a2
9
            andi t3, a1, 0x12
10
            ori t4, a2, 0x21
11
```

#### 3.3 Data Transfer Instruction

There are two basic data transfer instructions for accessing data memory:

```
lw t0, 4(s3)  # load word from memory to register
sw t0, 8(s3)  # store word from register to memory
```

The data is loaded or stored using a 5-bit address. The memory address is formed by adding the contents of the base address register to the offset value.

```
Example.
    .global _start
    .data
    a: .word 1 2 3 4 5
    .text
    _start:
                                              t0 = 0x01, t1 = 0x02
            la a1, a
                                              t2 = 0x03, t3 = 0x04
            lw t0, 0(a1)
9
                                              t4 = 0x06, t5 = 0x06
            lw t1, 4(a1)
10
            lw t2, 8(a1)
11
            lw t3, 12(a1)
12
            lw t4, 16(a1)
13
            addi t4, t4, 1
14
            sw t4, 20(a1)
15
            lw t5, 20(a1)
16
   Remark. Address is byte-base, thus the increment is 4 when accessing a1.
```

These instructions follow the I-type format.

Since 8-bit bytes are useful, most architectures address individual bytes in memory.

Note that in byte addressing, we have Big Endian, where the leftmost byte is the word address, and the rightmost byte is the word address for Little Endian. In RISC-V, we use Little Endian, where the leftmost byte is the least significant byte.

We also have loading and storing byte operations:

```
lb t0, 1(s3) # load byte from memory
sb t0, 6(s3) # store byte to memory
```

Here, 1b places the byte from memory into the rightmost 8 bits of the destination register and performs signed extension. sb then takes the byte from the rightmost 8 bits of a register and writes it to memory.

```
Example. Assume that in memory, we have:

0xFFFFFFF 4
0x009012A0 0

Now, we have the following operation:

add s3, zero, zero
1b t0, 1(s3)
sb t0, 6(s3)
```

What is the value left in to? What word is changed in memory and to what? What if the machine was Big Endian?

#### Solution:

- 1. t0 = 0x00000012
- 2. New memory:

0xFF12FFFF 4 0x009012A0 0

3. t0 = 0x00000090, New memory:

0xFFFF90FF 4 0x009012A0 0

### Control Instruction

#### 4.1 Introduction to Register

Previously we have take a look on the instruction fields of RISC-V. Now, we can take a closer look on it.

	31 25	24 20	19	15	14 12	11 7	6	0
R-Type	funct7	rs2	rs1		funct3	rd	opcode	
	31	20	19	15	14 12	11 7	6	0
I-Type	imm[11	:0]	rs1		funct3	rd	opcode	
	31 25	24 20	19	15	14 12	11 7	6	0
S-Type	imm[11:5]	rs2	rs1		funct3	imm[4:0]	opcode	
	31 30 25	24 20	19	15	14 12	11 8 7	6	0
B-Type	imm[12 10:5]	rs2	rs1		funct3	imm[4:1 11]	opcode	
	31				12	11 7	6	0
U-Type		imm[31:12]		rd	opcode			
	31 30	11 7	6	0				
J-Type	im	m[20 10:1 11 1		$\operatorname{rd}$	opcode			

There are a total of five instruction categories, including

- 1. Load and Store instruction
- 2. Bitwise instructions
- 3. Arithmetic instructions
- 4. Control transfer instructions
- 5. Pseudo instructions

The RISC-V register file holds 32 32-bit general-purpose registers, with two read ports and one write port. Thus, there are at most three operands. Registers are faster than main memory, and they are easier for the compiler to use. However, register files with more locations are slower.

#### 4.2 Control Instructions

In RISC-V, we have control flow instructions. For example, we have conditional branch instructions:

```
bne s0, s1, Lbl  # go to Lbl if s0 != s1
beq s0, s1, Lbl  # go to Lbl if s0 == s1
```

These instructions follow the B-format.

```
Example.
 1 .global _start
3 .text
                                          Line 5: a0 = 1
4 _start:
                                          Line 6: a1 = 1
          li a0, 1
                                         Line 7: t0 = 20
          li a1, 1
                                         Line 8: t1 = 23
          li t0, 20
                                          Line 9: t0 != t1 -> goto inst1
          li t1, 23
                                         Line 10 & 11 -> ignored
          bne t0, t1, inst1
9
         addi a0, a0, 1
beq t0, t1, inst2
Line 13: t0:-0
Line 14-> ignored
Line 15: a0 = 2
                                         Line 12: a0 = 3
10
                                         Line 13: t0 != 0 -> goto end
12
          bne t0, zero, end
13
          inst2: addi a0, a0, 3
14
           end: sub a0, a0, a1
15
```

Logic basis

# Arithmetic Logic Unit

Datapath

# Floating Number

Pipeline

More on Pipeline

## Performance

# Memory

Cache

Cache Disc

## Virtual Machine

## Instruction-Level Parallelism