

CONTROLS (positions from the panel render)



CABLE TO THE MAIN BOARD



PWR_FLAG (for the ERC check only)

Generated by pcb/tools/leggibile.py from the same netlist as the PCB: do not edit by hand

Sheet: /
File: mic-comandi.kicad_sch

Title: maelcum MIC control board — draft v0.1 — readable schematic

Size: User	Date:	**Rev: 0.1-draft**
KiCad E.D.A. 10.0.7		Id: 1/1