1 Automatic learning of end stops

Automatic detection of the upper and lower end stops.

Press and hold both buttons simultaneously until an audible signal is emitted and the LED turns yellow.

PRESS **Up** + **Down** **simultaneously until the audible signal**

The support lowers completely and then rises fully to locate the two end stops.

