
2 Loading height

Setting and storing the support tilt for loading.

1 Fully extend the extractable tray.


2 Tilt the support to the desired position.

PRESS **Head up** or **Head down**



3 Store the position.

PRESS **Feet up** + **Feet down** simultaneously



Customer service: customerservice@stem.it