2 Suspension height

Setting and storing the suspension height.

PRECONDITIONS

ⓘ **Recommended value: 200 mm total, measured from the stainless steel platform to the floor**

1 Reach the desired suspension height.

PRESS **Up arrow**



2 Store the suspension height.

PRESS **Suspension** + **Up arrow** **simultaneously**

Audible signal: suspension height stored.

