

SKYCAB - CARDBOARD SHEET 1 OF 5 (3-ply, 25 x 38 in (64 x 97 cm))


Print at 100% / ACTUAL SIZE on a 36 inch (914 mm) roll (page is 860 mm wide, so it fits inside the printer margins: no scaling). Check the 10 x 10 cm square before cutting.


Line up the dashed sheet outline with a corner of your cardboard. The waves (flutes) inside the cardboard must run UP-DOWN on this print, like the grey lines.


Either cut the paper parts out and trace round them, or pin the whole print on the sheet and cut through the solid lines.














Measure both ways. Must be exactly 10 cm.

- Cut
- Fold (glue tabs)
- Press line (inside face)
- Placement mark / sheet edge
- Waves (flutes) this way

ON THIS SHEET

B1	Belt ring x1
C4	Wall, lower rear x1
C2	Wall, upper rear x1
E	Backrest x1
D1	Front beam x1
D2	Rear beam x1
G	Dashboard x1
N	Pod bottom cap x2
R5	Wall joiner strips x3
H	Dashboard brace x2

FLIPPED COPY (F): this copy is the mirror image, for the other side.
LAYER 2 (L2): glue face to face with the first layer, waves crossed, with PVA; press flat overnight.


edge of your 25 x 38 in (64 x 97 cm) cardboard sheet

SKYCAB - CARDBOARD SHEET 2 OF 5 (3-ply, 25 x 38 in (64 x 97 cm))

Print at 100% / ACTUAL SIZE on a 36 inch (914 mm) roll (page is 860 mm wide, so it fits inside the printer margins: no scaling). Check the 10 x 10 cm square before cutting.

Line up the dashed sheet outline with a corner of your cardboard. The waves (flutes) inside the cardboard must run UP-DOWN on this print, like the grey lines.

Either cut the paper parts out and trace round them, or pin the whole print on the sheet and cut through the solid lines.



10 x 10 cm

Measure both ways. Must be exactly 10 cm.

- Cut
- Fold (glue tabs)
- Press line (inside face)
- Placement mark / sheet edge
- Waves (flutes) this way

ON THIS SHEET

A	Deck x2
R5	Wall joiner strips x5

FLIPPED COPY (F): this copy is the mirror image, for the other side.
LAYER 2 (L2): glue face to face with the first layer, waves crossed, with PVA; press flat overnight.


edge of your 25 x 38 in (64 x 97 cm) cardboard sheet


SKYCAB - CARDBOARD SHEET 3 OF 5 (3-ply, 25 x 38 in (64 x 97 cm))


Print at 100% / ACTUAL SIZE on a 36 inch (914 mm) roll (page is 860 mm wide, so it fits inside the printer margins: no scaling). Check the 10 x 10 cm square before cutting.


Line up the dashed sheet outline with a corner of your cardboard. The waves (flutes) inside the cardboard must run UP-DOWN on this print, like the grey lines.

Either cut the paper parts out and trace round them, or pin the whole print on the sheet and cut through the solid lines.










Measure both ways. Must be exactly 10 cm.


- Cut
- Fold (glue tabs)
- Press line (inside face)
- Placement mark / sheet edge
- Waves (flutes) this way

ON THIS SHEET

B2	Bottom ring x1
C4	Wall, lower rear x1
C3	Wall, lower front x1
E	Backrest x1
I	Rotor ring x2

FLIPPED COPY (F): this copy is the mirror image, for the other side.
LAYER 2 (L2): glue face to face with the first layer, waves crossed, with PVA; press flat overnight.






edge of your 25 x 38 in (64 x 97 cm) cardboard sheet


SKYCAB - CARDBOARD SHEET 4 OF 5 (3-ply, 25 x 38 in (64 x 97 cm))


Print at 100% / ACTUAL SIZE on a 36 inch (914 mm) roll (page is 860 mm wide, so it fits inside the printer margins: no scaling). Check the 10 x 10 cm square before cutting.


Line up the dashed sheet outline with a corner of your cardboard. The waves (flutes) inside the cardboard must run UP-DOWN on this print, like the grey lines.

Either cut the paper parts out and trace round them, or pin the whole print on the sheet and cut through the solid lines.

















Measure both ways. Must be exactly 10 cm.

- Cut
- Fold (glue tabs)
- Press line (inside face)
- Placement mark / sheet edge
- Waves (flutes) this way

ON THIS SHEET

C3	Wall, lower front x1
C2	Wall, upper rear x1
C1	Wall, upper front x2
E	Backrest x1
Q	Rotor base disc x1

FLIPPED COPY (F): this copy is the mirror image, for the other side.
LAYER 2 (L2): glue face to face with the first layer, waves crossed, with PVA; press flat overnight.


edge of your 25 x 38 in (64 x 97 cm) cardboard sheet


SKYCAB - CARDBOARD SHEET 5 OF 5 (3-ply, 25 x 38 in (64 x 97 cm))


Print at 100% / ACTUAL SIZE on a 36 inch (914 mm) roll (page is 860 mm wide, so it fits inside the printer margins: no scaling). Check the 10 x 10 cm square before cutting.


Line up the dashed sheet outline with a corner of your cardboard. The waves (flutes) inside the cardboard must run UP-DOWN on this print, like the grey lines.


Either cut the paper parts out and trace round them, or pin the whole print on the sheet and cut through the solid lines.





















Measure both ways. Must be exactly 10 cm.

- Cut
- Fold (glue tabs)
- Press line (inside face)
- Placement mark / sheet edge
- Waves (flutes) this way

ON THIS SHEET

D1	Front beam x1
D2	Rear beam x1
Q	Rotor base disc x3
R3	Rotor rim strip x4
R8	Seat edge strip x2
K	Tail fin side x2

FLIPPED COPY (F): this copy is the mirror image, for the other side.
LAYER 2 (L2): glue face to face with the first layer, waves crossed, with PVA; press flat overnight.

edge of your 25 x 38 in (64 x 97 cm) cardboard sheet