SKYCAB - LAST PAGE: PARTS NOT CUT FROM CORRUGATED CARDBOARD (thin card, plastic, paper guides)

Print at 100% / ACTUAL SIZE on a 36 inch (914 mm) roll; the page is 860 mm wide so it fits inside the printer margins. Check the 10 x 10 cm square first.

U Headlight trim: Thin card (cereal box), painted silver or white, cut 2 (flip one for the right side)
V Headlight lens: White see-through plastic (frosted folder, milk jug), cut 2 (flip one for the right side)
W Headlight box side: Thin card (cereal box), cut 2
X Headlight box back: Thin card (cereal box), cut 2 (flip one for the right side)
R7 Headlight hood: Thin card (cereal box), cut 2
J Rotor blade: Thin card (cereal box), painted black, cut 8 (4 per rotor)
L TAXI sign box: Thin card (cereal box), cut 1
S Windshield: Clear plastic sheet (A3 OHP / clear folder), cut 1
M Tail light: Red card (or red craft foam), cut 2
Y Pod top collar: Thin card (cereal box), cut 2 (one per pod)
R9 Motor collar: Thin card (cereal box), cut 2 (one per motor)
O Fish-mouth guide: Paper (the printout itself), cut paper only, use 4 times
P Pod tube wrap template: Paper (the printout itself), cut paper only, use for both pods

10 x 10 cm

S WINDSHIELD

Clear plastic: A3 OHP sheet or an opened clear folder

Tabs fold OUT and tape to the deck on line S

front centre

BACK

FRONT

strut joins here (inner side)

wire

P POD TUBE

wrap round tube, top edge flush

ends must just meet: made for a

7 cm OUTSIDE diameter tube

gap or overlap? re-measure and enter it on the page

cut: bottom of pod

back

top

end

end

L TAXI (front)

BACK

overlap

TABS: fold OUT, glue under disc Q

Y POD TOP COLLAR

FRONT

U

V LENS

cut off

cut off

O FISH-MOUTH: cut the paper on the wavy line first

FRONT TOP BACK BOTTOM FRONT

X BOX BACK

LED hole

W HEADLIGHT BOX SIDE - this side white, faces in

overlap the ends 1 cm

BOTTOM TABS: fold IN, back X glues on

TOP TABS: fold OUT, glue to the wall round the window

TABS: fold back, glue to the wall above the trim

R7 HEADLIGHT HOOD

M

J

THIS EDGE level with the motor face

R9 MOTOR COLLAR

wrap about 3 turns, until it fits the socket in Q