

TIMETABLE



U.S. SOUTHERN REGION TIMETABLE NO. 1

Effective at 0001 July 1, 2024
Central Daylight Time

For the government and information of employees only.

Keith Creel, President and Chief Executive Officer

Mark Redd, Executive Vice President and Chief Operating Officer

Tracy Miller, Senior Vice President Operations Southern Region

GCOR 4.3 Timetable Characters - Explanation of Characters

The following characters placed in the GCOR 4.3 column provided in timetable indicate:

A – Automatic interlocking

B – General Orders.

C – Radio Communication.

E – Electric Lock.

G – Gate, normally lined against conflicting route.

I – Manual interlocking.

J – Junction with another railroad.

M – Maintenance of Way Lock Out Mechanism or use by maintenance of way employees.

S – Gate, left lined in position last used or crossing protected by stop signs.

T – Turning facility.

W – Hand throw crossover between Main tracks.

X – Power operated crossover between Main tracks.

- Where the symbol # is shown in the Station column it will denote the location of a Control Point or Manual Interlocking.

Table of Contents

US SOUTHERN REGION TELEPHONE NUMBERS	1
KANSAS CITY	2
MEXICO.....	6
ROODHOUSE	10
SPRINGFIELD.....	13
JACKSONVILLE	15
GODFREY	17
EAST ST. LOUIS TERMINAL	19
GATEWAY EASTERN BRANCH	21
PITTSBURG	22
HEAVENER	26
FORT SMITH BRANCH.....	31
SHREVEPORT	32
SHREVEPORT TERMINAL	36
GREENVILLE	47
ALLIANCE	52
DALLAS.....	54
WHITE ROCK BRANCH	56
VICKSBURG.....	57
HODGE.....	61
REDWOOD BRANCH.....	62
MERIDIAN	63
HAVERTY	68
BAY SPRINGS BRANCH.....	70
ARTESIA	71
LOUISVILLE CONNECTION.....	72
TUSCALOOSA	76
ABERDEEN BRANCH	77
COUNCE BRANCH	78
YELLOW CREEK BRANCH.....	79
GULFPORT	80
ALEXANDRIA	82
NEW ORLEANS	85
BEAUMONT	91
LAKE CHARLES.....	97
ROSENBERG	99
LAREDO	101
PORT NECHES BELT LINE	106
PORT NECHES BRANCH	107

US SOUTHERN REGION TELEPHONE NUMBERS

OPERATIONS				
General Manager				
Shreveport (763) 999-0645		Midwest (612) 463-4112		Southeast (601) 933-4732
Superintendents/Terminal				
Shreveport (318) 676-6115	Kansas City (816) 681-5351	Midwest (918) 422-5034	Southeast-Wylie (972) 836-0755	Southeast (816) 277-5264
ENGINEERING				
Assistant Chief Engineer South Region (605) 321-8445				
Superintendents / Division Engineers				
(318) 676-6067		(816) 245-3185		(318) 676-6562
MECHANICAL				
Director (816) 245-3128				
Supt. Locomotive (816) 983-3627				
TRANSPORTATION				
General Manager (816) 245-3105				
Senior Director				
KOC (816) 983-1840		KOC (816) 983-1839		SDC (281) 350-7394
Corridor Manager				
Midwest (816) 983-1809		Southeast (816) 983-1803		Spring TX (281) 350-7399
Train Dispatchers				
Kansas City Console 1 (816) 346-2531	Pittsburg Subdivision Heavener Subdivision from Pittsburg to North Shady Point			
Kansas City Console 2 (816) 346-2532	Heavener Subdivision from North Shady Point (including switch) to Heavener Shreveport Subdivision Ft. Smith Branch			
Kansas City Console 3 (816) 346-2533	Alexandria Subdivision, New Orleans Subdivision (Monday-Friday, 0700-1500) Alliance Subdivision, Dallas Subdivision, Greenville Subdivision Beaumont Subdivision from South Frierson to North DeQuincy Wye (including switch) Lake Charles Subdivision			
Kansas City Console 5 (816) 346-2535	Beaumont Subdivision from South Frierson to North DeQuincy Wye (including switch) Lake Charles Subdivision Vicksburg Subdivision from East Fosters to East Calhoun (including switch)			
Kansas City Console 6 (816) 346-2536	Meridian Subdivision, Haverty Subdivision, Vicksburg Subdivision			
Kansas City Console 7 (816) 346-2537	Mexico Subdivision Roodhouse Subdivision from Mexico to Louisiana Godfrey Subdivision Roodhouse Subdivision from Louisiana to Roodhouse Springfield Subdivision Jacksonville Subdivision Gateway Eastern Branch (Willows Manual Interlocking) Tuscaloosa Subdivision Aberdeen Subdivision Artesia Subdivision from Meridian to West Point Artesia Subdivision from West Point to Corinth Gulfport Subdivision New Orleans Subdivision			
Kansas City Console 8 (816) 346-2538	Shreveport Terminal Subdivision Greenville Subdivision from Texas Junction to West Leg Texas Wye (including switch)			
Spring Console 1 (816) 346-2534	Beaumont Subdivision from North DeQuincy Wye to Station 11 Rosenberg Subdivision Laredo Subdivision			

US Southern Region Timetable

UT Channel	Station Number	GCOR 4.3	Method of Operation	SOUTHWARD ↓	KANSAS CITY SUBDIVISION STATION PAGE # Denotes Control Point or Manual Interlocking	NORTHWARD ↑	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
				Distance From Airline Jct.		Mile Post Location				
332-484	04664	B	YL	196.1	(Ottumwa Sub) OTTUMWA	302.8	302.4 to 305.0	YARD		
					12.9					
	04665			183.2	NSS Blakesburg BLAKESBURG SSS Blakesburg	315.5 315.7 316.8		6,360		318.8 (HBD/ WILD)
					11.2					
	04666			172.0	NSS Moravia MORAVIA SSS Moravia	326.2 326.9 327.4		5,790		
					.9					
	04667	A J M		171.1	APNC JCT (APNC Crossing)	327.8				
					22.6					
346-484	04669		TWC	148.5	SEYMOUR	350.4				345.9
					4.6					
	04670			143.9	NSS Sewal SEWAL SSS Sewal	354.1 355.0 356.5		12,000		
					11.1					
332-484	04671			132.8	NSS Powersville POWERSVILLE SSS Powersville	365.95 366.1 367.3		6,470		372.4
					13.9					
	04673			118.9	NSS Newtown NEWTOWN SSS Newtown	379.2 380.0 381.3		10,200		
346-484					26.0					391.7
332-484				92.9	# Laredo North LAREDO # Laredo South	405.1 406.0 407.6		12,058		
					8.1					
	04677			84.8	# CHULA	414.1				414.1
					8.6					
346-484	04678	J		76.2	# Chillicothe North CHILLICOTHE (Jct MNC) # Chillicothe South	421.9 422.7 423.0		5,063		434.3
					9.8					
				66.4	# DAWN	432.5				
					10.5					
332-484	04680			55.9	# Braymer North BRAYMER # Braymer South	442.1 443.0 443.2		4,911		454.7
					13.8					
	04682	J X		42.1	# POLO (North End 2 MT) (Jct UP)	UP 456.8 456.8				UP464.1
					11.5					
346-484	04684	X(2)		30.6	# LAWSON JCT	UP 468.3 468.3				
					7.8					
	04686			22.8	EXCELSIOR SPRINGS			476.1		
					5.4					
	04688	X(2)		17.4	# MOSEBY JCT	UP 481.5 481.5				
					7.4					
373-454	04689			10.0	Liberty North LIBERTY Liberty South	488.1 488.9 489.2		5,050		485.2
					Continued Next Page					

US Southern Region Timetable

UT Channel	Station Number	GCOR 4.3	Method of Operation	SOUTHWARD ↓	KANSAS CITY SUBDIVISION STATION PAGE # Denotes Control Point or Manual Interlocking	NORTHWARD ↑	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
				Distance From Airline Jct.		Mile Post Location				
373-454					5.5					
		I J X		4.4	# BIRMINGHAM (NS Crossing)	494.4				
					.2					
		X		4.2	# MINNEVILLE	494.6				
					2.4					
		I	CTC	1.8	(South End 2 MT) # DRAWBRIDGE (North End 2 MT)	497.1				
					1.5					
				0.3	# FREIGHTLINE JCT	498.6				
					0.3					
	04690	B T			JOINT AGENCY			YARD		
	04696	J		0.0	(South End 2 MT) # AIRLINE JCT (Jct KCS)	498.9				

MPH	
MAXIMUM SPEED	60
Exceptions:	
MP 302.8 – MP 305.0.....	20
MP 305.0 – MP 327.8.....	40
MP 327.8 over APNC Crossing	40
MP 327.9 – MP 456.7.....	40
Key Trains	
MP 475.0 – MP 481.5 No 2 MT	40
MP UP 473.8 – MP UP 481.4 No 1 MT	40
MP 481.5 – MP 494.0.....	40
No.1 Main Track	
MP 494.0 – MP 498.8.....	25
No. 2 Main Track	
MP 456.7 – MP 457.2.....	40
MP 468.3 – MP 481.5.....	50
MP 494.0 – MP 498.8.....	25
UP SIDING	
MP 456.7 – MP 456.8.....	10
MP 456.8 (N XO SWT UP SIDING) –	
MP 456.85 (UP CONNECTION SWT NO 2 Track)...	40
Polo through North crossover	40
Polo through South crossovers	25
Lawson Jct through Crossover.....	40
Moseby Jct. through North Crossover	40
Moseby Jct. through South Crossover	20
Laredo through turnouts and on siding.....	25
Drawbridge through North and South Crossovers ..	25
Air Line Jct. Over Air Line Switch	15
TrAM Area 2 Locations	
All mixed trains (excluding 100 series) in	
excess of 18,000 tons are restricted to	25

Loaded unit trains

Loaded unit trains carrying crude oil or ethanol are restricted to 30 MPH in non-signaled territory not equipped with a Broken Rail Detection System.

Unless lower speed is prescribed.

Once equipped, territories with a Broken Rail Detection System will be identified by bulletin.

Cold Weather Speed Restrictions

Temperature -15 degrees F or colder	
Entire Sub	35
Temperature below minus -22 degrees F	
Entire Sub	30
Unless a more restrictive speed is in effect.	

Speed Test Sections

MP 307 – MP 310
MP 490 – MP 493

US Southern Region Timetable

Radio Channels

	AAR	Dispr Call In
UT Channel	Refer to Station Page	
Road- Ottumwa to Laredo	044-044	1
Road – Laredo to Airline Jct.	044-044	1
Yard	088-088	7
NS Control Opr Birmingham	018-018	
Engineering Service Reliability		3
Diesel Specialist		5
PTC Help Desk		8
Emergency		911

Telephone

KC Joint Agency Yardmaster.....816-245-3188
 KCT Chief Dispatcher913-551-2179
 KCT Traffic Control Dispatcher East.....913-551-2187
 NS KN Operator, Birmingham816-842-5967

Yard Limits

South MP	North MP
	Ottumwa (Ottumwa Sub) 302.4
305.0	Ottumwa

Positive Train Control (PTC)

PTC is in effect on the Kansas City Sub

Track Bulletins

UP Trains between Polo and Airline Jct.

Southward UP trains must obtain TGBO at Des Moines. Northward trains must obtain TGBO at the originating terminal, unless otherwise instructed.

TrAM Area

The Kansas City Sub is:
 TrAM Area 1 between MP 302.8 and MP 405.1.
 TrAM Area 2 between MP 405.1 and MP 498.8.

Block System

Centralized Traffic Control is in use between Laredo and Airline Jct.

Movement Authority

Track Warrant Control is in use between Ottumwa and to Laredo North.

Main Track Designation

Two main tracks are in use between Polo and Airline Jct, except over Drawbridge. Beginning at the west, the main tracks are numbered 1 and 2.

Interlocking

Automatic Interlocking - APNC JCT. To enter CP main track within automatic interlocking limits, employees must not open the case door or unlock electrically locked switch without Track Warrant authority from CP Operations Supervisor. Employees must not operate Maintenance of Way Lock Box without permission from CP Operations Supervisor.

Birmingham - Manual interlocking under the control of the NS KN Tower control operator.

Drawbridge - Manual interlocking at MP 497.0 under the control of the CP Operation Supervisor.

Equipment Restrictions

Kansas City Terminal: Close clearance in East Yard (EYD) track 100 (short 1) – south side only, track 101 (1 track) – north and south side and track 102 (2 track) – north side only, will not clear man on side of equipment.

Switch Information

Liberty - The inside switch at the South end of the Center siding must be lined and locked for movement onto the NO 2 Main Track. The inside switch at the North end of the Center siding must be lined and locked for movement onto the NO 1 Main Track.

The following main track switches may be left lined and locked in either position:

Ottumwa - North switch at Quincy Street

Electric Locks or Governing Signals

Location	Mile Post	Location of Switch
APNC Interlocking	327.95	APNC Jct. North Transfer Switch (EL)
Excelsior Springs	474.2	N end Italian Pasta Co (EL)
Excelsior Springs	474.8	S end Italian Pasta Co (EL)
Liberty	488.0	N end of Center Siding trk (GS)
Liberty	488.8	N end of House trk (EL)
Liberty	488.8	S end of Center Siding trk (GS)

Trackside Warning Detectors

Mile Post	Type of Detector	Call Back
318.8	HBD/DED/WILD	#318855
345.9	HBD/DED	#345955
372.4	HBD/DED	#372455
391.7	HBD/DED	#391755
414.1	HBD/DED	#414155
434.3	HBD/DED	#434355
454.7	HBD/DED	#454755
464.1	HBD/DED	N/A
485.2	HBD/DED	MT 1 #485266 MT 2 #485244

Bad Order Set Out Tracks

Bad order cars should be spotted between fluorescent yellow paint marks.

Laredo – MP 405 Spot on MFA track

Harris – MP 384 House track spot between buildings.

Powersville – MP 366 North end of siding.

Blakesburg – MP 316 House track south switch.

Chula – MP 413 House track and old siding-south switch only.

Chillicothe – MP 422.6 Number 3 track next to Jackson Street.

Braymer – MP 443.2 House track south switch only.

Moseby – MP 480.8 Moseby Siding.

Liberty – MP 489 Spot car on house track on level track. North switch only.

Other Tracks Not Shown as Stations

Station Number	Location	Mile Post	Switch at
04672	Lucerne	372.4	Both ends
04674	Harris	383.9	North end

General Information

Ottumwa - BNSF crews using CP track must monitor the CP road channel 044-044.

Laredo - Elevator track numbers 1, 2 and MFA track only are in service. No loaded cars may be placed on No. 2 Track. Due to close clearance crews must not ride sides of cars between 1 and 2 tracks when cars are located on those tracks.

Laredo - When using the inside crossover switch for track protection while working on the Stub track at Laredo, you must contact the Dispatcher and inform them that you will be lining the switch for protection account of the switch, when thrown reverse, will give a track occupancy indication on the Dispatchers computer. Once the switch is no longer needed for protection, it must be lined back for the stub track to yard track movement.

Lucerne - Premium Standard Farms (PSF) is designated a REMOTE-CONTROL ZONE (RCZ). CP crews must contact PSF on radio channel AAR 044-044 for permission to enter the RCZ. When work is completed and are clear of the RCZ, they will notify PSF.

If unable to contact PSF by radio, notify the Operations Supervisor and request Customer Service contact PSF.

Joint Agency Yard - Joint Agency limits include all tracks other than CP Main Track. Employees are required to have a current copy of the Greater Kansas City Operating Instructions and KCS Timetable and Special Instructions.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	EASTWARD ↑	MEXICO SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	WESTWARD ↓	Yard Limits	Siding Length	Continuos Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Mexico Depot		Mile Post Location				
53260	C B	TWC	0.0	(Roodhouse Sub) # MEXICO DEPOT	325.7				
				1.1					
53270			1.1	ESS Mexico MEXICO (Includes Hill Trk) WSS Mexico	325.9 326.8 327.4		7,290		
53310			5.7	4.6 THOMPSON	331.4				
53440			14.3	8.6 CENTRALIA	340.0				
53520			25.5	11.2 ESS Clark CLARK WSS Clark	350.1 351.2 351.8		7,923		
	A			0.7					
53610			26.2	NS RRX	351.9				
			35.9	9.7 HIGBEE	361.6				
53660			40.8	4.9 ESS Yates YATES WSS Yates	365.9 366.5 367.1				
53720			46.7	5.9 ARMSTRONG	372.4				
				9.1					
53810			55.8	ESS Glasgow GLASGOW WSS Glasgow	381.1 381.5 381.5				
				2.0					
53830			57.8	ESS Harmony HARMONY WSS Harmony	382.9 383.5 384.5		7,700		
53900			64.8	7.0 ESS Gilliam GILLIAM WSS Gilliam	390.4 390.5 391.0				
				3.1					
53930	C B		67.9	ESS Slater SLATER WSS Slater	393.0 393.6 394.0				
54050			78.8	10.9 ESS Marshall MARSHALL WSS Marshall	404.0 404.5 404.8				
				16.6					
54210			95.4	ESS Blackburn BLACKBURN WSS Blackburn	420.4 421.1 421.5		5,043		
54240			98.4	3.0 ALMA	424.1				
54290			103.5	5.1 CORDER	429.2				
				4.7					
54340			108.2	ESS Higginsville HIGGINSVILLE WSS Higginsville	433.9 433.9 434.7				
				6.1					
54410			114.3	MAYVIEW	440.0				
				7.6					
				Continued on next page					

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	MEXICO SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Mexico Depot		Mile Post Location				
54480	TWC	TWC	121.9	ESS Odessa ODESSA WSS Odessa	447.1 447.6 448.3		5,600	459.65 CQ	460.5
				7.7					
54550			129.6	BATES CITY	455.3				
				3.5					
54590			133.1	OAK GROVE	458.8				
				4.3					
54630			137.4	ESS Grain Valley GRAIN VALLEY WSS Grain Valley	462.5 463.1 464.0		7,369		
				4.5					
54670			141.9	BLUE SPRINGS	467.6				
				11.0					
54780			152.9	INDEPENDENCE WSS Independence	478.6 478.9				
				3.3					
	M		156.2	# ROCK CREEK JCT. (Pittsburg Sub)	481.9			469.12 CQ	472.1

MAXIMUM SPEED MPH 40

Exceptions:

MP 381.5 – MP 382.030
 MP 404.0 – MP 405.3HER 30
 MP 476.0 – MP 481.9.....30
 All Switches and Sidings10

Radio Channels

	AAR	Dispr Call In
Road	078-078	
Disp.	078-078	1
Critical Incident Desk	078-078	3
KCT Narrowband		
East Dispatcher	060-060	187
West Dispatcher	060-060	188
KCT Wideband		
East Dispatcher	060-060	187
West Dispatcher	060-060	188

TrAM Area

The Mexico Sub is TrAM Area 1.

Movement Authority

Track Warrant Control (TWC) is in use between Mexico Depot and Rock Creek Jct.

Positive Train Control (PTC)

PTC is in effect on the Mexico Sub.

Interlockings/Control Points

Automatic Interlocking Approach Location:

(Main Track and Siding, if applicable)

- NS RRR at MP 351.8
- WWD Approach: MP 347.8; EWD Approach: MP 356.5

Equipment Restrictions

LOADED COAL TRAINS

All loaded coal trains must proceed on mainline only.

GLASGOW

River Lead, west of Old Highway 87, restricted to two (2), four (4) axle engines to 705 switch.

Kansas City

Train makeup restrictions for eastbound trains out of Kansas City and any train operating on the wye at Roodhouse.

- When train tonnage exceeds 7,500 tons, the first five cars must be loads*.
- When train tonnage exceeds 10,000 tons, the first ten cars must be loads*.

*Loads would consist of cars weighing 50 tons or more provided the train contains 5 or 10 cars weighing 50 tons or greater. Two consecutively loaded platforms of an articulated car are to be considered the equivalent of one car weighing 50 tons.

Six Axle Locomotives Prohibited from Operating On The Following Tracks:

- Marshall - Except on Fletcher Track West Switch to English Street at MP 404.47
- Glasgow

US Southern Region Timetable

Continuous Quiet Zone – GCOR 5.8.4

Robinson Rd. MP 459.65
Woods Chapel Rd MP 469.12

Trackside Warning Detectors

Mile Post	Type of Detector	Call back
330.8	HBD/DED	#88
364.9	HBD/DED/Oversized Load (C) (W)	
372.3	HBD/DED	
385.9	HBD/DED/Oversized Load (C) (E)	
396.8	HBD/DED	
408.1	HBD/DED	
420.6	HBD/DED	
429.2	HBD/DED	
460.5	HBD/DED	
472.1	HBD/DED	

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
House Track	E	326.0	YARD
Hill Track +	E	326.5	YARD
Centralia Storage	W	339.7	585
East Yates	W	365.9	5,620
West Yates	E	367.1	5,620
Glasgow Co-Op	W	371.9	1,255
MFA Fertilizer	W	380.4	742
Eat Glasgow Co-Op	W	381.1	IND
West Glasgow	E	381.5	IND
East Slater	W	393.0	4,908
City Tracks	W	393.3	IND
East Elevator	W	393.6	1,056
East Slater Crossover	W	393.6	XO
West Elevator	E	393.8	1,056
E Farmers Grain Terminal++	W	394.0	IND
W Farmers Grain Terminal	E	395.0	IND
Hann & Phillips ++	E	404.0	420
East Marshall	W	404.0	3193
East 703 Marshall ++	W	404.2	1,067
Fletcher Grain ++	E	404.4	541
West 703 Marshall	E	404.5	1,067
West Marshall	W	404.8	3193
MFA 404.9	E	404.9	2,600
E Central MO AG Services	W	405.1	IND
W Central MO AG Services	E	405.3	IND
Kent Foods	W	406.5	1,424
United Refrigeration	E	407.2	1,300
Central MO AG Services +	E	420.7	620
Alma Co-Op	E	424.2	2,100
East Ray Carroll Elevator	W	427.9	IND
West Ray Carroll Elevator	E	428.0	IND
East Higginsville	W	433.9	3,976
East Higginsville MFA Grain Elevator ++	W	434.0	1,585
West Higginsville MFA Grain Elevator ++	E	434.4	1,585
West Higginsville	E	434.7	3,976
Super Sweet	W	434.9	900
MFA 435.2	W	435.2	385
Fertilizer Track	E	440.9	210
Odessa Team	W	448.4	470

Name	DOE	MP	Footage
E Blue Springs Run Around	W	467.2	1,188
W Blue Springs Run Around	E	467.5	1,188

+ Indicates Connected to Siding
++ Indicates Connected to Business Track

Switch Information

CENTRAL MISSOURI AGRISERVICES

Dual control derrails are installed on the industry track. These derrails operate in conjunction with the main line PAS switches. When operating the PAS switch by hand, it is also necessary to operate the power derail by hand.

DTMF Yard Switches are installed on the both the East Industry Track and West Industry Track of Central MO AG industry track. When entering the industry tracks it will be necessary to operate the DTMF Yard switches.

East Industry track switch DTMF code: normal switch DTMF # 405133 – reverse switch DTMF #405144.

West Industry track switch DTMF code: normal switch DTMF #405333 – reverse switch DTMF #405344.

RAY CARROLL ELEVATOR

Dual control derrails are installed on the industry track. These derrails operate in conjunction with the main line PAS switches. When operating the PAS switch by hand, it is also necessary to operate the power derail by hand.

DTMF Yard Switches are installed on the both the East Industry Track and West Industry Track of Ray Carroll industry track. When entering the industry tracks it will be necessary to operate the DTMF Yard switches.

East Industry track switch DTMF code: normal switch DTMF #00111 – reverse switch DTMF #00122.

West Industry track switch DTMF code: normal switch DTMF #00211 – reverse switch DTMF #00222.

Power Assisted Switches (PAS):

East Mexico

Radio Channel 078-078
Normal DTMF #325811 Reverse DTMF #325822

West Mexico

Radio Channel 078-078
Normal DTMF #327311 Reverse DTMF #327322

East Clark

Radio Channel 078-078
Normal DTMF #350111 Reverse DTMF #350122

East Harmony

Radio Channel 078-078
Normal DTMF #382811 Reverse DTMF #382822

West Harmony

Radio Channel 078-078
Normal DTMF #384411 Reverse DTMF #384422

East Central MO Ag Services

Radio Channel 078-078
Normal DTMF #405111 Reverse DTMF #405122

West Central MO Ag Services

Radio Channel 078-078
Normal DTMF #405311 Reverse DTMF #405322

East Ray Carroll

Radio Channel 078-078
Normal DTMF #427811 Reverse DTMF #427822

US Southern Region Timetable

West Ray Carroll

Radio Channel 078-078

Normal DTMF #427011 Reverse DTMF #427022

East Odessa

Radio Channel 078-078

Normal DTMF #447111 Reverse DTMF #447122

West Odessa

Radio Channel 078-078

Normal DTMF #448311 Reverse DTMF #448322

West Grain Valley

Radio Channel 078-078

Normal DTMF #464011 Reverse DTMF #464022

General Information

CLARK

WWD Trains holding main track at Clark to meet EWD trains must stop east of posted point East of MP 351.5 until EWD train clear of main track.

ROCK CREEK JCT

Trains exceeding 3,700 feet do not foul crossing at Independence Ave. MP 480.95 until instructed by KCT, Traffic Control Operator Kansas City to proceed to Rock Creek Jct.

KANSAS CITY

While operating on trackage of foreign lines in the Kansas City area, all employees will be governed by the current edition of the Greater Kansas City Area Operating Rules and Special Instructions.

OZARK VALLEY RAILROAD

MP 326.1 - All movement governed by GCOR Rule 6.28.

The Ozark Valley Railroad begins operations at MP 0.0 to MP 24.8 (end of track) on the former Mexico Industrial Lead (Fulton Branch).

INSTRUCTIONS FOR CROSSING NS RR AT MEXICO, MO, TO ENTER OZARK VALLEY RR

Contact NS Dispatcher on radio channel 031-031 and tone 355, to receive permission to crossover.

BROKEN RAIL DETECTION (BRD)

Broken Rail Detection (BRD) limits are in effect on the main track between MP 480.9 and MP 327.4.

Begin BRD and End BRD signs will be posted at the outer limits of BRD Territory.

Limits monitored by BRD have indicators that display aspects for the condition of the track.

BRD INDICATORS

<u>Aspect</u>	<u>Indication</u>
Flashing Green	No defects.
Flashing Red	Expect next indicator to be red.
Red or Dark	Proceed at restricted speed until the leading wheels pass the next BRD indicator and report to the train dispatcher.

While moving within BRD territory, trains must comply with the indication of the BRD indicator.

If an indicator displaying a flashing green or flashing red changes to an indication requiring a train to proceed at restricted speed, the train must immediately reduce speed consistent with good train handling. Train must then move at restricted speed until the leading wheels pass the next BRD indicator and report such an indicator change to the train dispatcher.

When one of the following occurs, move at restricted speed until the leading wheels have passed the next BRD indicator or the end of BRD limits:

- The train enters the main track between BRD indicators.
- The previous BRD indicator is unknown.
- Movements in the opposite direction from which the BRD segment was entered.

Heavy Grade

MP 467.9 – MP 471.3 WWD Avg. Grade 1.02%

MP 473.1 – MP 476.8 EWD Avg. Grade 1.11%

MP 478.7 – MP 481.8 WWD Avg. Grade 1.06%

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	EASTWARD ↑	ROODHOUSE SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	WESTWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Roodhouse		Mile Post Location				
12370	C B T	YL	0.0	(Godfrey Sub) ROODHOUSE (West Wye Switch)	237.3 237.5	237.3 – 237.5			
				5.4					
52420			5.4	DRAKE	242.7				
				3.9					
52460			9.3	ESS Hillview HILLVIEW WSS Hillview	246.0 246.6 246.9				
				3.9					
52510	A		13.2	PEARL (Illinois River Bridge)	250.5				
				15.1					
52660			28.3	ESS Pleasant Hill PLEASANT HILL WSS Pleasant Hill	264.1 265.6 265.8		8,294		
				8.8					
	A		37.1	LOUISIANA (Mississippi River Bridge)	274.4				
				.03					
52750	A		37.13	LOUISIANA (BNSF RRX)	274.7				
				12.8					
52870		TWC	49.9	ESS Bowling Green BOWLING GREEN WSS Bowling Green	286.7 287.5 288.4		8,400		
				5.8					
52940			55.7	CURRYVILLE	293.3				
				9.0					
53020			64.7	VANDALIA	302.3				
				8.9					
53110			76.6	ESS Laddonia LADDONIA WSS Laddonia	310.1 311.2 311.8		7,989		
				5.5					
53160			79.1	RUSH HILL	316.7				
				6.2					
52220			85.3	ESS Arthur ARTHUR WSS Arthur	322.4 322.9 323.1				
				2.8					
53260	C B		88.1	MEXICO DEPOT (Mexico Sub)	325.7				

MAXIMUM SPEED	MPH
	49
Exceptions:	
MP 237.3 – MP 241.0	40
MP 250.3 – MP 251.4	30
MP 252.3 – MP 252.4	40
MP 273.7 – MP 274.1	20
MP 274.1 – MP 274.7	10
MP 274.7 – MP 275.1	20
MP 275.1 – MP 325.7	40
Loaded Unit Trains 60 or Greater or Loaded Coal	
Trains between:	
MP 237.7 – MP 273.7	40
MP 275.1 – MP 325.7	30

MPH
All Switches and Sidings unless listed below10
Turnouts and Sidings
Pleasant Hill25
Tons per Operative Brake
When maximum subdivision speed is over 45 MPH, the maximum speed permitted will be determined by the tons per operative brake.
100 or less No Restriction
101 to 110 55
111 to 120..... 50
Over 120 45

US Southern Region Timetable

Radio Channels

	AAR	Dispr Call In
Roodhouse to Louisiana		
Road	090-090	
Disp.	090-090	1
Critical Incident Desk	090-090	3
Louisiana to Mexico		
Road	078-078	
Disp.	078-078	1
Critical Incident Desk	078-078	3

TrAM Area

The Roodhouse Sub is TrAM Area 1.

Movement Authority

Track Warrant Control (TWC) is in use between Roodhouse and Mexico.

Positive Train Control (PTC)

PTC is in effect on the Roodhouse Sub.

Yard Limits

North MP	South MP
237.3	Roodhouse237.5

Interlockings/Control Points

Automatic Interlocking Approach Location

(Main Track and Siding, if applicable):

- Pearl at MP 250.5
- WWD Approach: MP 242.8; EWD Approach: MP 255.7
- BNSF RRX at MP 274.7
- WWD Approach: MP 270.5; EWD Approach: MP 278.7

Draw Bridge - Pearl, IL. MP 250.5 Automatic Interlocking

- If Home Signal does not display a Proceed Indication:
1. Notify the dispatcher of the stop indication.
 2. Ascertain from the Bridge Tender or by a member of the crew inspecting the movable span portion of the bridge that the rails are aligned properly for rail traffic movement.
 3. Place dual control derail at west end of the bridge in hand position and line for rail traffic. Proceed on proper signal from crew member.
 4. After one unit or car has passed over the derail, restore the derail to the power position.

Drawbridge/BNSF RRX - Louisiana, MO

Drawbridge at Louisiana, MO, and the BNSF RRX are automatic interlockings. Trains encountering a STOP indication, after stopping short of signal, must communicate with the bridge tender to ascertain if the bridge is lined for their movement.

Westward Trains

If the bridge is lined for train movement and the signal governing movement over the bridge fails to display a proceed indication, be governed by the instructions posted in release box at the Bridge West Ward Home signal.

Trains encountering a STOP indication at the BNSF RRX West Ward Home Signal, be governed by instructions posted in the release box located at the RRX.

Eastward Trains

If the bridge is lined for train movement and the BNSF RRX East Ward Home Signal fails to display a proceed indication, be governed by the instructions posted in release box at the RRX. If train is delayed at the BNSF RRX interlocking, the train must contact bridge tender again before proceeding to ascertain that the bridge is lined for their movement because bridge could have been turned during the delay.

Equipment Restrictions

Train Make-Up Restrictions

Roodhouse

Train make up restrictions for any train operating on the wye at Roodhouse.

- When train tonnage exceeds 7,500 tons, the first five cars must be loads*.
- When train tonnage exceeds 10,000 tons, the first ten cars must be loads*.

*Loads would consist of cars weighing 50 tons or more provided the train contains 5 or 10 cars weighing 50 tons or greater. Two consecutively loaded platforms of an articulated car are to be considered the equivalent of one car weighing 50 tons.

Six Axle Locomotives Prohibited from Operating On All Industry Tracks Except:

- Poet Laddonia

Trackside Warning Detectors

Mile Post	Type of Detector	Call Back
242.6	HBD/DED/Oversized Load (C) (W)	#88
260.8	HBD/DED/Oversized Load (C)(E)(W)	
267.9	HBD/DED (C)(E)(W)	
281.2	HBD/DED/Oversized Load (C) (E)	
293.8	HBD/DED	
307.6	HBD/DED	

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
Hillview 702 ++	W	246.6	IND
West Hillview	E	246.9	4,364
Pearl Bridge Team	E	250.7	
Richter Fertilizer++	E	265.7	400
Stock Track	E	276.6	300
1 st Service Supply	W	302.2	IND
Harbison-Walker			
Refactories++	W	302.8	IND
MFA West Vandalia	E	303.0	IND
3 rd Service Supply	W	303.9	758
Missouri Ethanol+	W	311.0	IND
Missouri Farmers Association	W	311.5	IND
National Refactories			
(OVR) ++	W	322.9	IND
West Arthur (OVR)	E	323.1	3,245

Name	DOE	MP	Footage
ADM Grain Elevator	W	323.1	IND
NS Connection++	E	325.7	CONN
+ Indicates Connected to Siding			
++ Indicates Connected to Business Track			
Switch Information			
ROODHOUSE WEST WYE SWITCH			
A DTMF Yard Switch is installed on the West Wye Switch. To operate the DTMF yard switch: normal switch DTMF #237211 – reverse DTMF # 237222.			
The switch point indicator will indicate the following:			
Green - normal position (Roodhouse Subdivision to Godfrey Subdivision)			
Yellow - reverse position (Roodhouse Subdivision to Springfield Subdivision)			
Red - in transition or out of correspondence			
Note: There is a 50 ft. to 100 ft. circuit at these switches that must not be fouled until the switch is lined for intended movement.			
Spring Switch Location			
West Pleasant Hill – MP 265.8			
Power Assisted Switches (PAS):			
East Pleasant Hill			
Radio Channel 090-090			
Normal DTMF #264111 Reverse DTMF #264122			
East Bowling Green			
Radio Channel 078-078			
Normal DTMF #286611 Reverse DTMF #286622			
Power Assisted Switches (PAS):			
West Bowling Green			
Radio Channel 078-078			
Normal DTMF #288311 Reverse DTMF #288322			
East Laddonia			
Radio Channel 078-078			
Normal DTMF #310111 Reverse DTMF #310122			
East Laddonia			
Radio Channel 078-078			
Normal DTMF #311711 Reverse DTMF #311722			
FRA Excepted Track			
- No 12 track North Yard - No 15 track North Yard - Kaiser Lead			
General Information			
Broken Rail Detection (BRD)			
Broken Rail Detection (BRD) limits are in effect on the main track between MP 237.50 and MP 250.25, between MP 250.60 and MP 274.08, between MP 274.73 and MP 324.88.			
Begin BRD and End BRD signs will be posted at the outer limits of BRD Territory.			
Limits monitored by BRD have indicators that display aspects for the condition of the track.			

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	EASTWARD ↑	SPRINGFIELD SUBDIVISION STATION PAGE # DENOTES CONTROL POINT OR MANUAL INTERLOCKING	WESTWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Cockrell		Mile Post Location				
11910	TWC	TWC	0.0	(End of Line) COCKRELL	193.4		Industry		
				10.1					
12030			10.1	East Prouty PROUTY West Prouty	203.4 203.5 204.0				
				6.7					
12100			16.8	YEOMANS	210.2				
				2.5					
12120			19.3	REES	212.7				
				3.4					
12160			22.7	CLEMENTS	216.1				
				5.6					
12270	C B T	YL	28.3	MURRAYVILLE	221.7	N Leg Wye MP 234.5 – MP 237.7 S Leg Wye MP 234.5 – MP 67.5			
				15.6					
12370			43.9	ESS Roodhouse ROODHOUSE (West Wye Switch) (Roodhouse Sub)	234.5 237.3				

MAXIMUM SPEED **MPH 40**

Exceptions:

MP 226.8 – MP 227.1 HER 35

MP 234.5 – MP 237.3 10

All Switches and Sidings unless listed below 10

Turnouts and Sidings

Murrayville 35

Radio Channels

	AAR	Dispr Call In
Road	090-090	
Disp.	090-090	1
Critical Incident Desk	090-090	3
IM	056-056	4

TrAM Area

The Springfield Sub is TrAM Area 1.

Movement Authority

Track Warrant Control (TWC) is in use between Cockrell and Roodhouse.

Yard Limits

East MP	West MP
234.5 Roadhouse (N Leg Wye)	237.7
234.5 Roadhouse (S Leg Wye)	67.5

Equipment Restrictions

CURRAN

Cars exceeding 66 feet are not permitted in ADM.

Movement over Public Crossings

Automatic Warning Devices Infrequently Used:

- MP 194.4 – FAS 1619 – Curran & Auburn
- MP 198.6 – FAS 623 – Loami Road, Springfield
- MP 203.2 – FAS 621 – PP & New Berlin Street
- MP 205.0 – Huffaker Road
- MP 206.0 – County Line Road
- MP 209.8 – FAS 614
- MP 215.8 – County Line Road

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
Curran Elevator	W	193.6	
Prouty Elevator +	W	203.3	
Prouty Elevator +	E	204.0	

+ Indicates Connected to siding.

Switch Information

Murrayville PAS

A Power Assisted Switch is installed at Murrayville. The switch point indicator will indicate the following:

Green - normal position (Jacksonville Subdivision)

Yellow - reverse position (Springfield Subdivision)

Red - in transition or out of correspondence

Radio Channel 090-090

Normal DTMF #226711 Reverse DTMF #226722

Roodhouse West Wye Switch

A DTMF Yard Switch is installed on the West Wye Switch. To operate the DTMF yard switch: normal switch DTMF #237211 – reverse DTMF # 237222.

The switch point indicator will indicate the following:

Green - normal position (Roodhouse Subdivision to Godfrey Subdivision)

Yellow - reverse position (Roodhouse Subdivision to Springfield Subdivision)

Red - in transition or out of correspondence

NOTE: There is a 50 ft. to 100 ft. circuit at these switches that must not be fouled until the switch is lined for intended movement.

Roodhouse Wye

Wye switches may be left lined and locked as last used.

General Information

Cockrell - Springfield

MP 192.4 to KC Jct. is under the jurisdiction of the UP timetable.

KC Jct. to CN Connection and ILES is under the jurisdiction and control of the NS Train Dispatcher.

CN Connection to Avenue is under the jurisdiction and control of the CN Train Dispatcher.

ILES to Ridgley Yard is under the jurisdiction and control of the UP-Train Dispatcher.

Ridgley to Avenue via the IM is under the jurisdiction and control of the IM Train Dispatcher.

NOTE - NS Bulletins and Notices posted at the East St. Louis and Roodhouse Terminals. Train crews must contact NS Train Dispatcher before departing initial terminal and request Dispatchers Bulletins and provide NS Train Dispatcher with train information.

Train crews must then contact the CN Train Dispatcher for the highest number General Order in effect and provide CN Train Dispatcher with train information. Train crews must also contact UP Train Dispatcher, request Track Warrant, and provide UP Train Dispatcher with train information.

Eastward Crews should contact NS Train Dispatcher (039-039) in the area of Prouty - Westward Crews contact NS Train Dispatcher when departing Springfield to advise NS Train Dispatcher of their approach.

Eastward Crews contact UP Train Dispatcher from the Prouty area and Westward Crews should contact the UP-Train Dispatcher (030-030) when leaving the Springfield area.

Eastward Crews contact the CN Train Dispatcher before leaving Air Line Industrial Lead at KC JCT. Westward Crews contact the CN Train Dispatcher before leaving the IM property to request permission to enter CN track.

Train crews contact IM Train Dispatcher (056-056, tone 04) after arriving on CN property or prior to leaving UP Ridgley for permission to enter IM track.

Murrayville

Milepost equalization - There is one mile between MP 221 and MP 227.

Broken Rail Detection (Brd)

Broken Rail Detection (BRD) limits are in effect on the main track between MP 234.5 and MP 221.7.

Begin BRD and End BRD signs will be posted at the outer limits of BRD Territory.

Limits monitored by BRD have indicators that display aspects for the condition of the track.

BRD Indicators

<u>Aspect</u>	<u>Indication</u>
Flashing Green	No defects.
Flashing Red	Expect next indicator to be red.
Red or Dark	Proceed at restricted speed until the leading wheels pass the next BRD indicator and report to the train dispatcher.

While moving within BRD territory, trains must comply with the indication of the BRD indicator.

If an indicator displaying a flashing green or flashing red changes to an indication requiring a train to proceed at restricted speed, the train must immediately reduce speed consistent with good train handling. Train must then move at restricted speed until the leading wheels pass the next BRD indicator and report such an indicator change to the train dispatcher.

When one of the following occurs, move at restricted speed until the leading wheels have passed the next BRD indicator or the end of BRD limits:

- The train enters the main track between BRD indicators.
- The previous BRD indicator is unknown.
- Movements in the opposite direction from which the BRD segment was entered.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	JACKSONVILLE SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Jackson ville		Mile Post Location				
32380	TWC		0.0	(End of Line) JACKSONVILLE	216.3				
				7.1					
23200			7.1	WOODSON	223.4				
				3.3					
12270			10.4	MURRAYVILLE (Roodhouse Sub)	226.7				

MAXIMUM SPEED **MPH**
40

Exceptions:

MP 216.3 – MP 218.810
 MP 234.5 – MP 237.310
 All Switches and Sidings10

Radio Channels

	AAR	Dispr Call In
Road	090-090	
Disp.	090-090	1
Critical Incident Desk	090-090	3

TrAM Area

The Jacksonville Sub is TrAM Area 1.

Movement Authority

Track Warrant Control (TWC) is in use between Jacksonville and Murrayville.

Movement over Public Crossing

Automatic Warning Devices Used Infrequently:

- MP 217.8 – Vandalia Street

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
N Jacksonville Run Around	S	216.5	690
S Jacksonville Run Around	N	216.7	690
BNSF Interchange		217.3	
PACTIV (Mobil)	N&S	217.3	
Bartlett Elevator	N	219.2	IND

Switch Information

Murrayville PAS

A Power Assisted Switch is installed at Murrayville. The switch point indicator will indicate the following:

Green - normal position (Jacksonville Subdivision)
Yellow - reverse position (Springfield Subdivision)
Red - in transition or out of correspondence

Bartlett Elevator

Dual control derail is installed on the industry track. This derail operates in conjunction with the main line PAS switch. When operating the PAS switch by hand, it is also necessary to operate the power derail by hand.

Power Assisted Switches (PAS):

Murrayville

Radio Channel 090-090

Normal DTMF #226711 Reverse DTMF #226722

Bartlett Elevator

Radio Channel 090-090

Normal DTMF #219211 Reverse DTMF #219222

FRA Excepted Track

All yard and industry tracks.

General Information

BROKEN RAIL DETECTION (BRD)

Broken Rail Detection (BRD) limits are in effect on the main track between MP 234.5 and MP 221.7.

Begin BRD and End BRD signs will be posted at the outer limits of BRD Territory.

Limits monitored by BRD have indicators that display aspects for the condition of the track.

BRD INDICATORS

Aspect	Indication
Flashing Green	No defects
Flashing Red	Expect next indicator to be Red
Red or Dark	Proceed at restricted speed until the leading wheels pass the next BRD indicator and report to the train dispatcher.

While moving within BRD territory, trains must comply with the indication of the BRD indicator.

US Southern Region Timetable

If an indicator displaying a flashing green or flashing red changes to an indication requiring a train to proceed at restricted speed, the train must immediately reduce speed consistent with good train handling. Train must then move at restricted speed until the leading wheels pass the next BRD indicator and report such an indicator change to the train dispatcher.

When one of the following occurs, move at restricted speed until the leading wheels have passed the next BRD indicator or the end of BRD limits:

- The train enters the main track between BRD indicators.
- The previous BRD indicator is unknown.
- Movements in the opposite direction from which the BRD segment was entered.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	GODFREY SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Pittsburg		Mile Post Location				
01370	C B T	YL	0.0	(Roadhouse Sub) ROADHOUSE (West Wye Switch) SSS Roadhouse	237.3 68.2 67.6	MP 68.2 – MP 67.6			
42420		TWC	3.6	3.6 WHITEHALL	64.6				55.4
42510			13.0	9.4 CARROLLTON	55.2				
42590			21.2	8.2 KANE	47.0				
42640			26.5	5.3 JERSEYVILLE	41.7				
42680			30.5	4.0 NSS Sherman SHERMAN SSS Sherman	38.3 37.7 36.8	7,405			
42710			32.5	2.0 DELHI	35.7				35.7
22520	I		40.2	7.7 GODFREY (East St. Louis Sub)	28.1				

MPH	
MAXIMUM SPEED	49
Exceptions:	
MP 68.2 – MP 67.2	10
MP 56.0 – MP 28.1	40
Loaded Unit Trains 60 or Greater	35
Loaded Coal Trains	35
All Switches and Sidings unless listed below	
Turnouts and Sidings	
Sherman	25
Tons per Operative Brake	
When maximum subdivision speed is over 45 MPH, the maximum speed permitted will be determined by the tons per operative brake.	
100 or less	No Restriction
101 to 110	55
111 to 120	50
Over 120	45

Radio Channels

	AAR	Dispr Call In
Road	090-090	
Disp.	090-090	1
Critical Incident Desk	016-010	3

TrAM Area

The Godfrey Sub is TrAM Area 1.

Movement Authority

Track Warrant Control (TWC) is in use between
Roadhouse and Godfrey.

Positive Train Control (PTC)

PTC is in effect on the Godfrey Sub.

Yard Limits

North MP	South MP
68.2	Roadhouse 67.6

Equipment Restrictions

**Six Axle Locomotives Prohibited from Operating
On The Following Tracks:**

- All Industry Tracks

Trackside Warning Detectors

Mile Post	Type of Detector	Call Back
55.4	HBD/DED	#88
35.7	HBD/DED	

**Other Tracks Not Shown as Stations
(Business Tracks)**

Name	DOE	MP	Footage
Green Country Farm Service	S	67.2	1,830
North Carrollton	S	55.3	1,100
Illinois Valley Supply ++	N	55.1	320
South Carrollton	N	55.0	1,100
Carrollton Farmers Elevator	N	54.9	1,090
US Can	S	41.2	950
Jersey County Farm Service	N	40.9	550
Lake Drive Logistics	S	28.3	250
++ Indicates Connected to Business Track			

Switch Information

ROODHOUSE SOUTH WYE SWITCH

South wye switch must be left lined and locked for movement around the wye.

Southward trains approaching 13-degree curve at MP 67.9 and operating with excess of 7,000 trailing tons must have ten (10) loads (cars weighing over 50 tons) on the head end or be operated with distributed power or helper locomotives.

ROODHOUSE WEST WYE SWITCH

A DTMF Yard Switch is installed on the West Wye Switch. To operate the DTMF yard switch: normal switch DTMF #237211 – reverse DTMF # 237222.

The switch point indicator will indicate the following:

Green - normal position (Roodhouse Subdivision to Godfrey Subdivision)

Yellow - reverse position (Roodhouse Subdivision to Springfield Subdivision)

Red - in transition or out of correspondence

NOTE: There is a 50 ft. to 100 ft. circuit at these switches that must not be fouled until the switch is lined for intended movement.

SHERMAN POWER ASSISTED SWITCH

A PAS Switch is located at North Sherman. To operate the switch, use channel 090-090: normal switch DTMF #038311 – reverse DTMF # 038322

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	WESTWARD ↑	EAST ST. LOUIS TERMINAL SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	EASTWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Godfrey		Mile Post Location				
22512			0.0	(Godfrey Sub) GODFREY	252.1				
Operation via UPRR between Godfrey MP 252.1 and Q Tower MP 281.0									
		NO 1 MT Current of Traffic	YL	28.9	Q TOWER	281.0	NO 1 MT MP 281.0 - MP 287.2	NO 2 MT MP 281.0 - MP 281.4	
				0.4					
			NO 2 MT TWC	29.3	HOLE IN THE WALL	281.4			
				0.3					
			W	29.6	M&O JCT	281.7			
				1.9					
			I	31.5	VALLEY JCT	283.6			
				1.4					
			22810	32.9	EAST ST. LOUIS	285.0			
			C B	2.2					
		6.28		35.1	CHURCH (End of Line)	287.2			

MAXIMUM SPEED **MPH**
10

Exceptions:
Turnouts and Sidings 10

Radio Channels

	AAR	Dispr Call In
Road	090-090	
Disp.	090-090	1
Critical Incident Desk	090-090	3
KCS Gateway Road – State of Illinois	090-090	
ESTL Yd & KCS Mech	060-060	
KCS Gateway ESTL	079-079	
NS Yard	076-076	
CN	072-072	
CSXT Rose Lake Yd	008-008	
KCS GWWR ATM	060-060	
ESTL Yd	044-044	
ALS	044-044	
KCS Gateway ESTL Yd	041-041	
UP Disp	030-030	
TRRA	026-026	
NS Road	092-092	#351
Emergency		911

Track Bulletins

Train crews must obtain a KCS Track Bulletin from the train dispatcher when they come on duty.

TrAM Area

The East St. Louis Terminal Sub is TrAM Area 3.

Main Track Designation

Two main tracks are in use between Q Tower and Church.

Track Warrant Control in effect between MP 281.4 – MP 283.4.

Yard Limits

East MP	West MP
281.0	Q Tower & Church MT 1287.2
281.0	Q Tower MT 2281.4

Tolson Main between M&O Jct. and STOP sign governing movement over TRRA RRX is Yard Limits. Permission must be secured from KCS Assistant Trainmaster, East St. Louis before occupying track between these points.

6.28 Other than Main Track

SWAMP INDUSTRIAL LEAD: MP 265.01 all movement by Rule 6.28 not to exceed 10 MPH. Permission must be obtained from Track Supervisor before entering these limits.

US Southern Region Timetable

EAST ALTON INDUSTRIAL LEAD:

Between Wann (MP 2.3) and East Alton (Olin Brass - MP 0.91) is governed by Rule 6.28 - Other than Main Track not to exceed 10 MPH. Permission must be obtained from the Track Supervisor and Console 7 before entering these limits.

FRA Excepted Track

All locomotive facility tracks, East St. Louis Yard.

Movement over Public Crossings

Automatic warning devices used infrequently at MP 1.0 – St. Louis Avenue on Old Conrail Main.

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
Cargill	E	281.7	1,950
Brenntag	W	281.8	900
WATCO Cahokia			
Terminal	W	281.8	IND
Big River Zinc	W	282.7	IND
Afton Chemical Coop	W	282.8	IND

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	WESTWARD ↑	GATEWAY EASTERN BRANCH STATION PAGE # Denotes Control Point Or Manual Interlocking	EASTWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Q TOWER		Mile Post Location				
	W	YL	0.0	(East St. Louis Sub) Q TOWER	238.6	MP 236.8 – MP 236.8			
				0.2					
	S		0.2	K DIAMOND	238.4				
				1.4					
	I		1.6	WILLOWS INTERLOCKING	237.0				
				0.2					
			1.8	CSXT ROSELAKE YD	236.8				

MAXIMUM SPEED		MPH
		20*
*Restricted Speed with Maximum of 20 MPH.		
Exceptions:		
MP 238.4.....	5	
Switches and Sidings	10	

Radio Channels

	AAR	Dispr Call In
Road	090-090	
Disp.	090-090	1
Critical Incident Desk	090-090	3

TrAM Area

The Gateway Eastern Branch is TrAM Area 1.

Yard Limits

East MP	West MP
238.6	Q Tower
	CSXT Roselake YD281.4

General Information

K CONNECTION

K Connection between Q Tower and K Crossing is governed by Yard Limits. Permission must be secured from Console 7 in order to occupy the K Connection.

NOTE: Train crews must obtain a CPKC Track Bulletin from the train dispatcher when they come on duty.

EWD trains proceeding from the K Connection to the Q Connection must not pass the absolute signal at Q Tower unless:

1. Permission has been secured to enter the CTC (UP Springfield District).
- or
2. After proceeding, train will clear Q Tower Interlocking without entering CTC.

Q CONNECTION

Q Connection between Bridge JCT and Q Tower is governed by Yard Limits. Permission must be secured from CPKC Assistant Trainmaster, East St. Louis, to occupy the Q Connection.

CSXT CONNECTION - K CROSSING-CONE YARD

Crossing of K Connection and GWWE at K Crossing protected by STOP signs.

ROSELAKE CONNECTION

The connection track from the CPKC main track to the TRRA northbound track is designated as the Roselake Connection.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	PITTSBURG SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits		Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Kansas City		Mile Post Location					
0004	B C T	6.28	0.0	(Mexico Sub) KANSAS CITY (2MT) # West Wye	3.7 5.0	N MT MP 1.1 – MP 5.0	S MT MP 1.3 – MP 5.0			
		CTC		1.4						
			1.4	# AIRLINE JCT.	5.1					
	I			0.3						
			1.7	# UP RRX	5.4					
				0.1						
			1.8	# MALONE JCT.	5.5					
				0.4						
			2.2	# KCS JCT. (Signal 84R)	5.9					
				0.2						
	I		2.4	KCS RRX (2)	6.1					
				0.2						
			2.6	# KCS JCT. (Signal 98L)	6.3					
				1.8						
0009			4.4	# Blue Valley North BLUE VALLEY # Blue Valley South	8.1 8.1 9.8			8,342		
				15.4						12.1
0023			19.8	# Grandview North GRANDVIEW # Grandview South	23.3 23.5 25.3			9,284		15.1
				4.9						27.0
0027	W		24.7	INT. FREIGHT GATEWAY # IFG South	28.5 28.7					
				4.3						
0033			29.0	# Jaudon North JAUDON # Jaudon South	32.5 32.7 34.2			8,480		36.9
				20.4						46.1
0053			49.4	# Drexel North DREXEL # Drexel South	50.9 53.1 53.1			11,285		
				9.3						58.4
0062	T		58.7	# Amsterdam North # Amsterdam Wye (N Leg) AMSTERDAM # Amsterdam South	61.3 61.6 62.4 62.7			6,792		67.8
				18.3						68.8
0081			77.0	# Hume North HUME # Hume South	79.9 80.7 81.5			7,541		77.6
				18.2						86.8
0099			95.2	# Eve North EVE # Eve South	97.9 98.9 100.0			10,214		89.4
				15.7						95.2
	A		110.9	BNSF RRX	114.6					110.4
				3.5						
0118			114.4	# Mulberry North MULBERRY # Mulberry South	115.9 118.1 118.4			12,397		
				10.1						
				Continued next page						

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	PITTSBURG SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Kansas City		Mile Post Location				
0258	B C T	YL	124.5	# Pittsburg North PITTSBURG (2 MT) (Heavener Sub)	126.8 128.2	MT NO 1 (E) MP 126.8 – MP 128.8	MT NO 2 (W) MP 126.8 – MP 128.8		124.9

MPH MAXIMUM SPEED 59

Exceptions:

MP 1.1 – MP 5.0 Zero Track	15
MP 1.1 – MP 5.0 Tracks 901 - 902.....	15
MP 1.3 – MP 5.0 South MT	15
MP 2.8 – MP 5.0 Track 903	15
MP 5.0 – MP 5.4	15
MP 5.4 – MP 6.3	25
MP 6.3 – MP 11.4	40
MP 11.4 – MP 23.5	45
MP 37.3 – MP 42.2	45
MP 56.6 – MP 57.0	50
MP 72.1 – MP 73.4	45
MP 91.4 – MP 92.0	50
MP 114.5 – MP 114.6	40
MP 126.8 – MP 128.8 NO 1 MT	20
MP 126.8 – MP 128.8 NO 2 MT	HER 20
All Switches and Sidings unless listed below	10

Turnouts and Sidings

Blue Valley	30
Grandview, North IFG, South IFG, Jaudon, Drexel, Amsterdam, Hume, Eve, Mulberry & Pittsburg North End.....	25

Kansas City Terminal Tracks

Zone 4

Tracks 001-0021, 92-94, 98, 125-132	
Tracks including Turnouts	15
Crossover.....	10

Zone 5

Tracks 041-042, 097-098, 100-122, 201-202	
Tracks including Turnouts	15
Crossover.....	10

Grandview & IFG

Zone 1 & 12 Track 201

Track including Turnouts.....	15
Crossover.....	15

Zone 12

Tracks 401 – 405, 602, 701 & 800

Track including Turnouts.....	15
Crossover.....	15

Heavy Load Restriction

Eight axle cars with and gross weight of 132 – 263 Tons	
MP 73.2.....	25

Tons per Operative Brake

When maximum subdivision speed is over 45 MPH, the maximum speed permitted will be determined by the tons per operative brake.

Over 15045 MPH

Radio Channels

	AAR	Dispr Call In
Road	010-010	
Pittsburg Yard Switching	010-010	
Yardmaster	064-064	
Knoche Yard Switching	063-063	
KCT East	060-060	187
KCT West	060-060	188
BNSF KC	036-036	
BNSF Murray Yard	066-066	
Disp.	016-010	1
Critical Incident Desk	016-010	3

TrAM Area

The Pittsburg Sub is TrAM Area 1.

Block System

Centralized Traffic Control (CTC) is in use between Kansas City and Pittsburg.

Main Track Designation

Two main tracks are in use at Pittsburg and Kansas City.

Positive Train Control (PTC)

PTC is in effect on the Pittsburg Sub.

Yard Limits

North MP	South MP
1.1	North Main 5.0
1.3	South Main 5.0
126.8.....	NO 1 (E) MT..... 128.8
126.8.....	NO 2 (W) MT..... 128.8

US Southern Region Timetable

Pittsburg Yard Limits

Within Yard Limits at Pittsburg, permission must be obtained from the Train Dispatcher to enter the No. 1 and No. 2 Main Tracks. Upon clearing these main tracks, they must be released back to the Train Dispatcher.

Interlockings/Control Points

AUTOMATIC INTERLOCKING APPROACH

LOCATIONS (MT and Siding, if applicable)

- BNSF RRX at MP 114.6
- NWD Approach: MP 120.66
- SWD Approach: MP 109.00

Equipment Restrictions

Six Axle Locomotives Prohibited from Operating On The Following Tracks:

- Knoche Yard
- Tracks 429
- Tracks 430 and 431 East of the Car Shop
- Track 700 (Industrial Lead) North of Front Street
- Zone 5, Track 412 (Mechanical Expedite)
- Old BN Connection (Grandview) – MP 23.1

Electric Locks

Station	MP	Location of switch
Cave Switch	8.5	Cave Switch
Midwest Locomotive	10.0	Midwest Locomotive
Grandview	23.1	BN Connection
IFG Crossover	27.7	IFG Crossover

Trackside Warning Detectors

Mile Post	Type of Detector	Call Back
12.1	DED	#88
15.1	HBD/DED	
27.0	HBD/DED	
36.9	HBD/DED	
46.1	HBD/DED	
58.4	HBD/DED	#88
67.8	Wheel Impact/Hunting Truck/ Imbalanced Load/Machine Vision	
68.8	HBD/DED (C) (S)	
77.6	HBD/DED (C) (N) & (S)	
86.8	HBD/DED	
89.4	HBD/DED	
95.2	HBD/DED/Oversized Load (C) (N) & (S)	
110.4	HBD/DED/Oversized Load (C) (N)	
124.9	HBD/DED	

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
Midwest Locomotive	S	10.0	1,500
BN Connection	N	23.1	1,500
Grandview Team Track +	N	23.9	1,722
American Ingredients	N	24.8	1,525
Grandview South Ind. Lead +	S	25.0	3,100
North IFG-IFG 601	S	25.2	18,229

Name	DOE	MP	Footage
IFG Crossover	S	27.7	XO
South IFG-IFG 601	N	28.6	18,229
Cleveland	N	39.0	800
Drexel Team Track	S	53.0	1,471
N.L. KCPL-Amsterdam +	S	61.6	838
S.L. KCPL-Amsterdam +	N	61.9	842
Amsterdam Team Track +	S	62.2	1,541
Amsterdam Team Track +	N	62.5	1,541
Amoret	S	68.7	900
Hume Team Track +	S	80.7	2,766
Hume Team Track +	N	81.3	2,766
Richards	S	93.3	720
Eve Team Track +	S	98.2	1,170
Eve Team Track +	N	98.5	665
Oskaloosa	N	112.3	630
Mulberry Team Track +	N	118.2	580

+ Indicates Connected to Siding

General Information

Trains Departing Kansas City

CPKC southward trains will contact the yardmaster for permission to depart. Once permission from yardmaster is granted, train will then contact CPKC dispatcher for permission to enter CPKC dispatched Main Track at KCS JCT. Once permission is received from CPKC dispatcher, the train is to contact KCT East dispatcher and report the following: Train ID; Locomotive number; total number of cars; tonnage; footage (including locomotives); from location (e.g., 902) and to location (e.g., CPKC Main Track).

Trains Departing Kansas City Off the KCT Main Track

CPKC southward trains departing off the KCT Main Track (aka bridge 19 meets) after reporting to KCT that crew is on train. Crew will contact CPKC dispatcher for permission to enter CPKC Main Track at KCS Jct. If unable to contact either CPKC or KCT dispatcher call CPKC Yardmaster and report situation.

Trains Arriving Kansas City

Before passing signal at North Blue Valley NWD movements must comply with the following.

- Trains must report locomotive/train ID and total cars in train to CPKC yardmaster and receive instructions.
- The crew must contact KCT East dispatcher to enter KCT track. The crew will inform the KCT East dispatcher of the following: Train ID; Locomotive number; total number of cars (loads, empties) tonnage; footage (including locomotives); from location (e.g., Blue Valley) and to location (e.g. Knoche, BNSF Murray yard, etc.)

All trains and locomotives entering Kansas City yard limits must operate on radio channel 064-064. Prior to entering Kansas City yard limits, you must contact the yardmaster for instructions and to ascertain route is clear. Do not foul the west end of any track at East Kansas City yard until receiving permission from the yardmaster.

Industrial lead must have a minimum of two cars coupled together south of Front Street when leaving equipment unattended.

US Southern Region Timetable

Close Clearances not otherwise specified in the timetable are designated by Close Clearance Signs, crews are to use caution when handling equipment at any location where close clearances may exist.

CPKC crews operating on Kansas City Terminal trackage will use KCT Channel 060-060.

While operating on trackage of foreign lines in the Kansas City area, all employees will be governed by the current edition of the Greater Kansas City Operating Rules and Special Instructions.

When operating solid over-the-road trains from the CPKC to BNSF, the following will govern:

- When a train is routed via the Kansas City Terminal Railway, notify the Kansas City Tower of the arriving and departure time at KCS junction.
- Notify the Kansas City Tower when arriving Airline Junction to obtain a route and clearance to the BNSF.
- Notify the Kansas City Tower when arriving on the KCT Bluff Track, and again when departing the KCT Bluff Track.
- When arriving Harlem Street or Ustic Tower, call the Kansas City Tower to request transportation from the BNSF yard and advise the delivery time.
- Any delay in excess of fifteen minutes en route to the BNSF must be reported at once to the Kansas City Yardmaster. If delay continues, a status report must be made every fifteen minutes to permit supervisors to handle.

Maintenance of Way employees desiring to perform track work on the main track between MP 5.0 and MP 6.3 must obtain permission from the KCT Operator.

Kansas City Terminal

Close clearance in East Yard (EYD) track 100 (short 1) – south side only, track 101 (1 track) – north and south side and track 102 (2 track) – north side only, will not clear man on side of equipment.

The group of tracks 4 through 20 within Knoche Yard is designated as bowl tracks, tracks 4 through 20 must be secured with three hand brakes on each track. Crews must leave behind the three cars with hand brakes unless otherwise directed by the Knoche Yardmaster.

Industrial lead switch must be left lined for 903 when not in use. West end of the service track must be lined for 902 when not in use.

Road crews departing the service track will operate on radio channel 064-064 within the Kansas City yard limits (Knoche Yard) until train is released and departing yard limits.

Crews delivering trains to foreign line carriers will use radio channel 064-064 to contact the yardmaster to arrange transportation.

Bulk commodity trains do not use the crossover 901 to the north Main Track at Kansas Avenue.

Unit oil trains are restricted to Tracks 901, 902 and 903.

Remote Operations:

The Kansas City Joint Agency Yard has been established as a Remote-Control Operating Area.

A Remote-Control Zone is established in the Kansas City Joint Agency Yard on the work lead between the East G.I. Track switch extending Eastward to the Eastbound clearance point of the track 125 switch. This zone shall be identified as RCZ 1.

A Remote-Control Zone is established in the Kansas City Joint Agency Yard on the work lead between the Eastbound clearance point of the track 125-switch extending Eastward to the clearance point of the Zero Track switch. This zone shall be identified as RCZ 2.

A Remote-Control Zone is established in the Kansas City Joint Agency Yard on Zero Track between the work lead/ west crossover switch extending Eastward to the clearance point of the Tail Track switch. This zone shall be identified as RCZ 3.

Drexel

When possible, southward trains stop at least 720 feet north of Pine Street, MP 53.0, when leaving train unattended, waiting for signal indication or waiting to meet opposing train.

Amsterdam

A dual control derail is installed at the clearance point of the North leg of the Wye. This derail operates in conjunction with the dual controlled switch at Amsterdam Wye. When operating the Amsterdam Wye dual control switch by hand, it is also necessary to operate the derail by hand.

IFG

Permission must be granted by CPKC Console 1 Dispatcher prior to occupying Business Track (602) at IFG. CPKC Console 1 Dispatcher must be informed once movement is clear of Business Track (602) at IFG.

A dual-control derail is installed at the south end of IFG. This derail operates in conjunction with the dual-controlled main line switch. When operating the South IFG dual-controlled switch by hand, it is also necessary to operate the derail by hand.

The practice of mounting and dismounting moving equipment on Track 201 within the International Freight Gateway ("IFG") facility is prohibited.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	HEAVENER SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuos Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Pittsburg		Mile Post Location				
0128	CTC	CTC	0.0	(Pittsburg Sub) PITTSBURG # Pittsburg South	128.2 128.8	Both MT's MP 128.8 – MP 129.7	YARD	CQ 173.32- 174.65	142.2 144.0 151.0 158.75 163.6 164.3 164.7 169.8 174.1 183.8 190.1 195.5 197.6 205.6 218.4 226.7 238.0 247.2
			1.5	SEK JCT	129.7				
0134			5.7	# EMPIRE	133.9		Coal Loop		
			6.5						
0140			12.2	# Asbury North ASBURY # Asbury South	139.4 140.4 141.4		9,438		
			13.9						
0155			26.1	# Joplin North JOPLIN # Joplin South	153.0 154.3 154.6		7,959		
			0.5						
			26.6	MNA RRX	154.8				
			0.3						
			26.9	MNA CONN	155.1				
			4.9						
0160			31.8	SAGINAW	160.0				
			10.1						
0170			41.9	# Dalby North DALBY # Dalby South	169.0 170.1 170.8		9,124		
			2.6						
			44.5	BNSF RRX	172.7				
			1.4						
0174			45.9	NEOSHO	174.1				
			6.7						
0181			52.6	# McElhany North McELHANY (CP 181) # McElhany South	179.1 180.8 182.6		17,642		
			19.9						
0201			72.5	# Noel North NOEL # Noel South	200.4 200.7 202.1		8,537		
			13.5						
0215			86.0	# Dorsey North DORSEY # Dorsey South	213.3 214.2 215.1		8,705		
			2.8						
0217			88.8	DECATUR	217.0				
			5.5						
0222			94.3	# Gentry North GENTRY # Gentry South	221.3 222.5 222.9		7,867		
			1.2						
0224			95.5	# FLINT CREEK	223.7		Coal Loop		
			5.6						
0229			101.1	# Siloam Springs North SILOAM SPRINGS # Siloam Springs South	228.6 229.3 230.2		8,084		
			6.7						
0236			107.8	# Watts North WATTS # Watts South	234.3 236.0 236.8		12,273		
			8.4						
0244			116.2	# WESTVILLE	244.4				
		Continued on next page							

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	HEAVENER SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Pittsburg		Mile Post Location				
				13.8					
0258			130.0	# Stilwell North STILWELL # Stilwell South	257.0 258.2 258.6		7,794		
				10.7					
0268			140.7	# Cave Springs North CAVE SPRINGS # Cave Springs South	267.2 268.9 269.0		8,699		
				12.2					
0281			152.9	# Marble City North MARBLE CITY # Marble City South	280.5 281.1 282.2		8,333		
				9.3					
	A		162.2	UP RXX	290.4				
				0.7					
0291	B		162.9	# SALLISAW	291.1				
				8.1					
0299		CTC	171.0	# Gans North GANS # Gans South	298.4 299.2 300.1		8,144		
				12.5					
0312			183.5	# Spiro North SPIRO # Spiro South	311.4 311.7 313.6		10,668		301.9 305.3 308.3
				3.0					
0315			186.5	# BONANZA	314.7		Coal Loop		
				5.3					315.7
0320			191.8	# Shady Point North SHADY POINT # Shady Point South	319.2 320.0 320.8		7,661		
				6.4					
0326			198.2	POTEAU	326.4				
				7.4					331.4
0333	X		205.6	# Howe North HOWE # Howe South	333.0 333.8 334.7				
				4.2					
0338	W B C T		209.8	# Heavener North HEAVENER (Shreveport Sub)	336.7 338.0	Both MT's MP 336.7 – MP 338.0			

MAXIMUM SPEED	MPH
	59
Exceptions:	
MP 128.8 - MP 128.9 NO 1 (East) and NO 2 (West) MT's	HER 20
MP 128.9 – MP 130.2	HER 40
MP 145.5 – MP 147.4	50
MP 147.4 – MP 158.0	40
MP 158.0 – MP 164.5	50
MP 164.5 – MP 166.0	45
MP 166.0 – MP 168.5	30
MP 168.5 – MP 172.3	40
MP 172.3 – MP 177.5	25
MP 177.5 – MP 185.9	40
MP 185.9 – MP 186.1	30
MP 186.1 – MP 191.0	40
MP 191.0 – MP 192.4	30
MP 192.4 – MP 194.4	40

	MPH
MP 194.4 – MP 194.8	30
MP 194.8 – MP 195.9	40
MP 195.9 – MP 196.8	25
MP 196.8 – MP 210.0	30
MP 210.0 – MP 216.7	40
MP 216.7 – MP 217.1	30
MP 217.1 – MP 224.0	40
MP 224.0 – MP 226.1	30
MP 226.1 – MP 230.2	40
MP 230.2 – MP 234.3	35
MP 234.3 – MP 239.5	40
MP 239.5 – MP 240.0	30
MP 240.0 – MP 250.6	40
MP 250.6 – MP 256.2	35
MP 256.2 – MP 262.5	40
MP 262.5 – MP 264.0	30
MP 264.0 – MP 277.6	40

US Southern Region Timetable

	MPH
MP 277.6 – MP 278.6	30
MP 278.6 – MP 285.3	40
MP 285.3 – MP 285.6	30
MP 285.6 – MP 290.3	40
MP 290.3 – MP 290.4 over RRX	30
MP 290.4 – MP 301.0	40
MP 306.5 – MP 307.3	45
MP 316.9 – MP 317.3	55
MP 325.6 – MP 325.7	50
MP 331.7 – MP 336.3 NO 1 (East) and NO 2 (West) MT's	40
MP 336.3 – MP 338.4 NO 1 (East) MT	20
MP 336.3 – MP 336.9 NO 2 (West) MT	10
MP 336.9 – MP 338.4 NO 2 (West) MT HER 20	
All Switches and Sidings unless listed below	10

Turnouts and Sidings

Asbury, McElhany and CP 181 XO	40
Joplin, Dalby, Dorsey, Gans, Spiro, Cave Springs, North Howe Switch	30
Noel, Gentry, Siloam, Watts, and Stilwell, Marble City, Shady Point, and South Howe All Switches	25

Tons per Operative Brake

When maximum subdivision speed is over 45 MPH,
the maximum speed permitted will be determined by
the tons per operative brake.

Over 150	45
----------------	----

Radio Channels

	AAR	Dispr Call In
Pittsburg to North Shady Point		
Road	010-010	
Yard	063-063	
Disp.	016-010	1
Critical Incident Desk	016-010	3
North Shady Point to Heavener		
Road	078-078	
Yard	063-063	
Disp.	039-078	1
Critical Incident Desk	039-078	3
Emergency		911

TrAM Area

The Heavener Sub is TrAM Area 4.

Block System

Centralized Traffic Control (CTC) is in use between
Pittsburg and Heavener.

Main Track Designation

Two main tracks are in use at Pittsburg and between
Howe and Heavener.

Positive Train Control (PTC)

PTC is in effect on the Heavener Sub.

Yard Limits

North MP	South MP
128.2	Pittsburg MT 1 & 2129.7
336.7	Howe & Heavener MT 1 & 2338.0

Pittsburg Yard Limits

Within Yard Limits at Pittsburg, permission must be
obtained from the Train Dispatcher to enter the No. 1
and No. 2 Main Tracks. Upon clearing these main
tracks, they must be released back to the Train
Dispatcher.

Heavener Yard Limits

Within Yard Limits at Heavener, permission must be
obtained from the Yard Supervisor at Heavener to enter
the No. 1(East) and No. 2 (West) Main Tracks. Upon
clearing these main tracks, they must be released back
to the Yard Supervisor.

All main track switches within Heavener Yard Limits
may be left lined as last used.

Interlockings/Control Points

Automatic Interlocking Approach Locations:

(Main Track and Siding, if applicable)

- MNA RRX at MP 154.8
 - NWD Approach MP 158.3
 - SWD Approach MP 151.0
- BNSF RRX at MP 172.7
 - NWD Approach MP 176.2
 - SWD Approach MP 169.0
- UP RRX at MP 290.4
 - NWD Approach MP 296.7
 - SWD Approach: MP 286.5

Equipment Restrictions

Train Make-Up Restrictions

Between North Marble City MP 280 and Joplin MP 155,
when train tonnage exceeds 5,000 tons behind each
locomotive consist (including in train distributed
power), the first five (5) cars behind the locomotive
consist must weigh 50 tons or more provided train
contains 5 cars that weigh 50 tons or more. Two
consecutively loaded platforms of an articulated car are
to be considered the equivalent of one car weighing 50
tons.

Six Axle Locomotives Prohibited from Operating on The Following Tracks:

- Long Bell American – MP 157.5
- Linde Spur – MP 177.1
- Gentry-McKee Foods – MP 222.1
- Jet Stream Plastics – MP 230.0
- Soroco – MP 230.1
- Zone 44, Tracks 701, 702 and 703 (These
tracks are industries within Watts yard limits)
- HJ Baker (Zone 4, Track 702 in Westville,
OK – MP 244.85)
- Baron – MP 250.2 (Past road crossing)
- Bunch – MP 271.8
- Quarry Spur – MP 281.3

Continuous Quiet Zone – GCOR 5.8.4

Washington Ave	MP 173.32
College St.	MP 173.64
Spring St.	MP 174.33
McKinney St.	MP 174.65

US Southern Region Timetable

Electric Locks

Station	MP	Location of switch
SEK Jct.	129.7	SEK JCT
MNA Connection	155.0	MNA Connection
MNA Connection	157.5	Long Bell American
MNA Connection	158.2	Gulf States Paper
Saginaw	159.7	North Switch Saginaw
Saginaw	160.3	South Switch Saginaw
Neosho	173.8	North Switch Neosho
Neosho	174.3	South Switch Neosho
McElhany	177.1	Linde Spur
McElhany	178.3	North Missouri Sugars
McElhany	178.8	South Missouri Sugars
McElhany	180.7	Government Lead
McElhany	184.5	Goodman Spur
Noel	191.8	Fairview Mills
Noel	200.9	Noel Team (Gas Track)
Decatur	216.1	Simmons East Team
Decatur	217.0	North Switch Decatur
Decatur	217.5	South Switch Decatur
Gentry	222.1	Gentry-McKee Foods
Siloam	229.2	Siloam Springs NW Sdg
Siloam	230.0	Siloam Springs SW Sdg
Westville	240.7	North Feeder
Westville	241.6	South Feeder
Westville	243.9	North Westville
Westville	244.5	South Westville
Stilwell	255.8	Conner Industries
Sallisaw	291.1	UP Interchange Track
Poteau	325.6	Fort Smith Br. Jct.
Howe	333.1	Howe Storage N Switch
Howe	333.7	Howe Storage S Switch
Heavener	336.3	Mine Spur

Trackside Warning Detectors

Mile post	Type of Detector	Call Back
142.2	DED	#88
144.0	HBD/DED/Oversized Load (C) (N)	
151.0	HBD/DED (C) (S)	
158.75	High Water	
163.6	High Water	
164.3	HBD/DED (C) (N) & (S)	
164.4	High Water	#88
164.7	High Water	
165.11	High Water	
169.8	High Water	#88
174.1	HBD/DED (C) (N)	
183.8	HBD/DED	
190.1	High Water	#88
195.5	HBD/DED	
197.6	DED	
205.6	HBD/DED/Oversized Load (C) (S)	#88
218.4	HBD/DED (C) (N)	
226.7	HBD/DED (C) (S)	
238.0	HBD/DED (C) (N)	
247.2	HBD/DED/Oversized Load (C) (S)	
262.1	HBD/DED/Oversized Load (C) (N)	
275.1	HBD/DED (C) (S)	

Mile post	Type of Detector	Call Back
284.4	HBD/DED/Oversized Load (C) (N) & (S)	#88
301.9	HBD/DED (C) (N)	
305.3	DED	
308.3	DED	
315.7	HBD/DED	
331.4	HBD/DED/Oversized Load (C) (S)	

FRA Excepted Track

FRA Excepted Track from MP 3.1 to MP 4.0.

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
Kelso	N	129.4	370
Empire District Electric	S	133.9	IND
Asbury Team Track	S	139.5	775
Joplin Team Track	S	154.4	1,000
Dalby Team TrackN		170.7	1,200
BNSF Interchange	N	173.2	2,900
N Missouri Sugars Team Track	S	178.5	505
S Missouri Sugars Team Track	N	178.7	505
N Ozark Wood Switch	S	180.6	2,366
S Ozark Wood Switch	N	181.2	2,366
SWEPCO-AEP Flint Creek	S	223.7	IND
Siloam Springs Ramp Track	N	229.1	785
Jet Stream Plastics	S	230.0	2,091
Soroco	S	230.1	2,091
N Switch Watts	S	236.0	3,000
Watts Yard	N	236.7	
Baron	N	250.2	1,050
707 Stilwell	S	258.0	900
Bunch	N	271.8	700
N SW Marble City Storage	S	280.7	2,403
S SW Marble City Storage	N	281.2	2,403
Quarry Spur	N	281.3	6,600
UP Interchange 023	S	290.6	4,350
Gans Team Tracks		299.2	510
Spiro/Emerson	S	311.5	2,715
Spiro/Emerson	N	312.0	2,715
AES/Bonanza	S	315.7	IND
Waldron Industrial Spur	S	338.2	CONN

General Information

Heavener

A dual control derail on the south lead at Heavener yard is located 345 feet north of the No. 1 (East) main switch and operates in conjunction with the No. 1 (East) main track. When operating the No. 1 (East) main switch by hand, it will also be necessary to operate the derail by hand.

Empire

An interlocked dual-controlled derail is installed at the clearance point of Empire. This derail operates in conjunction with the dual-controlled switch operated by the train dispatcher. When operating the Empire dual-controlled switch by hand, it is also necessary to operate the derail by hand.

Train crews operating empty coal trains will perform a Class IA air brake test prior to departure.

Joplin

Northward trains encountering a STOP indication at the MNA automatic interlocking, MP 154.8 will also receive a dark signal at the south siding switch at Joplin until the engine occupies the MNA interlocking limits.

Simmons Industry

A) Cars must not be left between the main track switch and the switch point derail, which is located 554 feet from the main track switch.

B) Crew members are prohibited from riding equipment within the dumper room.

Flint Creek

A power operated switch point derail is installed at the clearance point of the Flint Creek Spur. This derail operates in conjunction with the dual-controlled Flint Creek Spur switch operated by the train dispatcher. When operating the Flint Creek dual-controlled switch by hand, it is also necessary to operate the derail by hand.

Train crews operating empty coal trains will perform a Class IA air brake test prior to departure.

Footing At 253.2 and 263.6

Train crews are prohibited from walking on the right of way at the following locations:

- MP 253.2 - East side of main track
- MP 263.6 - East side of main track

Sallisaw

The interlocking signals at the UP crossing are also designated as a control point. When a crew encounters a STOP signal at this location and fails to receive a proceed indication after following instructions in the release box, authority must be received from the train dispatcher before proceeding except when operating within the limits of track and time.

Waldron Industrial Spur (MP 0.0 To MP 4.0)

All movements must be made per Rule 6.28 not to exceed 10 MPH on all tracks. MP 4.0 begins Arkansas Southern Railroad.

OK Feed

1. Riding on the sides of engines or cars while entering or moving through the dumper facility is prohibited. Train crews must remain inside the locomotive cab.
2. Speed through the dumper room and over the scales is restricted to 5 MPH.

Heavy Grades

Avg. Grade	Between	Descending
1.31%	MP 177.7 – MP 174.3	NWD
1.32%	MP 184.5 – MP 188.3	SWD
1.42%	MP 206.2 – MP 209.8	NWD
1.29%	MP 209.9 – MP 212.6	SWD
1.43%	MP 219.1 – MP 215.3	NWD
1.36%	MP 230.3 – MP 233.6	SWD

Grade Conditions

Due to grade conditions, the train dispatcher must ascertain the exact location of the preceding train and determine that the preceding train has passed the milepost location listed below before issuing authority to the following train per GCOR 9.12.1.

Following trains

Stilwell North
Westville South
Siloam Springs South
McElhany South
McElhany North

Preceding trains

MP 250
MP 250
MP 234(N Watts)
MP 192
MP 174

The train dispatcher will not issue provisions of General Code of Operating Rule 9.12.1 to a train or locomotive for movement between South Joplin and North Dalby if a track light is indicated on his console and there is evidence of heavy rain in the area.

The train dispatcher may authorize a train to move the minimum distance required in order to clear public crossings at grade at the above locations.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	EASTWARD ↑	FORT SMITH BRANCH STATION PAGE # Denotes Control Point Or Manual Interlocking	WESTWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Fort Smith		Mile Post Location				
6356	G	YL	0.0	(End of Line) FORT SMITH (Via A&M to MP 6.0)	0.0 F	MP 412.0 – MP 422.5 (Via A&M)			
				0.9					
	S	TWC	0.9	FSR RRX	0.9 F				
				19.6					
6336			20.5	CAMERON	20.5 F				
				7.2					
0326			27.7	POTEAU (Heavener Sub)	27.7 F				

MAXIMUM SPEED	MPH
	25
Exceptions:	
MP 11.7 F – MP 11.9 F	10
MP 27.0 F – MP 27.7 F	10
All Switches and Sidings	10

Radio Channels

	AAR	Dispr Call In
Road	078-078	
Yard	063-063	
Disp.	039-078	1
Critical Incident Desk	039-078	3

TrAM Area

The Fort Smith Branch is TrAM Area 1.

Movement Authority

Track Warrant Control (TWC) is in use between MP 6.0 F and Poteau.

Yard Limits

East MP	West MP
412.0	VIA A&M 422.5

Equipment Restrictions

Six Axle Locomotives Prohibited from Operating on The Following Tracks:

- All Tracks

Gross Weight

Cars with a gross weight more than 132 tons must not be handled on the Fort Smith Branch.

Cars delivering in interchange to the Fort Smith Railroad must not exceed 131 tons. Cars consigned to Planters Corporation are exempt from these restrictions.

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
Cameron Team	E	20.0 F	1,585

General Information

Fort Smith Operation Via The A&M Railway

Trains must secure track warrants and track bulletins from the A&M Dispatcher at (479) 751-1281.

OK Feed

1. Riding on the sides of engines or cars while entering or moving through the dumper facility is prohibited. Train crews must remain inside the locomotive cab.
2. Speed through the dumper room and over the scales is restricted to 5 MPH.

Milepost Equalization

CPKC MP 6.0 F and A&M MP 422.5 are the same location.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	SHREVEPORT SUBDIVISION STATION PAGE # DENOTES CONTROL POINT OR MANUAL INTERLOCKING	SOUTHWARD ↓	Yard Limits	Siding Length	Continuos Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location	
			Distance From Heavener		Mile Post Location					
0338		YL	0.0	(Heavener Sub) HEAVENER # Heavener South	338.5 338.5		12,257		339.6 347.9	
				16.2	# Page North PAGE # Page South				353.9 354.7 356.4	
0355		CTC	16.2	12.6 # Rich Mountain North RICH MOUNTAIN # Rich Mountain South	366.1 367.3 368.0				363.8	
				12.5 MENA	379.8					
0367			28.8	6.5 # Potter North POTTER # Potter South	385.6 386.3 387.0				374.8	
				15.5					383.5 384.1 384.7	
0380			41.3	# Vandervoort North VANDERVOORT # Vandervoort South	400.2 401.8 402.0				396.4	
				3.2 HATTON # Hatton South	405.0 405.0					
0386			47.8	3.8 # Wickes North WICKES # Wickes South	408.4 408.8 410.8				406.5 406.5	
				12.5						
0402			63.3	82.8	# Gillham North GILLHAM # Gillham South				420.4 421.3 422.2	425.0
				94.4	11.6 D&E CONN # D&E Conn				432.9 433.0	
0405	B T		66.5	0.2 # DeQueen North DEQUEEN # DeQueen South	431.6 433.1 433.1				7,477	
	A			0.7 D&E RRX	433.8					
				4.4						
0438	W		99.7	# Wade North WADE # Wade South	438.0 438.2 440.4				11,906	
				11.1						
0450			110.8	# Winthrop North WINTHROP # Winthrop South	447.6 449.3 449.7				10,797	
				13.7						
0464			124.5	# Wilton North WILTON # Wilton South	462.3 463.0 463.8				7,372	
	A			4.6						
			129.1	# KRR RRX	467.6					
				2.6						
0469	B T W		131.7	# Ashdown North ASHDOWN # Ashdown South	468.0 470.2 470.1				10,459	
				16.7						
				Continued next page						

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	SHREVEPORT SUBDIVISION STATION PAGE # DENOTES CONTROL POINT OR MANUAL INTERLOCKING	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location			
			Distance From Mexico Depot		Mile Post Location							
0488	W	CTC	148.4	# Trigg Street North # Trigg Street South TEXARKANA	484.7 486.8 486.9		9,997	490.9				
	A			0.5								
			148.9	TNER RRX	487.4							
				0.1								
			149.0	UP RRX	487.5							
				1.9								
0494	A		150.9	UP RRX	489.4							
				3.4								
			154.3	# Jury North Jury # Jury South	491.0 492.8 493.5		12,444					
				10.0								
			164.3	CASS	502.8							
0518				14.0								
			178.3	# Sandra North SANDRA # Sandra South	515.8 516.8 517.5		7,740					
				13.0								
0533			191.3	SHORELINE (Shreveport Terminal Sub)	529.8						523.3	

MPH	
MAXIMUM SPEED	
59	
Exceptions:	
MP 338.4 – MP 338.5	20
MP 338.5 – MP 345.2	40
MP 345.2 – MP 345.9	30
MP 345.9 – MP 402.2	40
MP 402.2 – MP 402.7	30
MP 402.7 – MP 407.1	40
MP 407.1 – MP 408.2	30
MP 408.2 – MP 415.6	40
MP 415.6 – MP 428.0	30
MP 428.0 – MP 433.8	40
MP 433.8 – MP 443.0	40
MP 467.6 over RRX	40
MP 467.7 – MP 470.9	50
MP 486.9 – MP 487.3	40
MP 487.3 – MP 487.6 over RRX	30
MP 487.6 – MP 489.4	40
MP 497.1 – MP 497.7	40
All Switches and Sidings unless listed below	
Through Turnouts and on Sidings	
South Heavener switch only.....	25
Potter, Wickes, Gillham, DeQueen, Wade, Winthrop, Wilton, Ashdown, Texarkana, Jury & Sandra	25
Page, Rich Mountain, Vandervoort	30
Page Siding Only	
RRX MP 354.3–MP 354.7	HER 20

Tons per Operative Brake

When maximum subdivision speed is over 45 MPH, the maximum speed permitted will be determined by the tons per operative brake.
Over 15045 MPH

Radio Channels

	AAR	Dispr Call In
Road	078-078	
Yard	063-063	
Disp.	039-078	1
Critical Incident Desk	039-078	3

TrAM Area

The Shreveport Sub is:
TrAM Area 1 between MP 440.0 and MP 529.1.
TrAM Area 4 between MP 338.0 and MP 440.0.

Block System

Centralized Traffic Control (CTC) is in use between Heavener and Shoreline.

Positive Train Control (PTC)

PTC is in effect on the Shreveport Sub.

US Southern Region Timetable

Interlockings/Control Points

Automatic Interlocking Approach Location (Main Track and Siding, if applicable):

- D&E RRX at MP 433.8
NWD Approach: MP 438.0
SWD Approach: MP 428.8
- KRR RRX at MP 467.6
NWD Approach: MP 473.3
SWD Approach: MP 463.8
- TNER RRX at MP 487.4
NWD Approach: MP 491.0
SWD Approach: MP 483.4
- UP RRX at MP 487.5
NWD Approach: MP 491.0
SWD Approach: MP 483.4
- UP RRX at MP 489.4
NWD Approach: MP 494.1
SWD Approach: MP 486.7

Ashdown

1. The interlocking signals at the KCSR/KRR crossing at MP 467.6 are also designated as a control point. When a crew encounters a STOP signal at this location and fails to receive a proceed indication after following instructions in the release box, authority must be received from the train dispatcher before proceeding, except when operating within the limits of track and time.
2. KRR trains and engines must obtain track and time from the CPKC train dispatcher before entering the main track.

Equipment Restrictions

Train Make-Up Restrictions

Between North DeQueen MP 431 and Heavener MP 338, when train tonnage exceeds 5,000 tons behind each locomotive consist (including in train distributed power), the first five (5) cars behind the locomotive consist must weigh 50 tons or more provided train contains 5 cars that weigh 50 tons or more. Two consecutively loaded platforms of an articulated car are to be considered the equivalent of one car weighing 50 tons.

Six Axle Locomotives Prohibited from Operating on The Following Tracks:

- Hatfield Lumber Co. at MP 391.6.

Movement over Public Crossings

Automatic Warning Devices Used Infrequently:

- MP 401.8 – Port Arthur Avenue
(Team Track only)
- MP 462.79 – AR 234 – Douglas Street
(Team Track only)
- MP 487.2 – Douglas Street
(when switching Miller Bowie)

Continuous Quiet Zone – GCOR 5.8.4

Forest Lake Dr.....MP 481.8
Lake Ridge Dr.MP 482.2

Electric Locks

Station	MP	Location of switch
Hartfield	391.4	North Hartfield Switch
Hartfield	391.9	South Hartfield Switch
Hatton	404.7	Hatton North Leg Wye
Wade	438.3	Crossover
KRR RRX	467.7	KRR Conn
Ashdown	467.8	N. House Track
Ashdown	468.1	S. House Track
Ashdown	469.2	N. West Track
Ashdown	470.1	N. Crossover
Ashdown	470.8	S. Lead Switch
TNER RRX	487.2	S. Yard Lead
TNER RRX	487.3	TNER Conn
S. Texarkana N Crossover	499.0	N. Crossover
S. Texarkana S Crossover	499.0	S. Crossover
S. Texarkana South SW	499.3	Yard

Trackside Warning Detectors

Mile Post	Type of Detector	Call Back
339.6	DED	#88
347.9	HBD/DED/Oversized Load (C) (N)	
363.8	HBD/DED	
374.8	HBD/DED	
383.5	High Water	
384.1	HBD/DED	
384.7	High Water	
396.4	HBD/DED	
406.3	High Water	
406.5	HBD/DED	
425.0	HBD/DED	
440.5	HBD/DED	
459.4	HBD/DED	
474.5	HBD/DED	
476.3	DED	
479.1	DED	
490.9	HBD/DED/Oversized Load (C) (N) (S)	
496.5	DED	
498.5	DED	
505.5	HBD/DED/Oversized Load (C) (N)	
523.3	HBD/DED	

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
North Page Team +	S	354.6	641
South Page Team +	N	354.8	641
Rich Mountain Team +	N	367.4	1,147
Olsen	S	382.6	1,635
Potter Team +	N	386.7	1,572
North Hatfield Switch	S	391.4	1619
Hatfield Lumber +	S	391.6	564
South Hatfield Switch	N	391.9	1,619
North Vandervoort Team +	S	401.4	1,429
South Vandervoort Team +	N	401.8	1,429

US Southern Region Timetable

Name	DOE	MP	Footage
Hatton North Leg Wye	S	404.7	748
Hatton South Leg Wye	N	405.0	793
Wickes Team +	N	408.8	372
North Gillham Team +	S	421.2	866
DeQueen 005 +	S	431.8	Yard
DeQueen 001 +	N	432.9	Yard
North DeQueen XO +		432.9	XO
DeQueen House Track	N	433.5	581
Wade North Set Out Switch +	S	438.2	1,708
Wade XO MT to Set Out ++	S	438.3	XO
Wade South Set Out Switch +	N	438.6	1,708
Winthrop South Spur +	N	449.6	1,082
Wilton Team +	N	463.2	2,081
Ashdown-KRR Connection	N	467.7	Conn
Ashdown-N House Trk Sw	S	467.8	981
Ashdown-S House Trk Sw	N	468.1	981
Ashdown Nashville Bridge (ASSR) +	N	468.1	Conn
Ashdown-N Compress Sw	S	468.1	1,293
Ashdown-S Compress Sw	N	468.4	1,293
Ashdown North 002 E	S	469.2	3,947
Ashdown North 003 ++	S	469.3	3,717
Ashdown South 003 ++	S	469.5	2,051
Ashdown-S West Track Sw	N	470.0	3,717
Ashdown South 001 +	N	470.0	2,051
North Ashdown XO	S	470.1	XO
South Ashdown XO	N	470.1	XO
Ashdown North Leg Wye ++	S	470.2	1,077
South Tail Setout	S	470.4	210
Ashdown South Leg Wye ++	N	470.5	1,276
South Lead Switch	N	470.8	3,993
Ogden		473.3	
Commercial Storage +	N	485.6	646
Texarkana XO Siding to Yard	S	486.4	XO
Texarkana Yard Lead 704 +	N	487.1	Yard
Texarkana S Yd Lead Sw	N	487.2	Yard
UP TNER Conn	S	487.3	Conn
Texarkana Stock Pen N Sw	S	487.9	1,550
Texarkana Stock Pen S Sw	N	488.3	1,550
Jury Team +	N	491.1	1,335
South Texarkana North XO	S	499.0	Yard
South Texarkana South XO	N	499.3	Yard
Bloomburg	N	507.5	706
Sandra Team +	S	517.1	831
+ Indicates Connected to Siding			
++ Indicates Connected to Business Track			

General Information

Page - Mena

The sighting of fire between Page and Mena must be reported immediately to the train dispatcher.

Hatfield

Between North and South Switches Pass Track, a switch point derail has been installed 341 feet north of the south switch.

Hatton

Train crews must have the automatic brakes cut in and operative on all cars when switching the rock plants at Hatton. Cars stored or spotted for loading must be left with the air brakes applied, wheels chocked, and sufficient hand brakes applied to prevent movement.

A dual control switch has been installed on the main track MP 405 for entrance to south leg of the wye. A power switch point derail has been installed approximately 300 ft. from the dual control switch on the south leg of the wye and operates in conjunction with the dual control main track switch. When permission is received to operate the dual control switch by hand, it will also be necessary to operate the switch point derail by hand.

When picking up cars, hand brakes will not be released until after Air Brake Test is completed.

Before departing Hatton Rock plant:

- If train contains less than 50% MWAX type equipment make a minimum automatic brake reduction, release hand brakes, and move train WITHOUT releasing minimum set.
- If train contains at least 50% MWAX type equipment, move train with automatic brake released. Use dynamic or automatic brake applications as necessary to control train.

When taking a Distributed Power train into the plant, crews must end distributed power on both ends before leaving the train at Hatton.

Milepost Equalization - MP 442 TO MP 443

There are 2.1 miles between MP 442 and MP 443.

Texarkana

For movement onto the UP main track, the crew must obtain authority or track and time from the UP dispatcher at Omaha, NE, telephone (800) 762-0742 or (402) 636-1602 or radio frequency 027-027. The Texarkana Yardmaster can be contacted at (903) 798-2871 from 06:00 to 18:00 or the Longview Yardmaster at (903) 238-2872 from 18:00 to 06:00 or radio frequency 061-061 *71.

Grade Conditions

Due to grade conditions, the train dispatcher must ascertain the exact location of the preceding train and determine that the preceding train has passed the milepost location listed below before issuing authority to the following train per GCOR 9.12.1.

Following trains	Preceding trains
Rich Mountain	South MP 377
Rich Mountain	North MP 356 (South Page)
Page	North MP 345

The train dispatcher will not issue provisions of General Code of Operating Rule 9.12.1 to a train or locomotive for movement between South Rich Mountain and North Potter, or South Vandervoort and North Wickes, if a track light is indicated on his console and there is evidence of heavy rain in the area.

The train dispatcher may authorize a train to move the minimum distance required to clear public crossings at grade at the above locations.

Heavy Grade

MP 352.8 – MP 349.1 NWD Avg. Grade 1.46%
 MP 367.4 – MP 358.7 NWD Avg. Grade 1.50%
 MP 367.4 – MP 374.1 SWD Avg. Grade 1.24%

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation		NORTHWARD ↑	SHREVEPORT TERMINAL SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
0533		CTC		0.0	(Shreveport Sub) # Shoreline North SHORELINE # Shoreline South	529.8 531.8 532.3		12,581		534.8 543.9
				15.7	15.7					
0549		CTC WEST	CTC EAST	15.7	BLANCHARD # Blanchard North	547.5 547.6				
					1.5					
0549				17.2	# TEXAS JCT.	549.0				
					West 2.8/East 1.1					
0550				18.3	# CP 550 (East MT)	550.1				
					1.7					
0552	X			20.0	# NORTH SHREVEPORT	551.8				
					1.6					
0554	C B T	MT	MT	21.6	SHREVEPORT YARD	553.4				
					0.1					
	X	CTC HOLLYWOOD	CTC HOLLYWOOD	21.7	# SOUTH SHREVEPORT	553.5	MP 553.6 to MP 554.7			
					1.2					
				22.9	# CP 554	554.7				
					2.3					
				25.2	HARRIET ST. YARD	557.0				
					0.8					
	X			26.0	# TEXAS AVE.	557.8				
					1.0					
	T			27.0	# SOUTH WYE (Control Point MT 1 Only)	558.8				
					0.1					
	X			27.1	# WILKINSON	558.9				
					2.0					
		#2 MT		29.1	HOLLYWOOD	560.8				
		#1 MT								
					2.6					
	A	CTC	CTC	31.7	# CEDAR GROVE (UP RRX)	563.5				
					0.5					
				32.2	SLACK INDUSTRIAL PARK	564.0				
					1.6					
0567				33.8	FORBING	565.6				
					9.6					
0577				43.4	FRIESON # Frieson North #Frieson South (Beaumont Sub)	575.2 575.3 577.0		8,213		567.6

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	WESTWARD ↑	SHREVEPORT TERMINAL SUBDIVISION STATION PAGE NO. 1 & NO 2 MAIN TRACKS # Denotes Control Point Or Manual Interlocking	EASTWARD ↓	Yard Limits	Siding Length	Continuos Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Harriet St. Yard		Mile Post Location				
		YL	0.0	HARRIET ST. YARD (Begin NO 1 MT)	557.4	MP 557.4 to MP 558.2			
		2 MT CTC		0.5					
			X	0.5	# TEXAS AVE.	V-170.0			
					1.2				
			X	1.7	# WILSONS ALLEY	V-168.8			
					0.7				
			A	2.4	# SPRING ST. JCT. (UP RRX)	V-168.1			
		CTC			0.4				
				2.8	# WEST BOSSIER	V-167.7			
					0.4				
				3.2	# LRN CONN	V-167.3			
					0.8				
			0562	4.0	BOSSIER YARD	V-166.5			
					0.2				
				4.2	UP RRX	V-166.3			
					2.9				
			1011	7.1	# Fosters West FOSTERS # Fosters East	V-163.6 V-163.4 V-161.7	9,251		

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	SHREVEPORT TERMINAL SUBDIVISION STATION PAGE NO. 3 MT # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuos Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Shoreline		Mile Post Location				
		CTC	27.0	# SOUTH WYE	L-558.5				560.0
				0.3					
			27.3	# CP 558 (UP RABBIT)	L-558.8				
				0.7					
			X	30.0	# WILSONS ALLEY	L-559.5			
					0.5				
				30.5	SILVER LAKE	L-560.0			
				1.2					
				31.7	# RED JCT.	L-561.2			

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	SHREVEPORT TERMINAL SUBDIVISION STATION PAGE BLANCHARD WYE # DENOTES CONTROL POINT OR MANUAL INTERLOCKING	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From North Wye		Mile Post Location				
		CTC	0.0	NORTH LEG TEXAS WYE	Y-548.3				
				0.4					
			0.4	WEST LEG TEXAS WYE	Y-548.7				

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	UP SHREVEPORT SUBDIVISION STATION PAGE # DENOTES CONTROL POINT OR MANUAL INTERLOCKING	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From		Mile Post Location				
Operation via UP – Red Jct. (L-561.2) to L&A Jct. (B-105.1) (North Little Rock Area Timetable, Shreveport Subdivision)									

MAXIMUM SPEED **MPH**
59

Exceptions:

MP 563.5 – MP 563.6	40
East MT MP 547.5 – MP 547.6	30
East MT MP 547.6 – MP 553.5	40
West MT MP 549.2 – MP 553.5	40
Hollywood No 2 MP 553.6 – MP 560.9	40
Hollywood No 1 MP 553.5 – MP 554.9	30
Hollywood No 1 MP 554.9 – MP 560.9	40
MP 557.4 (Shell Rd.) – V-169.9 MT 1	15
MP 558.4 Hollywood 1 & 2–MP 558.9 (Rat Hole) .	30
MP 560.9 – MP 571.7	50
MP 571.7 – MP 572.1	45
MP 572.1 – MP 575.3	50
MP L-558.5 – MP 558.8 No 3 MT.....	10
MP L-558.8 – MP 559.6 No 3 MT.....	20
MP 559.6 – MP 559.9 No 3 MT.....	10
MP L-559.9 – MP 561.2 No 3 MT.....	20
MP V-170.0 – MP V-169.9 No 1 & 2 MT	30
MP V-169.9 No 1 MT	15
MP V-168.0 – MP V-166.5	30
MP V-166.5 – MP V-166.0	HER 30
MP Y-548.3 – MP V-548.7	20

All Switches and Sidings unless listed below 10

Through Turnouts and on Sidings

Shoreline both ends and siding.....	25
North Blanchard End 2 MT.....	25
North Leg Texas Wye West MT Switch.....	25
Texas Junction All switches double XO	30

MPH

CP 550 (East MT) Switch.....	25
North Shreveport East and West Main Switch	25
South Shreveport East and West Main Switch....	40
CP 554 all switches.....	25
CP 556 in and out of Harriet Street	15
Texas Ave all switches.....	30
CP 558 (UP Rabbit) No 3 MT.....	25
Wilsons Alley MP L-559.5 & MP V168.8	
all switches.....	25
North & South Portland Ave XO both ends	15
Spring St Jct. Jct. #1 & #2 (Turnout to MT No 1).25	
West Bossier MT switch.....	30
LRN Connection.....	25
East Bossier MT switch.....	30
Fosters both ends and siding	30
Hollywood Jct. HW 1& HW2 turnout MT No 1	40
Frierson both ends and siding	25
LRN Connection MT switch.....	25
West Leg Texas Wye MT switch	25
Zone 1 Tracks 190-198 including turnout and	
crossover	15
Zone 1 Tracks 1-30 including turnout and	
crossover	15
Zone 1 Tracks 33-35 including turnout.....	15
Zone 1 Tracks 44-47 including turnout.....	15
Zero Track, Long 1, 3, 4 ,6& 7 and also North and	
South Long leads	15
N Switching Lead MP 550.2 and MP 551.9.....	25
S Switching Lead MP 553.8 and CP 554	30

US Southern Region Timetable

MPH

Harriet Street Yard

Tracks 1, 4, 5 and the lead tracks
at N & S Harriet St.....15

Tons per Operative Brake

When maximum subdivision speed is over 45 MPH,
the maximum speed permitted will be determined by
the tons per operative brake.

Over 150 45

Radio Channels

	AAR	Dispr Call In
Road CTC Territory	076-076	
Yardmaster	050-050	
Yard Switching	063-063	
Disp.	047-076	1
Critical Incident Desk	047-076	3

TrAM Area

The Shreveport Terminal is TrAM Area 1.

Block System

Shreveport Terminal

Centralized Traffic Control (CTC) is in use between
Shoreline and Blanchard. Blanchard to Hollywood is
double MT CTC and Hollywood to Frierson.

No 1 & No 2 MT

Centralized Traffic Control (CTC) is in use between
Texas Ave to Spring St Jct. and is double MT.
Centralized Traffic Control (CTC) is in use between
West Bossier to Fosters and is single MT.

No 3 MT

Centralized Traffic Control (CTC) is in use between
South Wye and Red Jct.

Blanchard Wye

Centralized Traffic Control (CTC) is in use between
North Leg Texas Wye and West Leg Texas Wye.

Texas Wye Main (CP Texas Jct. – Turnout Leg)

Centralized Traffic Control (CTC) is in use.

Main Track Designation

Two main tracks are in use at Pittsburg and between
Howe and Heavener.

Positive Train Control (PTC)

PTC is in effect on the Shreveport Terminal Sub.

Yard Limits

North MP	South MP
554.7 Hollywood No 1	558.2
West MP	East MP
V170.7..... Harriett St Yd.....	V170.0

Interlockings/Control Points

Automatic Interlocking Approach Location:

(Main Track and Siding, if applicable)

- Cedar Grove UP RRX at MP 563.5
NWD Approach: 569.3.
SWD Approach: 560.3
- UP RRX at MP 561.9 (Alexandria Sub.)
SWD Approach: V-167.7
- Spring Street at MP V-168.1
WWD Approach: V-166.3.
WWD Approach: LRN Track V-167.3
EWD Approach: (Hollywood 1 & 2 MT)
556.2.
EWD Approach: (No. 3 MT) L-559.0
- Bossier UP RRX at MP V-166.3
WWD Approach: V-163.5.
EWD Approach: V-168.5.
- EWD Approach: Siding V-166.6

Spring Street Junction UP Interlocking

The interlocking signals at the CPKCR/UPRR crossing
at MP V-168.1 are also designated as a Control Point.
When a crew encounters a STOP signal at this location
and fails to receive a proceed indication, after following
the instructions in the release box, authority must be
received from the Train Dispatcher before proceeding,
except when operating within limits of Track and Time.
Eastward trains must contact the control operator
before operating the release box to ascertain that train
is not stopped for the purpose of meeting or being
passed by another train.

Cedar Grove UP Interlocking

The interlocking signals at the CPKCR/UPRR crossing
at MP 563.5 are also designated as a Control Point.
When a crew encounter a STOP signal at this location
and fails to receive a proceed indication after following
the instructions in the release box, authority must be
received from the Train Dispatcher before proceeding,
except when operating within the limits of Track and
Time.

Equipment Restrictions

Harriett Street Yard:

Loaded bulk commodity trains and Intermodal trains
are only allowed on tracks 1, 4 and 5.

Only MW equipment is allowed in track 10.

Trains, engines, and all on track equipment must obtain
permission from the dispatcher to occupy all tracks at
Harriet Street Yard and the Shell Road extension.

Bossier Yard

When handling a loaded rail train, as a unit or in a
manifest train, it must not use Tracks 4, 5, 6, 7 or 8.

US Southern Region Timetable

Six Axle Locomotives Prohibited from Operating on All Industry Tracks:

EXCEPT:

- 700(A) and 701(B) at Superior Tie and Timber
- Slack Industrial – Madden Rock Track
- Silverlake
- Forbing
- Benton & Brown
- Rail Plant Tracks
- Co-op Lead
- Hope Industrial Lead B-Line MP B-105.1 – MP B-103.0

Movement over Public Crossings

Crossings At Grade

Cedar Grove Industrial Lead - St. Vincent - Linwood

Manually operated traffic light. A member of the crew must operate key boxes to the “Stop” position before the crossing is occupied, and “Start” when movement over the crossing is completed. If the system fails to display a red aspect for vehicular movement, a flagman must protect movement over the crossing.

Automatic Warning Devices Infrequently Used:

- MP 551.9 – North Lakeshore Dr

Electric Locks

Station	MP	Location of switch
Sup. Tie & Timber	530.0	N Sup Tie & Timber
Sup. Tie & Timber	530.4	S Sup Tie & Timber
Brian-UOP	544.9	Brian-UOP
Harriet Street Yd.	557.4	S Harriet St Yd. Lead
Cedar Grove	561.1	North Cedar Grove
Cedar Grove	561.9	South Cedar Grove
Cedar Grove	563.0	Blount Brothers
Slack Ind. Park	563.6	N Madden Rock Trk
Slack Ind. Park	565.2	S Madden Rock Trk
UP Yard Conn	V-169.4	UP Yard Conn

Trackside Warning Detectors

Mile Post	Type of Detector	Call Back
534.8	HBD/HW/DED	#88
543.9	HBD/DED/Oversized Load	
567.6	HBD/DED/Oversized Load	
L-560.0	DED/Oversized Load	

MECHANICAL INSPECTION SYSTEM

Type	Milepost
Wheel Impact/Hunting Truck/ Imbalanced Load	536.0

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
North Superior Tie & Timber	S	530.0	1,487
South Superior Tie & Timber	N	530.4	1,487
Oil City	S	535.8	1,400
Brian – UOP	S	544.9	IND
Blanchard Team	N	548.1	150
North Leg Texas Wye (W MT)		548.3	
Shreveport Industrial Park ++	S	551.1	IND
Coop Lead	S	551.9	LEAD
North Run Around Track ++	S	551.9	
CP 556 (Hollywood 1 & 2)		556.3	CP
North Harriet St 001	S	556.3	YARD
South Harriet St 001	N	557.4	YARD
North Portland Ave XO	S	557.4	XO
South Portland Ave XO E	N	557.4	XO
North Cedar Grove	S	561.1	3,576
Cedar Grove Industry Lead++	S	561.1	LEAD
South Cedar Grove	N	561.9	3,576
North Madden Rock Track	S	563.6	7,358
Ryerson ++	N	565.2	IND
South Madden Rock Track	N	565.2	7,358
North Forbing	S	565.4	1,883
South Forbing	N	565.8	1,883
Frierson Team Track +	S	576.2	250
UP Yard Connection	W	V-169.4	CONN
UP Riverfront Yard Lead	E	V-168.1	Lead
Halliburton Spur +	E	V-163.4	800
Baroid +	W	V-163.1	750
East Bossier		V-166.5	
Hope Industrial Lead	N	B-105.1	IND
North Hinkle	S	B-104.2	2,785
South Hinkle	N	B-104.8	2,785
Benton & Brown	N	B-103.8	IND

+ Indicates Connected to Siding

++ Indicates Connected to Business Track

Switch Information

Switching Signals at North and South Shreveport Yard

Before the train dispatcher may line the crossover from the switching lead to the East main at North Shreveport or the crossover at South Shreveport for movement through the crossover, or set any switching signal to a Stop indication, the dispatcher must contact the Shreveport Terminal Yardmaster. The Shreveport Terminal Yardmaster must verify that no train or switching job is using the signal and/or that they will remain clear of the signal.

North Shreveport Yard

The signals at the North end of Shreveport yard that govern movement southward from the tail track and northward from the run around and long lead, with the exception of the signal governing movement through the crossover from the long lead at North Shreveport, will be referred to as ‘switching signals. If the switching signal is displaying a restricting indication, the train or switch job has permission to use the signals for movement in the control point.

However, the crossover at North Shreveport must not be used in hand throw position without authority on the East Main. Trains and switch jobs have permission to change directions within the limits of the control point at North Shreveport between the switching signals if the crossover is not used. If the switching signal is displaying a STOP indication, ensure the switch from the run around is lined for your desired move, and if signal still displays a STOP indication, trains and switch crews must contact the Shreveport Terminal Yardmaster for instructions. However, if the control point is occupied by its own standing train or cut of cars, the train or switch job may, after stopping, pass the switching signal displaying STOP indication without contacting the Shreveport Terminal Yardmaster.

North Lead 29 Switch is close clearance on the west side of the North 30 Lead.

The North switching lead between CP 550 (MP 550.2) and MP 551.9 is 20 MPH.

A Switch Point Indicator has been installed at the Shreveport Industrial Switch, MP 551.1 on the Tail Track. The switch point indicator as defined by GCOR Rule 8.10 will indicate the switch positions as follows:

GREEN light will indicate switch points fit properly in normal position.

YELLOW light will indicate switch points fit properly in reverse position.

RED or DARK light will indicate stop and inspect switch.

South Shreveport Yard

The signals at the South end of Shreveport yard that govern movement northward from Hollywood 1 and southward from zero track, with the exception of the signal governing movement through the crossover from zero track at South Shreveport, will be referred to as 'switching signals. If the switching signal is displaying a restricting indication, the train or switch job has permission to use the signals for movement in the control point. However, the dual control switch at the crossover must not be used in hand throw position without authority on Hollywood 2. Trains and switch jobs have permission to change directions within the limits of the control point at South Shreveport between the switching signals if the crossover switch is not used. If the switching signal is displaying a STOP indication, trains and switch crews must contact the Shreveport Terminal Yardmaster for instructions. However, if the control point is occupied by its own standing train or cut of cars, the train or switch job may, after stopping, pass the switching signal displaying STOP indication without contacting the Shreveport Terminal Yardmaster.

CP 556 (Hollywood 1)

A dual control derail is installed on the north industry track. This derail operates in conjunction with the main line switch. When operating the dual control switch by hand, it is also necessary to operate the split point derail by hand.

Harriet Street Yard

DTMF Yard Switches are installed on both ends of Harriet Street Yard. When entering the North or South End of Harriet Street yard, it will be necessary to operate the DTMF yard switches.

North Lead Track switch code: normal switch DTMF #556311 – reverse DTMF # 556322.

South Lead Track switch code: normal switch DTMF #557211 – reverse DTMF #557222.

The switch point indicator will indicate the following:

Green - normal position (Lead to Lead)

Yellow - reverse position (Lead to L 1)

Red - in transition or out of correspondence

NOTE: There is a 50 ft. to 100 ft. circuit at these switches that must not be fouled until the switch is lined for intended movement.

Tracks 1, 4, 5 and the lead tracks at north and south Harriett Street are 15 MPH.

Spring Switches:

- **L&A Junction, MPB-105.1:**

NWD movement leave lined as last used.

SWD movement should line switch for UP main track and trail through.

- **Louisiana Junction, MPL-561.7:**

Leave lined as last used.

Power Assisted Switches (PAS):

Alliance Jct.

Radio Channel 010-010

Normal DTMF #580411 Reverse DTMF #580422

General Information

Track Bulletins:

- **Yard trains** – If required, verify Track Bulletins with Shreveport Terminal Yardmaster when going on duty.
- **Road Trains** - If required, verify Track Bulletins with the train dispatcher.

Universal Oil Products MP 544.9

Train crews working Universal Oil Products (UOP) at Brian, LA must wear approved hardhat while working inside the UOP facility.

Cedar Grove Yard

Trains, engines, and all on track equipment must obtain permission from the dispatcher to occupy Cedar Grove Yard.

Departure Instructions Shreveport Yard

Trains, engines, and all on track equipment ready to depart Shreveport Yard must obtain permission from the Shreveport Terminal Yardmaster before departing.

- If train or part of train received a Class I Air Brake Test at Shreveport Yard, crew must ascertain if a Roll-By release of air brakes system is required on departure.

Permission To Occupy Tracks Shreveport Terminal

Hollywood 1 553.5 – 554.7 must not be occupied without permission from the Shreveport Terminal Yardmaster.

Trains, Engines and All on Track Equipment Departing Shreveport Yard To:

- Alexandria, Beaumont, Hope Industrial Lead or Vicksburg Subdivisions or Other Yards and Industries: Must obtain verbal permission to proceed to CTC from train dispatcher before departing Shreveport Yard. Following receipt of authority to enter CTC, contact the Shreveport Terminal Yardmaster for permission to proceed to CTC.

NOTE: Trains, engines, and all on track equipment en route to Alexandria Subdivision must not depart Red Junction until after they have been issued a Track Warrant.

- **Shreveport And Greenville Subdivisions:** Must obtain verbal permission to proceed to CTC at North Shreveport (Main Track Specific) from Train Dispatcher prior to departing Shreveport Yard. Following receipt of authority to enter CTC, contact the Shreveport Terminal Yardmaster for permission to proceed to CTC.

Trains, Engines And All On-Track Equipment Entering Shreveport Yard From:

- **Beaumont Subdivision And Cedar Grove Industrial Areas:** Must contact Shreveport Terminal Yardmaster before departing Texas Avenue.
- **Shreveport And Greenville Subdivision:** Must contact Shreveport Terminal Yardmaster before departing Texas Junction. All southbound trains must clear CP North Shreveport before changing crews unless authorized by the yardmaster or train dispatcher.
- **Shreveport Terminal CTC Limits On #1, #2 and #3 Main Tracks:** Must contact Shreveport Terminal yardmaster prior to arriving Texas Ave.
- **Hope Industrial Lead And Alexandria Subdivisions:** Before departing L&A Junction or Curtis, crew member must contact the train dispatcher for permission to proceed. If using Red Junction, the crew must contact UP Hollywood Yardmaster (077-077) for permission to use UP trackage between Red Junction and L&A Junction. If delays are encountered notify the train dispatcher.

Operation Via Up For Movement Between Red Junction And L&A Junction

CPKC movement using UP tracks between Red Junction and L&A Junction are governed by the CPKC General Code of Operating Rules and current UP Timetable.

Prior to entering UP trackage between Red Junction and L&A Junction, crews must:

1. Secure UP track Warrant for bulletins.
2. Contact UP Yardmaster (Channel 077-077, phone 318-632-6640)
3. Verify any track bulletin changes that would affect the trains movement as outlined in Rule 6.2.

Employees who receive a UP track warrant listing track bulletins only (or "None" on line 16) must contact the UP-Train Dispatcher (channel 082-082, press *(star) 57 to tone train dispatcher, phone 1-800-726-1106) if:

- Incorrect/incomplete limits are listed on the "From" or "To" locations of the address
- or
- The "OK" time is more than 4 hours old. (More than 4 hours before the time the track warrant was received)

Operation Of Foreign Line Trains Over CPKC Main Tracks

All Foreign Line Trains must obtain authority from the CPKC train dispatcher before entering the CPKC Main Track at Spring Street, CP 558, or Red Junction.

Trains Moving In And Out Of Shreveport Yard

Between MP 551 and MP 553.7, Loaded Bulk Commodity Trains are allowed to only operate over East and West MT unless authorized by the Shreveport Terminal Superintendent and the Roadmaster. All yard tracks will be used for Loaded Bulk Commodity Trains only on an exception basis.

Trains operating on the east and west main tracks between MP 552.1 and 553.5 should ring engine bell continuously.

Shreveport Diesel Shop

Mechanical Department power operated derails are in service on the following tracks north and south of the Diesel Shop.

- On north run-around approximately 1,900 feet north of register room.
- On south run-around at RIP No. 456 switch.

These power operated derails are equipped with blue lights. All locomotives and/or train movements will not pass the above derail locations unless permission has been received from the diesel shop foreman to move beyond the derail.

Outbound locomotives from the diesel shop cannot be moved until permission has been received from the diesel shop foreman.

Inbound locomotives for the diesel shop must call for permission from the diesel shop foreman.

Switch 475 at MP 552.4 is Out of Service.

Crew members will place locomotive consist on track designated by the diesel shop foreman.

Run-around track must be left lined for run-around when not in use.

Train and Enginemen do not get on or off moving equipment while inside the north and south derail.

Car Shop

Close clearance east side of Track 147.

Shreveport Yard Complex Entrances

Entrance gates are numbered as follows:

- Gate number 1 is the General Office Building/Training Center.
- Gate number 2 is the Diesel Shop, Annex Building, Signal area.
- Gate number 3 is the Car Shop, Wheel Shop, Storeroom, Paint Shop area.
- Gate number 4 is the Trans-Serve area.
- Gate number 5 is the Yard Office and Transportation area.
- Gate number 6 is on North Lakeshore.
- Gate number 7 is the CPKC Transport, Maintenance of Way, Signal, and Transportation area.
- Isolation gate is on North Lakeshore Drive access to north end of yard.

NOTE: All gates must remain closed when not in use.

Emergency Instructions

When calling emergency vehicles to the Shreveport Yard complex, the following outline should be used to help expedite their arrival:

1. Call 911 immediately and remain calm.
2. Identify yourself (name) and that you are at CPKC (Canadian Pacific Kansas City Railway), Shreveport Yard, 4601 Hilry Huckaby III Avenue, Louisiana Highway 173, Shreveport, Louisiana.
3. Give reason for call - Injured person(s); burned, heart attack, injury, fire(s) - oil, gas, chemical, etc., explosion(s) - chemical leak(s) - or other.
4. Give gate number with the most direct access to the emergency. If direct access is blocked give next easiest access gate number.
5. Give location of emergency. Example: General Office - second floor, or Diesel Shop - south end, or near north shanty north end of yard, etc.
6. Dispatch person(s) to the given gate to direct the emergency vehicle to the crisis. If more than one response vehicle is expected, dispatched person(s) should stay at gate until all emergency vehicles arrive. If available, more than one person may be needed to perform the task of directing vehicles through yard to crisis.
7. Report incident to all necessary railway supervisors and civilian authorities as stated in rule book.

Reporting Delays

All road and yard crews going on duty in Shreveport Terminal (Shreveport Yard, Harriet St., Bossier Yards) must report the status of their crew to the Tower no later than five (5) minutes after their on-duty time. Yard crews must report to the Shreveport Terminal Yardmaster through the intercom (talkbacks) or on the telephone at ext. 6539. Road crews must report in by telephone on ext. 6031 or use ext. 6539 as an alternate. Crews should make every attempt to immediately secure their train documents at call time. Should they not have their required train documents after being on duty for twenty-five (25) minutes, they are again required to report to the tower in the manner outlined above.

In addition, road crews departing the diesel shop facilities must notify the Shreveport Terminal Yardmaster of any delays encountered commencing from call time.

All yard crews (including Bossier local crews) must contact the Shreveport Terminal Yardmaster prior to tie-up. If any crew is unable to complete their assigned work order before the expiration of the hours of service, they must make arrangements with the Shreveport Terminal Yardmaster to have work order completed.

Remote Operations

Shreveport Terminal has been established as a Remote-Control Operating Area.

A Remote-Control Zone is established on the north end of Shreveport Yard on the north switching lead between the one (1) track switch extending northward to the clearance point of the run around track. This zone is identified as "RCZ 1".

A Remote-Control Zone is established on the north end of Shreveport Yard on the north switching lead between the clearance point of the run around track extending northward to CP 550. This zone is identified as RCZ 2.

Shreveport Terminal Automated Classification Yard

The group of tracks numbered 1 through 30 within Shreveport Yard is designated as bowl tracks. Tracks 1-12 must be secured with two hand brakes and Tracks 13-30 must be secured with three hand brakes, preferably on the 'leave behind' cars.

Crews must 'leave behind' the required cars unless directed by the Shreveport Terminal Yardmaster. On the North switching lead, DO NOT cut off cars in motion while in the painted area designated as a "NO Cut Zone".

Milepost Equalization:


• **North Leg Texas Wye (West Main):** MP 548.3 on the Shreveport Terminal Subdivision and MP Y-548.3 on the Shreveport Terminal Subdivision are the same location.

• **West Leg Texas Wye:** 0.7 on the Greenville Subdivision and MP Y-548.7 on the Shreveport Terminal Subdivision are the same location.


• **Texas JCT:** The southbound signal entering West Main off the Greenville Subdivision at MP 0.08 is the official Shreveport Terminal – Greenville Subdivision boundary.

Note: Any bulletins requested from the switch point to the clearance point within the Texas Jct. turnout in Shreveport Terminal must be defined from MP 0.08 to MP 0.0 (0.08 is the south bound signal entering West Main off the Greenville Subdivision; 0.0 is the switch point).


Shreveport Terminal Map 1




Shreveport Terminal Map 2




Shreveport Terminal Map 3




Shreveport Terminal Map 4



Shreveport Terminal Map 5



Shreveport Terminal Map 6



---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	WESTWARD ↑	GREENVILLE SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	EASTWARD ↓	Yard Limits	Siding Length	Continuos Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Alliance Jct.		Mile Post Location				
		YL	0.0	(Dallas/Alliance Sub) # ALLIANCE JCT.	201.9	MP 201.9 - MP 197.9		CQ MP 201.5 to MP 199.4	
				3.1					
9201	B C		3.1	WYLIE YARD	198.8				
				1.0					
		CTC	4.1	# CP 198	197.8				195.3
				5.8					
9192			9.9	# Copeville West COPEVILLE # Copeville East	192.3 192.0 190.3		10,237		
				6.7					
9185			16.6	FARMERSVILLE	185.3				
				2.4					
			19.0	# MARTIN MARIETTA	182.9				
				11.3					
9172			30.3	# Greenville West GREENVILLE # Greenville East	172.6 171.6 171.4		6,448		
				0.4					
	I		30.7	# DGNO Connection DGNO	171.2 171.3				
				1.0					
	A		31.7	# BLACKLANDS RRX (CP 170)	170.2				
				22.4					
9148			54.1	# Brashear West BRASHEAR # Brashear East	149.0 147.8 146.9		10,635		
				7.5					
9140	B C		61.6	SULPHUR SPRINGS	140.3				
				4.1					
9136			65.7	# TUGCO	136.2				
				5.5					
9131			71.2	# Como West COMO # Como East	131.1 130.7 128.9		11,215		
				13.0					
9118			84.2	WINNSBORO	117.7				
				12.3					
9105			96.5	# Leesburg West LEESBURG # Leesburg East	107.0 105.4 105.1		9,471		
				3.4					
9101			99.9	# Monticello West MONTICELLO # Monticello East	102.4 102.0 101.0				
				3.7					
9098	A		103.6	PITTSBURG (UP RRX)	98.3				
				7.9					
9090			111.5	WELSH	90.4				
				1.6					
9089			113.1	# Cason West CASON # Cason East	89.3 88.8 87.8		7,072		
				Continued on next page					

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	WESTWARD ↑	GREENVILLE SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	EASTWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Alliance Jct.		Mile Post Location				
		CTC		10.4				CQ	85.1
9079			123.5	VEALS	78.4			MP 82.5 to MP 82.1	
				1.1					
9076	B C		124.6	# Hughes Springs West HUGHES SPRINGS # Hughes Springs East	78.5 77.3 76.3		11,465		74.2 73.2 71.4 64.7
				16.2					
9061			140.8	# Lassater West LASSATER # Lassater East	61.6 61.1 60.0		7,847		
				10.9					
	A		151.7	UP RRX	50.2				52.5
				0.9					
9049			152.6	JEFFERSON	49.3				
				13.7					
9035			166.3	# Fox West FOX # Fox East	36.4 35.6 34.8/16.5		8,267		41.7
				13.8					
9004			180.1	# Hammock West HAMMOCK # Hammock East	4.4 3.5 2.6		9,025		9.7
				2.8					
	T		182.9	WEST LEG TEXAS WYE	0.7				
				0.7					
9000			183.6	TEXAS JCT. (Shreveport Terminal Sub)	0.08				

MAXIMUM SPEED	MPH
Exceptions:	59
MP 201.9 – MP 197.9	20
MP 191.9 – MP 191.6	50
MP 185.3 – MP 185.2	20
MP 171.0 – MP 170.5	HER 40
MP 170.5 – MP 170.0	20
MP 170.0 – MP 168.5	55
MP 143.4 – MP 143.2	50
MP 142.5 – MP 141.3	HER 50
MP 141.3 – MP 139.0	HER 40
MP 139.0 – MP 129.0	50
MP 123.0 – MP 118.9	50
MP 118.9 – MP 118.5	45
MP 118.5 – MP 116.0	50
MP 105.8 – MP 105.2	50
MP 105.2 – MP 104.9	45
MP 98.9 – MP 98.2	20
MP 94.8 – MP 94.7	50
MP 88.3 – MP 88.2	40
MP 88.2 – MP 86.3	50
MP 86.3 – MP 83.0	40
MP 83.0 – MP 82.8	45
MP 82.8 – MP 82.5	40

	MPH
MP 82.5 – MP 81.5	50
MP 81.5 – MP 81.0	40
MP 81.0 – MP 71.0	50
MP 71.0 – MP 70.2	45
MP 70.2 – MP 69.2	50
MP 69.2 – MP 68.3	45
MP 68.3 – MP 63.6	50
MP 63.6 – MP 59.6	45
MP 59.6 – MP 50.5	50
MP 50.5 – MP 48.7	25
MP 48.7 – MP 35.0	50
MP 0.3 – MP 0.08	30
Wylie Intermodal Yard	
All switches and tracks.....	20
Sulphur Springs	
All switches and tracks.....	5
All Switches and Sidings unless listed below	10
Through Turnouts and on Sidings	
Copeville, Greenville, Brashear, Como,	
Leesburg, Cason, Lassater, Fox, Hammock	25
West Leg Texas Wye switch only.....	25
Martin Marietta, Hughes Springs.....	15

US Southern Region Timetable

Tons per Operative Brake

When maximum subdivision speed is over 45 MPH, the maximum speed permitted will be determined by the tons per operative brake.

150 tons or greater..... 45

Radio Channels

	AAR	Dispr Call In
Road	010-010	
Yard	050-050	
Disp.	016-010	1
Critical Incident Desk	016-010	3

TrAM Area

The Greenville Sub is TrAM Area 3.

Block System

Centralized Traffic Control (CTC) is in use between CP 198 and Texas Jct.

Positive Train Control (PTC)

PTC is in effect on the Greenville Sub.

Interlockings/Control Points

Automatic Interlocking Approach Location:

(Main Track and Siding, if applicable)

- DGNO at MP 171.2
WWD Approach: MP 167.0.
EWD Approach: MP 176.8
- Blacklands at MP 170.2
WWD Approach: MP 167.0.
EWD Approach: MP 173.3
- UP RRX at MP 98.3
WWD Approach: MP 94.2.
EWD Approach: MP 102.4
- UP RRX at MP 50.2
WWD Approach: MP 44.8.
EWD Approach: MP 55.2

Equipment Restrictions

Six Axle Locomotives Prohibited From Operating On The Following Tracks:

- Baldwin E&W MP 41.5 – MP 42.0
- Burford Wood Yard MP 52.0
- Burford Business Track E&W MP 52.0
- Faker E&W MP 95.5
- Pittsburg Pocket MP 98.2
- Pickton MP 126.1
- Cumby MP 154.5
- Campbell MP 161.2

Movement over Public Crossings

Sulphur Springs

Train and engine movements on House Track and Berry Track at Oak Avenue, Sulphur Springs, Texas, MP 140.3 will not activate the flashers and gates. A member of the crew must protect the crossing by operating the lever inside the box mounted on the side of the crossing bungalow at this location to the ON position. After entire movement has been made through crossing the lever must be returned to the OFF position.

Train and engine movements on West Team Track (i.e., Syrup Plant at League Street, Sulphur Springs, TX, MP 141.05, DOT 331-643J), will not activate the flashers and gates. A member of the crew must protect the crossing by operating the switch inside the box mounted on the side of the crossing bungalow at this location to the ON position. After entire movement has been made through crossing the lever must be returned to the OFF position.

Automatic Warning Devices Infrequently Used:

- MP 98.5 – Texas Street (Tracks 737 and 840 only)
- MP 112.0 – FM 1448 (Getty Oil Spur only)
- MP 125.7 – CR 2417 (Siding only)
- MP 161.0 – FM 513 (Siding only)
- MP 185.5 – Main Street (Siding only)

Continuous Quiet Zone – GCOR 5.8.4

Oak St.....	MP 201.5
Marble St.....	MP 201.4
FM 3412, Brown St	MP 201.3
FM 2514, Ballard Ave	MP 201.1
RD 389, Eubanks Ln	MP 200.0
Spring Creek Prkwy	MP 199.5
High Oaks Yard Crossing	MP 199.4
Nichols St.....	MP 82.1
Webb St	MP 82.5

Electric Locks

Station	MP	Location of switch
Farmersville	185.9	West Farmersville
Farmersville	185.3	East Farmersville
DGNO	171.3	DGNO 106/East Yard Lead Greenville
Campbell	160.9	Campbell
Sulphur Springs	140.4	West House Track
Sulphur Springs	140.1	East House Track
Sulphur Springs	140.1	Boomer Lead
WePac	138.8	WePac
South Pilgrims Pride	99.7	South Pilgrims Pride
Tiger-Atlas Roofing	81.5	Tiger-Atlas Roofing
Burford	52.4	Burford West Switch
Burford	52.0	Burford East Switch
Norboard	51.1	Norboard
Baldwin	42.0	Baldwin West Switch
Baldwin	41.5	Baldwin East Switch

US Southern Region Timetable

Trackside Warning Detectors

Mile Post	Type of Detector	Call Back
195.3	HBD/DED	#88
180.4	HBD/DED	
175.25	High Water	#88
169.2	High Water	
163.3	HBD/DED	
150.8	HBD/DED	
134.8	HBD/DED	
122.1	HBD/DED	
111.2	HBD/DED	
102.2	HBD/DED	
94.2	DED	
92.8	High Water	
91.8	DED	#88
90.8	DED (Welsh Spur)	
86.94	High Water	#88
85.1	HBD/DED	
74.2	HBD/DED	#88
73.2	High Water	
71.4	High Water	#88
64.7	HBD/DED	
52.5	HBD/DED	
41.7	HBD/DED	
9.7	HBD/DED	

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
North Texas Waterworks			
Plant 1 & 2	E	200.9	1,500
West Lead Wylie Yard	E	200.9	4,328
North Texas Waterworks			
Plant 3 +	W	200.3	6,000
North Texas Waterworks			
Plant 4 +	W	200.1	1,500
West West Lead XO	E	200.1	XO
East West Lead XO	W	200.0	XO
Northwest Lead Wylie Yard	E	200.0	LEAD
Central Lead Wylie Yard	E	199.6	LEAD
West Lavon Pass	E	199.4	5,150
East Lavon Pass	W	198.4	5,150
East Wylie Yard	W	198.2	YARD
East Lead Wylie Yard	W	198.1	2,672
Receiving/Departure Track			
Lead	W	198.1	2,351
West Farmersville	E	185.9	2,650
East Farmersville	W	185.3	2,650
Martin Marietta	W	182.9	IND
Floyd Pocket	W	178.3	200
North Texas Transload 721++	W	172.2	IND
North Texas Transload 719++	W	172.2	IND
North Texas Transload Lead	W	172.2	IND
East DGNO Yard Lead E	W	171.3	2,800
West DGNO Connection	E	171.1	CONN
East DGNO Connection	W	171.2	CONN
Compress	W	169.7	800
Campbell	W	160.9	1,800
CP 161		160.8	

Name	DOE	MP	Footage
Cumby	E	154.5	250
Westway	E	141.1	453
West House Track	E	140.4	942
Martin Fertilizer ++	E	140.4	IND
East House Track	W	140.1	942
Boomer Lead	W	140.1	4,556
Hollywood Spur	W	139.3	3,126
WePac	W	138.8	LEAD
Pickton	E	126.1	1,100
Esser	W	116.2	1,000
Tidewater W Leg of Wye	E	112.1	WYE
Newsome	E	107.7	500
West Monticello	E	102.4	6,767
East Monticello	W	101.0	6,767
South Pilgrims Pride	E	99.7	IND
West Pilgrims Pride 841	E	98.9	IND
East Pilgrims Pride 842 ++	W	98.6	IND
Pilgrims Pride 840 XO ++	E	98.6	XO
East Pilgrims Pride	W	98.5	IND
Pittsburg Pocket	W	98.1	600
West Faker	E	95.7	1,020
Faker Extension ++	W	95.6	700
East Faker	W	95.4	1,020
SWEPCO-AEP Welsh	W	90.6	IND
Cason Spur +	E	88.7	600
Tiger-Atlas Roofing	W	81.5	694
TN Conn +	E	78.3	CONN
West Pocket Track +	E	78.2	1,362
East Pocket Track +	W	77.9	1,362
West 407 +	E	77.4	863
East 407 +	W	77.2	863
West Hughes Spring Yd. 3 +	E	77.1	YARD
West Hughes Springs Yd. 4+	E	77.0	YARD
West Hughes Springs Yd. 5++E		77.0	YARD
West Hughes Springs Yd. 6++E		77.0	YARD
East Hughes Springs Yd. 6++W		76.4	YARD
East Hughes Springs Yd. 5++W		76.4	YARD
East Hughes Springs Yd. 4++W		76.4	YARD
East Hughes Springs Yd. 3 +	W	76.3	YARD
Pipe Yard	E	76.1	650
Lassater Spur +	W	60.9	653
Burford West Switch	E	52.4	1,893
Burford Team Track ++	W	52.0	IND
Burford Spur 701 ++	W	52.0	IND
Burford East Switch	W	52.0	1,893
Norboard	W	51.1	LEAD
T N T Spur	W	51.0	IND
Murray Spur	W	50.4	1,505
UP Interchange	E	50.3	CONN
Jefferson House Track	E	49.4	840
CP 48		47.9	
Baldwin West Switch	E	42.0	2,310
Baldwin Spur 702	E	42.0	772
Baldwin East Switch	W	41.5	2,310
Fox Spur +	E	36.4	1,167
Hammock Spur +	W	2.6	1,000

+ Indicates Connected to Siding

++ Indicates Connected to Business Track

US Southern Region Timetable

Switch Information

Alliance Junction

The normal position for the Alliance Jct. Switch is lined for the Alliance Subdivision and will display the following aspects when moving EWD and WWD:

GREEN - Lined properly for the Alliance Subdivision

YELLOW - Lined properly for the Dallas Subdivision

RED - STOP and inspect switch

Wylie

Main track switches may be left lined as last used.

The east lead yard track is connected to the east end of the Wylie Intermodal Terminal track.

When lining the switch(es) into or out of the Wylie Intermodal Terminal tracks, it will also be required to line the associated split rail derail in the non-derailing position.

Power Assisted Switches (PAS):

Alliance Jct.

Radio Channel 010-010

Normal DTMF #580411 Reverse DTMF #580422

General Information

Distributed Power

Other than unit trains, westbound trains in excess of 10,000 tons must have distributed power.

Greenville

1. If a red absolute signal is displayed at the DGNO Connection, at MP 171.2 the following will apply:

a. After authority is granted by the control operator to pass the stop indication, the train crew must wait 5 minutes 0 seconds then move by proper signal into the limits of the interlocking to insure the signals are at stop on the conflicting route.

b. After waiting 6 minutes 0 seconds and no conflicting movement is seen or heard, movement may proceed on proper signal to the switches. Before passing over the switches, the train must stop, and the employee must operate the switches by hand as outline in Rule 9.13.1 (Hand Operation of Dual Control Switches).

After at least one unit or car has passed over the switch points, the employee must return the switches to power unless otherwise instructed by the control operator.

c. When movement is seen or heard on conflicting route, proceed signal must not be given until such movement is stopped.

2. The interlocking signals at the CPKCR/Blackland RR crossing MP 170.2 are designated as control points. When a crew encounters a STOP signal at this location and fails to receive a proceed indication after following instructions in the release box, authority must be received from the train dispatcher before proceeding, except when operating within the limits of track and time.

Welsh Power Plant

Train crews operating empty coal trains will perform a Class IA air brake test prior to departing Hughes Springs If no extended haul brake slip is located in locomotive cab.

Note: An extended haul brake test is now required after coal train arrives Kansas City.

Baldwin

MW 093 or 095 are prohibited.

T&N Veals Yard

Prior to entering the T&N yard at Veals, you must obtain permission from the T&N yardmaster on radio channel TX66-RX66 between the hours of 06:00 and 18:00.

If you receive no answer via radio during these hours, contact the train dispatcher for further instructions.

All Tracks in the T&N yard will be restricted to 5 MPH.

Hughes Springs

A dual control derail has been installed on the East end of the siding. This derail operates in conjunction with the East dual control siding switch. When operating the East dual control switch by hand, it is also necessary to operate the derail by hand.

In addition, a hand operated split derail has been installed on the East lead at the clearance point of the siding. For proper signal and dual control switch operation at East Hughes Springs, the derail must be in the derailing position.

No loaded coal trains allowed on siding.

Measured Mile: MP 196 - 197 and MP 80 - 81.

Milepost Equalization:

• **East Fox:** MP 34.8 and MP 16.5 are the same location.

• **Alliance Junction:** MP C-580.4 on the Alliance Subdivision and MP201.9 on the Dallas and Greenville Subdivisions are the same location.

• **West Leg Texas Wye:** 0.7 on the Greenville Subdivision and MP Y-548.7 on the Shreveport Terminal Subdivision are the same location.

• **Texas Jct.:** The south bound signal entering West Main off the Greenville Subdivision at MP 0.08 is the official Shreveport Terminal-Greenville Subdivision boundary.

Note: Any bulletins requested from the switch point to the clearance point within the Texas Jct. turnout in Shreveport Terminal must be defined from MP 0.08 to MP 0.0 (0.08 is the south bound signal entering West Main off the Greenville Subdivision; 0.0 is the switch point).

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	WESTWARD ↑ Distance From Metro Jct.	ALLIANCE SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	EASTWARD ↓ Mile Post Location	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
9361	T	YL	0.0	(Greenville Sub) METRO JCT.	D-110.2	MP D-110.2			
			1.2	EAST METRO	D-109.0	MP D-109.0			
9357			4.5	DENTON	D-104.5				
			2.5						
9354			8.2	WSS Minchin MINCHIN ESS Minchin	D-102.8 D-102.0 D-102.0		3,654		
			11.1						
9343		TWC	19.3	WSS Lewisville LEWISVILLE ESS Lewisville	D-90.9 D-90.9 D-90.8			CQ MP D-96.2 to MP D-90.5	D-91.5
			15.9						
9328			35.2	WSS Cowley COWLEY ESS Cowley	D-76.1 D-75.0 D-74.9		5,580	CQ MP D-78.7 to MP D-74.9	
			1.5						
			36.7	WHITE ROCK JCT.	C-593.1				
			0.7						
			37.0	CP PARK	C-593.03				
BETWEEN CP PARK AND CP PLANO BE GOVERNED BY DART SILVER LINE TIMETABLE									
				CP PLANO	C-587.31				
			6.91						
9200		TWC	49.4	ALLIANCE JCT. (Alliance Sub)	C-580.4			CQ MP C-587.3 to MP C-580.9	
Operation via BNSF (Texas Division, Fort Worth Subdivision) Metro Jct. to Alliance									
Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	FORT WORTH SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location

	MPH	FRT	IMT
MAXIMUM SPEED	30	30	35
Exceptions:			
MP D-110.2 – MP D-109.0.....	20	20	
Loaded Bulk Commodity Train			
Entire Sub (except MP D-82.0 – MP D-89.0).....	25		
MP D-89.0 – MP D-82.0.....	10		
All Switches and Sidings			
unless listed below.....	10	10	
Through Turnouts and Sidings			
Alliance Jct.....	HER 25*	HER 25*	
*Indicates loaded bulk commodity trains – 10 MPH			

Radio Channels

	AAR	Dispr Call In
Road	010-010	
Yard	063-063	
Disp.	016-010	1
Critical Incident Desk	016-010	3

TrAM Area

The Alliance and Fort Worth Subs are TrAM Area 1.

Movement Authority

Track Warrant Control (TWC) is in use between East Metro and Alliance Jct.

US Southern Region Timetable

Yard Limits

West MP	East MP
D-110.2	D-109.0

Equipment Restrictions

Dynamic Braking

The use of Dynamic Braking is prohibited.

Six Axle Locomotives Prohibited From Operating On The Following Tracks:

- Tetra Pak-Union Camp MP D-105.4
- Dallas Morning News MP D-74.6

Movement over Public Crossings

Automated Horn

City	Street	MP
Murphy, TX	FM 2551	C-584.3
Murphy, TX	North Maxwell Creek Rd.	C-583.5

Continuous Quiet Zone – GCOR 5.8.4

Lewisville

Copper Canyon Rd	MP D-96.92
Orchid Hill Rd	MP D-96.73
Private Rd	MP D-95.55
Chinns Chapel Rd	MP D-95.05
FM 2499	MP D-94.40
Briar Hill Rd	MP D-93.53
Highland Village Rd	MP D-92.87
Garden Ridge Blvd	MP D-91.51
McGee Ln	MP D-90.99
Summit Ave	MP D-90.50

Cowley

Horizon North Dr	MP D-78.73
Dallas North Prkwy Ramp	MP D-78.65
Dallas North Prkwy	MP D-78.55
Ohio Dr	MP D-76.07
Coit Rd	MP D-74.90

White Rock Jct. – Alliance Jct.

Los Rios Blvd	MP C-586.95
Plano Prkwy	MP C-586.24
Park Vista Rd	MP C-585.40
FM 544	MP C-584.95
FM 2551, Murphy Rd	MP C-584.33
N. Maxwell Creek	MP C-583.72
McCreary Rd	MP C-583.20
Springwell Prkwy	MP C-582.70
FM 1378/Country Club	MP C-581.90
Westgate Way	MP C-580.95

Trackside Warning Detectors

Mile Post	Type of Detector	Call Back
D-91.5	HBD/DED	#88

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
Tetra Pak-Union Camp	E	D-105.4	11,000
84 Lumber	E&W	D-104.9	1,150
Denton	E&W	D-104.5	300
Ben E. Keith	W	D-104.5	500
Martin Brower	W	D-91.1	1,200
Lewisville	E&W	D-90.9	500
CP 85.5		D-85.5	
Dallas Morning News	W	D-74.6	960
Murphy		C-584.4	

Switch Information

Power Assisted Switches (PAS):

White Rock Jct.

Radio Channel 010-010
Normal DTMF #593111 Reverse DTMF #593122

Alliance Jct.

Radio Channel 010-010
Normal DTMF #580411 Reverse DTMF #580422

Spring Switch Location

West Cowley – MP D-76.1

General Information

Metro Jct.

All Westbound Trains arriving Metro Jct. must call BNSF Trainmaster on Channel 055 to report arrival time at Metro Jct.

White Rock Jct.

The normal position for the White Rock Jct. Switch is lined for the Alliance Subdivision and will display the following aspects when moving EWD and WWD:

GREEN - Lined properly for the Alliance Subdivision
YELLOW - Lined properly for the White Rock Branch
RED - Stop and Inspect Switch

Alliance Jct.

The normal position for the Alliance Jct. switch is lined for the Alliance Subdivision and will display the following aspects when moving EWD and WWD:

GREEN - Lined properly for the Alliance Subdivision
YELLOW - Lined properly for the Dallas Subdivision
RED - Stop and Inspect Switch

Milepost Equalization:

- MP C-593.1 corresponds to MP D-73.5 on the White Rock Branch
- MP C-580.4 corresponds to MP T-201.9 on the Dallas Subdivision

Measured Mile: C-581 - C-582

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	WESTWARD ↑	DALLAS SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	EASTWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Dallas Yd.		Mile Post Location				
	C B	YL	0.0	(End of Line) DALLAS YARD	T-220.0			CQ MP T-214.1 to MP T-202.1	
			5.4						
9215			5.4	DALLAS JCT	T-214.6				
			4.2						
		TWC	9.6	DGNO CONN	T-210.4	MP T-214.6			
			0.1			MP T-210.3			
9210			9.7	GARLAND	T-210.3				
			0.1						
	A		9.8	DGNO RRX	T-210.2				
			4.7						
9205			14.5	SACHSE	T-205.5				
			3.6						
			18.1	ALLIANCE JCT. (Alliance Sub)	T-201.9				

MAXIMUM SPEED **MPH 40**

Exceptions:

MP T-220.0 – MP T-214.6 (MT)	20
MP T-214.6 – MP T-210.3	20
MP T-202.3 – MP T-201.9	20
All Switches and Sidings	10

Radio Channels

	AAR	Dispr Call In
Road	010-010	
Yard	063-063	
Disp.	016-010	1
Critical Incident Desk	016-010	3

TrAM Area

The Dallas Sub is TrAM Area 3.

Movement Authority

Track Warrant Control (TWC) is in use between Garland and Alliance Jct.

Yard Limits

West MP	East MP
T-220.0	GCNO Connection
	T-210.3

Equipment Restrictions

Six Axle Locomotives Prohibited From Operating On The Following Tracks:

- Phibrotech MP T-209.7
- Dallas Yard MP 215.0 (past Plastic Can)

Continuous Quiet Zone – GCOR 5.8.4

Dallas Yard – Alliance Jct.

Shiloh Rd	MP T-214.12
Leon Rd	MP T-213.68
W. Kingsley Rd	MP T-213.48
Axe Dr	MP T-213.16
Devonwood Dr	MP T-212.42
Miller Rd	MP T-212.23
Ave F	MP T-211.21
Ave D	MP T-211.06
Ave B	MP T-210.90
Ave A	MP T-210.83
5th St	MP T-210.81
Main St	MP T-210.76
West State St	MP T-210.70
Walnut Rd	MP T-210.41
First St	MP T-210.21
Castle Dr	MP T-209.92
Buckingham Rd	MP T-209.38
Crist Rd	MP T-208.76
Naaman School Rd	MP T-208.17
Private Crossing	MP T-206.75
Murphy Rd	MP T-206.49
Ben Davis Rd	MP T-205.98
3rd St	MP T-205.72
5th St	MP T-205.59
Park Ln	MP T-205.17
Ranch Rd	MP T-204.34
Woodbridge Prkwy	MP T-203.88
Sanden Blvd	MP T-203.10
S. Westgate Way	MP T-202.60
Kirby St	MP T-202.15

**Other Tracks Not Shown as Stations
(Business Tracks)**

Name	DOE	MP	Footage
Reinhardt House Track	W&E	T-216.5	700
WSI	E	T-214.9	IND
Phibrotech Lead W	T-209.7	IND	
East Sachse		T-205.3	

Switch Information

Power Assisted Switches (PAS):

Alliance Jct.

Radio Channel 010-010

Normal DTMF #580411 Reverse DTMF #580422

General Information

Greenville - Dallas Jct.

All trains and engines en route to MP T-214.6 must not pass Naaman School Road, MP T-208.1, without permission from Wylie yard.

Alliance Jct.

The normal position for the Alliance Jct. switch is lined for the Alliance Subdivision and will display the following aspects when moving EWD and WWD:

GREEN - Lined properly for the Alliance Subdivision

YELLOW - Lined properly for the Dallas Subdivision

RED - Stop and Inspect Switch

Milepost Equalization:

- MP T-214.6 on the Dallas Subdivision corresponds to MP D-62.6 on the White Rock Branch Subdivision.
- MP T-201.9 on the Dallas and Greenville Subdivision corresponds to MP C-580.4 on the Alliance Subdivision.

Measured Mile: T-203 - T-204

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	WESTWARD ↑	WHITE ROCK BRANCH STATION PAGE # Denotes Control Point Or Manual Interlocking	EASTWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From White Rock Jct.		Mile Post Location				
		TWC	0.0	(Alliance Sub) WHITE ROCK JCT.	D-73.5				
			2.8						
9322			2.8	RICHARDSON	D-70.7				
9316			9.4	WHITE ROCK	D-64.1				
			10.9	1.5					
9215	B C		10.9	# DALLAS JCT. (Dallas Sub)	D-62.6				

MAXIMUM SPEED **MPH**
25

Exceptions:
All Switches and Sidings 10

Radio Channels

	AAR	Dispr Call In
Road	010-010	
Yard	050-050	
Disp.	016-010	1
Critical Incident Desk	016-010	3

TrAM Area

The White Rock Branch Sub is TrAM Area 1.

Movement Authority

Track Warrant Control is in use between White Rock Jct and Dallas Jct.

Equipment Restrictions

Six Axle Locomotives Prohibited from Operating on The Following Tracks:

- White Rock Industry Lead MP D-64.1
- Gaylord MP D-64.3
- DAP MP D-64.4
- Quaker MP D-64.5
- Northgate MP D-66.4

Movement over Public Crossings

Automated Horn

City	Street	MP
Richardson, TX	Custer Prkwy	D-72.05

Continuous Quiet Zone – GCOR 5.8.4

Lookout Dr	MP D-72.93
Custer Prkwy	MP D-72.05
Campbell Rd	MP D-71.68
S. 74, Arapahoe Rd	MP D-70.43
E. Spring Valley Rd	MP D-68.99

Continuous Quiet Zone – GCOR 5.8.4

Centennial Blvd	MP D-68.65
Buckingham Rd	MP D-68.39

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
Arapaho	W&E	D-70.1	600
Northgate	E	D-66.4	2,750
Quaker	E	D-64.5	1,960
DAP	E	D-64.4	1,910
Gaylord	E	D-64.3	1,860
White Rock Lead +	E	D-64.1	15,000
White Rock	W&E	D-64.1	837

+ Indicates Connected to Siding

Switch Information

Power Assisted Switches (PAS):

White Rock Jct.

Radio Channel 010-010

Normal DTMF #593111 Reverse DTMF #593122

General Information

White Rock Jct.

The normal position for the White Rock Jct. Switch is lined for the Alliance Subdivision and will display the following aspects when moving EWD and WWD:

GREEN - Lined properly for the Alliance Subdivision

YELLOW - Lined properly for the Dallas Sub, White Rock Branch

RED - Stop and Inspect Switch

Milepost Equalization:

- MP D-73.5 corresponds to MP C-593.1 on the Alliance Subdivision.
- MP D-62.6 corresponds to MP T-214.6 on the Dallas Subdivision.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	WESTWARD ↑	VICKSBURG SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	EASTWARD ↓	Yard Limits	Siding Length	Continuos Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Fosters		Mile Post Location				
1011		CTC	0.0	(Shreveport Terminal Sub) FOSTERS	161.7			CQ MP 72.58 through MP 66.19	155.3 151.9 138.4 125.1 107.1 97.0 84.2 74.4 64.3 47.1 30.4
			8.0						
1021			8.0	HAUGHTON	153.7				
				5.5					
5083			13.5	DOYLINE	148.2				
				6.8					
7083			20.3	# Sibley West SIBLEY # Sibley East	142.8 141.4 141.0		8,658		
				10.2					
1043			30.5	NELSON	131.2				
				4.0					
1047	A		34.5	# Gibsland West GIBSLAND # Gibsland East (L&NW RRX)	129.1 127.2 127.2		9,865		
				7.9					
1055			42.4	ARCADIA	119.3				
				0.5					
1057			42.9	MARTIN RESOURCES	118.8				
				7.3					
1063			50.2	# Simsboro West SIMSBORO # Simsboro East	113.2 111.5 108.4		24,882		
				5.7					
1072			55.9	RUSTON	102.8				
				7.4					
1079			63.3	CHOUDRANT	95.4				
				9.2			7,960		
1088			72.5	# Calhoun West CALHOUN # Calhoun East	87.6 86.2 86.0				
				10.4					
1100				82.9	# Fitzmorris West FITZMORRIS # Fitzmorris East		76.4 75.8 74.6		8,990
					3.8				
	A		86.7	QUACHITA RIVER BRIDGE	72.0				
				0.5					
1103	B C		87.2	MONROE	71.5				
				0.4					
	A		87.6	CP 71 (UP RRX)	71.1				
				4.8			20,059		
1107			92.4	# Magenta West MAGENTA # Magenta East	70.1 66.3 66.2				
				9.2					
1117			101.6	# Crew Lake West CREW LAKE # Crew Lake East	58.1 57.1 57.1		5,016		
					18.7				
1134			120.3	# Shannon West SHANNON # Shannon East	40.3 38.4 38.4		9,521		
				3.1					
1139			123.4	DELHI	35.3				
				Continued on next page					

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	WESTWARD ↑	VICKSBURG SUBDIVISION STATION PAGE # DENOTES CONTROL POINT OR MANUAL INTERLOCKING	EASTWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Fosters		Mile Post Location				
				20.2					12.9
1157		CTC	143.6	# Tallulah West TALLULAH # Tallulah East	16.8 15.1 15.1		8,766		
				14.3					
1173			157.9	# Bovay West BOVAY # Bovay East	2.4 0.8 0.7		8,609		2.5
				0.8					
1177	B C		158.7	VICKSBURG (Meridian Sub)	0.0				

MPH MAXIMUM SPEED 59

Exceptions:

MP 160.1 – MP 159.8	40
MP 127.2 – MP 127.1	40
MP 72.2 – MP 72.0	30
MP 72.0 – MP 68.0	40
MP 0.5 – MP 0.0	10
All Switches and Sidings unless listed below	10

Turnouts and Sidings

Sibley, Gibsland, Calhoun, Magenta, Shannon, Tallulah	25
CP 68 Crossover	25
Lansing Grain turnouts only	25
CP 110 Crossover	30
Simsboro, Fitzmorris, Bovay	30

Monroe

Zone 44 Tracks 1 – 6 including turnouts	15
---	----

Tons per Operative Brake

When maximum subdivision speed is over 45 MPH, the maximum speed permitted will be determined by the tons per operative brake.

100 or less	No Restriction
101 to 110	55
111 to 120	50
Over 120	45

Radio Channels

	AAR	Dispr Call In
Road	060-060	
Yard	007-007	
Disp.	086-060	1
Critical Incident Desk	086-060	3

TrAM Area

The Vicksburg Sub is TrAM Area 1.

Block System

Centralized Traffic Control (CTC) is in use between Fosters and Vicksburg.

Positive Train Control (PTC)

PTC is in effect on the Vicksburg Sub.

Interlockings/Control Points

Automatic Interlocking Approach Locations:

- (Main Track and Siding, if applicable)
- L&NW RRX at MP 127.2.
WWD Approach: MP 124.33.
EWD Approach: MP 129.67
 - Quachita River Bridge at MP 72.0.
WWD Approach: MP 67.39;
EWD Approach: MP 76.40
 - UP RRX at MP 71.1.
WWD Approach: MP 67.39;
EWD Approach: MP 76.40

Gibsland CPKC/L&NWRR Interlocking

The Interlocking signals at the CPKC/L&NWRR at MP 127.2 are also designated as a Control Point. When a crew encounter a STOP signal at this location and fails to receive a proceed indication after following the instructions in the release box, authority must be received from the Train Dispatcher before proceeding, except when operating within the limits of Track and Time.

Ouachita River Bridge MP 72.0 Automatic Interlocking Instructions

When a train or engine encounters a STOP indication at the bridge, it may proceed after a member of the crew has inspected the moveable span bridge and determined that the rails are aligned properly and that the rails are supported at each end of the turn span.

Control Point 71 MP 71.1/Up Interlocking MP 71.1

The interlocking signals at CP 71/UP interlocking are also designated as a control point. When a crew encounters a STOP signal at this location and fails to receive a proceed indication after following instructions in the release box, authority must be received from the train dispatcher before proceeding, except when operating within the limits of track and time.

US Southern Region Timetable

Equipment Restrictions

Six Axle Locomotives Prohibited From Operating On The Following Tracks:

- Gibsland Yard Tracks 2, 3, 5
- MDR Lead and MDR Main Track
- Monroe Roundhouse – MP 71.3
- Old Monroe Yard – MP 71.2
- UPRR South Interchange – MP 71.1
- All Industry/Business tracks, except:
 - o Sibley Branch-Minden Subdivision – MP 141.4
 - o Doyline – MP 148.2
 - o Blazer Construction Spur – MP 111.9
 - o Century Ready Mix – MP 76.8
 - o Lansing Grain – MP 36.94 and MP 36.61
 - o Bunge Spur – MP 14.9
 - o Bunge Spur – Levee St. Vicksburg

Monroe Yard – Six axle locomotives are allowed on tracks 3 and 6, but only the east 500 feet of tracks 1, 2, 4 and 5.

Movement over Public Crossings

Automatic Warning Devices Used Infrequently:

- MP 153.7 – North Myrtle Street (Siding only)
- MP 148.7 – Highway 164 (Doyline Interchange Track)
- MP 127.2 – Hwy 154 (LNW #5 Track)
- MP 36.1 – Tifton Avenue (Siding only)
- MP 35.6 – Denver Street (Siding only)
- MP 35.4 – Chicago Street (Siding only)

Continuous Quiet Zone – GCOR 5.8.4

Fourth Street	MP 72.58
Riverfront Street	MP 72.20
South Grand Street	MP 71.96
North Fourth Street	MP 71.76
North Fifth Street	MP 71.69
Desiard Street	MP 71.60
Powell Avenue	MP 69.17
Kansas Lane	MP 68.33
Chennault Park	MP 66.19

Electric Locks

Station	MP	Location of switch
Haughton	154.0	West Haughton
Haughton	153.3	East Haughton
Blazer Spur	152.8	Blazer Spur
Doyline	149.1	W Doyline Interchange
Doyline	148.4	E Doyline Interchange
Doyline	148.3	West Doyline
Doyline	147.5	East Doyline
Nelson	131.4	West Nelson
Nelson	130.7	East Nelson
Gibsland	128.4	West Gibsland #1
Gibsland	127.2	Gibsland XO MT to #1 Track
Gibsland	127.1	Gibsland #5 Track
Arcadia	120.2	West Arcadia
Arcadia	119.5	East Arcadia
Con Agra	117.4	Con Agra
Weyerhaeuser	116.6	Weyerhaeuser OSB
Ruston	102.6	West Ruston

Station	MP	Location of switch
Choudrant	95.8	West Choudrant
Choudrant	95.0	East Choudrant
Fitzmorris	75.0	Louisiana Plastic
Monroe	71.3	Monroe Fuel Track
Monroe	71.2	Monroe RIP Track
Monroe	71.2	Monroe Yard
Monroe	71.1	UP Interchange
Airport Ind. Park & W S/O Track	69.1	Airport Ind. Park & W S/O Track
Delhi	36.4	West Delhi
DSR Connection	17.8	West DSR Connection
DSR Connection	17.2	East DSR Connection

Trackside Warning Detectors

Mile Post	Type of Detector	Call Back
155.3	HBD/DED/Oversized Load (C) (W)	#88
151.9	Wheel Impact/ Hunting Truck/Imbalanced Load	
138.4	HBD/DED	
125.1	HBD/DED	
107.1	HBD/DED	
97.0	HBD/DED	
84.2	HBD/DED	
74.4	HBD/DED/Oversized Load (C) (E)	#88
64.3	HBD/DED/Oversized Load (C) (W)	
47.1	HBD/DED	
30.4	HBD/DED	
12.9	HBD/DED/Oversized Load (C) (E)	
2.5	HBD/DED (C) (E)	

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
East Haughton	W	153.3	3,386
Blazer Spur	E	152.8	1,324
CP Doyline		151.8	CP
West Doyline Interchange	E	149.1	3,012
Doyline Interchange ++	W	149.0	341
East Doyline Interchange	W	148.4	3,012
West Doyline	E	148.3	3,862
East Doyline	W	147.5	3,862
West LAS Interchange +	E	142.4	4,035
West Sibley 702 ++	E	142.4	3,573
East Sibley 702 ++	W	141.6	3,573
East LAS Interchange +	W	141.6	4,035
Sibley Branch Minden Sub +	E	141.4	CONN
West Nelson	E	131.4	3,468
East Nelson	W	130.7	3,468
West Gibsland #1	E	128.4	4,157
East Gibsland #1 ++	W	127.5	4,157
Gibsland Stub +	W	127.2	130
Gibsland XO MT to #1 Track	W	127.2	XO
Gibsland #5 Track	W	127.1	CONN
East Arcadia	W	119.5	3,051
CP 119		119.2	CP
West Martin Resources	E	119.2	4,049
Martin Underground ++	E	118.7	IND
East Martin Resources	W	118.4	4,049
CP 118		118.3	CP
Con Agra	E	117.4	6,087

US Southern Region Timetable

Name	DOE	MP	Footage
Weyerhaeuser OSB	W	116.6	1,824
Mid States Wood Preservers	W	112.9	459
Blazer Construction Spur +	W	111.9	3,230
CP 110		110.2	XO
House of Raeford +	W	110.0	IND
Ball-Foster +	W	109.7	5,226
Weyerhaeuser Surpine +	E	109.7	1,136
Industrial Insulation Group	W	108.7	903
Business Car Track	E	102.9	313
West Ruston	E	102.6	3,000
West Randal Farms ++	E	95.5	853
East Randal Farms ++	W	95.2	853
East Choudrant	W	95.0	4,275
Calhoun Team Track	E	86.2	678
Drill Track Xover +	W	76.3	XO
Drill Track +	W	75.6	IND
Louisiana Plastic	W	75.0	3,450
Set Out Track +	W	74.6	1,210
Riverwood Paper Mill	W	72.5	IND
CP 72		72.5	CP
Monroe Fuel Track	W	71.3	
Monroe RIP Track	W	71.2	
Monroe Yard	W	71.2	Yard
CP 69		69.2	CP
Monroe Switching Lead +	W	69.2	Yard
Airport Industrial Park &			
West Set Out Track	E	69.1	IND
East Set Out Track	W	68.4	3,255
CP 68		68.2	XO
Rayville Producers	E	52.2	1,350
CP 49		49.0	49.0
Holly Ridge Team Track	W	42.5	850
Pro-Boll Chemical	W	39.9	2,316
Lansing Grain West	E	36.9	8,453
Lansing Grain East	W	36.6	8,453
West Delhi	E	36.4	3,200
CP 27		27.8	CP
West DSR Connection	E	17.8	Conn
East DSR Connection	W	17.2	Conn
Bunge Spur	W	14.8	720

+ Indicates Connected to Siding

++ Indicates Connected to Business Track

Switch Information

Graphic Packaging

DTMF Yard Switches are installed on the Graphic Packaging Lead. When entering the Ouachita Terminal industry tracks it will be necessary to operate the DTMF switches.

- West Ouachita Terminal Industry track switch
DTMF code: normal switch DTMF #001111 – reverse switch DTMF #001122.
- East Ouachita Terminal Industry track switch
DTMF code: normal switch DTMF #000511 – reverse switch DTMF #000522.

LANSING GRAIN

Dual control derrails are installed on the east and west industry tracks. These derrails operate in conjunction with the main line switches. When operating the West dual control switch by hand it is also necessary to operate the split point derail by hand. When operating the East dual control switch by hand it is also necessary to operate the split point derail by hand.

DTMF Yard Switches are installed on both ends of Lansing Grain industry track. When entering the industry tracks it will be necessary to operate the DTMF switches.

West industry track switch DTMF code: normal switch DTMF #036811 – reverse switch DTMF #036822.

East Industry track switch DTMF code: normal switch DTMF #036711 – reverse switch DTMF #036722.

Vicksburg Yard

The following switches may be left as last lined:

- First switch approximately 50 feet north of Depot Street.

General Information

Graphic Packaging

Before removing the derail on Graphic Packaging Lead at Coleman Avenue, contact Superior Switching on channel 022-022.

Superior Switching must remain stopped while CPKC is making train movements south of the derail.

Notify Superior Switching after we have locked derail back in derailing position and departed Graphic Packaging Lead.

Vicksburg Yard

The following switches may be left as last lined:

- Double stack Intermodal Cars and Autoracks will not clear under Fairground Street Bridge in Vicksburg Yard.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	HODGE SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Pineville Jct.		Mile Post Location				
	T	YL	0.0	PINEVILLE JCT.	B-193.8	MP B-193.8			
			1.8	1.8		-			
			1.8	END OF LINE	B-192.0	MP B-192.0			

MAXIMUM SPEED **MPH**
20

Exceptions:

MP B-193.8 – MP B-192.010

Radio Channels

	AAR	Dispr Call In
Road	060-060	
Critical Incident Desk	086-060	3

TrAM Area

The Hodge Sub is TrAM Area 1.

Yard Limits

North MP **South MP**
 193.8 Pineville Jct.192.0

Equipment Restrictions

Six Axle Locomotives Prohibited from Operating on the entire Sub.

General Information

MP B-192.0 begins Louisiana Southern Railroad.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	REDWOOD BRANCH STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From End of Line		Mile Post Location				
1177		6.28	0.0	END OF LINE	218.0				
			2.3	VICKSBURG (Via Yard Track)	220.3				
			4.3	VICKSBURG IND. LEAD JCT.	222.3				
			0.7						
			5.0	END OF LINE	223.0				

MAXIMUM SPEED **MPH 10**
Exceptions: None

Radio Channels

	AAR	Dispr Call In
Road	060-060	
Yard	007-007	
Critical Incident Desk	086-060	3

TrAM Area

The Redwood Branch is TrAM Area 1.

Rule 6.28 Other than Main Track

Other than Main Track used on the Redwood Branch.

General Information

The former main track of the Redwood Branch between MP 221.1 and MP 222.3 is now the main track on the Meridian Subdivision which is CTC territory.

MP 222.3 to MP 223.0 is designated as Vicksburg Industrial Lead.

MP 222.3 on the Redwood Branch is the same location as MP 141.7 on the Meridian Subdivision.

MP 218.0 begins Vicksburg Southern Railroad (North).

MP 223.0 begins Vicksburg Southern Railroad (South).

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	WESTWARD ↑	MERIDIAN SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	EASTWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Vicksburg		Mile Post Location				
1177	B C	CTC	0.0	(Vicksburg Sub) # Vicksburg West VICKSBURG # Vicksburg East	142.0 140.6 140.3		8,586	CQ MP 139.76 MP 139.05	130.0
				8.4					
1185			8.4	# Newmans West NEWMANS # Newmans East	132.8 132.2 131.1		8,537		
				6.3					
1192			14.7	# Smiths West SMITHS # Smiths East	125.9 125.9 124.2		8,973		
				4.0					
1196			18.7	EDWARDS	121.9				
				9.9					
1206			28.6	# Century West CENTURY # Century East	112.8 112.0 110.9		9,239	CQ MP 109.15 to MP 102.92	112.9
				11.8					101.2
1218			40.4	DIXON	100.2				
				3.2					
1220	W		43.6	# Monument West MONUMENT West Switch Tender East Switch Tender	98.3 97.0 95.8 95.3		13,186		
				5.9					
Operation via CN RR between East and West Switch Tender (CN MP 729.1 – 730.3) (CPKC MP 95.8 – 95.4).									
1227	B C	CTC #1 MT	49.5	# Jackson West JACKSON (2 MT) # Jackson East	94.1 91.1 90.1				86.7
				3.4					
1229		CTC	52.9	# Whitfield West WHITFIELD # Whitfield East	88.5 87.7 86.8		8,704		
				2.7					
1232			55.6	GREENFIELD	85.0				
				4.2					
1237			59.8	# Brandon West BRANDON # Brandon East	82.8 80.8 80.8		9,843		
				5.1					
1242			64.9	# Rankin West RANKIN # Rankin East	75.9 75.5 73.9				
				6.4					
1249			71.3	PELAHATCHIE	69.3				
				7.3					
1255			78.6	# Harmon West HARMON # Harmon East	62.8 62.0 61.1		8,694		64.7
				1.7					
1257			80.3	MORTON	60.3				54.9
				11.0					
1268			91.3	# Forest West FOREST	50.3 49.3				43.8
				8.7					
1277			100.0	# Lake West LAKE # East Lake	40.7 40.6 38.9		8,600		
				9.7					
1287	B C		109.7	NEWTON	30.9				
				Continued on next page					

US Southern Region Timetable

Equipment Restrictions

Six Axle Locomotives Prohibited From Operating On The Following Tracks:

- Meridian Yard Track 1; and RIP Tracks 1 and 2
- West Lead, Jackson Yard, south of Carrier Blvd. – MP 92.4
- Air Base Lead – MP 98.5
- All industry tracks except:
 - o Vicksburg
 - o Jackson

Movement over Public Crossings

Automatic Warning Devices Infrequently Used:

- MP 153.7 – North Myrtle Street (Siding only)
- MP 148.7 – Highway 164 (Doyline Interchange Track)
- MP 127.2 – Hwy 154 (LNW #5 Track)
- MP 36.1 – Tifton Avenue (Siding only)
- MP 35.6 – Denver Street (Siding only)
- MP 35.4 – Chicago Street (Siding only)

Continuous Quiet Zone – GCOR 5.8.4

Oak StreetMP 139.76

Court StreetMP 139.05

All Public and Private Highway Crossings between MP 109.15 and MP 102.92.

Electric Locks

Station	MP	Location of switch
Haughton	154.0	West Haughton
Haughton	153.3	East Haughton
Blazer Spur	152.8	Blazer Spur
Doyline	149.1	W Doyline Interchange
Doyline	148.4	E Doyline Interchange
Doyline	148.3	West Doyline
Doyline	147.5	East Doyline
Nelson	131.4	West Nelson
Nelson	130.7	East Nelson
Gibbsland	128.4	West Gibbsland #1
Gibbsland	127.2	Gibbsland XO MT to #1 Track
Gibbsland	127.1	Gibbsland #5 Track
Arcadia	120.2	West Arcadia
Arcadia	119.5	East Arcadia
Con Agra	117.4	Con Agra
Weyerhaeuser	116.6	Weyerhaeuser OSB
Ruston	102.6	West Ruston
Choudrant	95.8	West Choudrant
Choudrant	95.0	East Choudrant
Fitzmorris	75.0	Louisiana Plastic
Monroe	71.3	Monroe Fuel Track
Monroe	71.2	Monroe RIP Track
Monroe	71.2	Monroe Yard
Monroe	71.1	UP Interchange
Airport Ind. Park & W S/O Track	69.1	Airport Ind. Park & W S/O Track
Delhi	36.4	West Delhi
DSR Connection	17.8	West DSR Connection
DSR Connection	17.2	East DSR Connection

Trackside Warning Detectors

Mile Post	Type of Detector	Call Back
130.0	HBD/DED/Oversized Load (C) (W)	#88
112.9	HBD/DED/Oversized Load (C) (E)	
101.2	HBD/DED	
86.7	HBD/DED/Oversized Load (C) (W)	
78.2	HBD/DED	
64.7	HBD/DED	
54.9	HBD/DED	
43.8	HBD/DED	
25.8	HBD/DED/Oversized Load (C) (E)	
14.4	HBD/DED/Oversized Load (C) (W)	

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
Vicksburg Industrial Lead	W	141.7	1,296
East Xover	E	141.0	
Vicksburg Yard +	E	140.9	
IP Wood Yard +	E	125.9	619
Calmaine Foods	W	122.8	1,040
Donald Wood Yard	E	120.9	1,520
Mega Plastic	E	107.5	538
Gulf States Cannery	E	107.2	1,978
Johnson Milling	W	104.9	402
West Dixon	E	100.4	3,392
East Dixon	W	99.7	3,392
Hawkins Field Ind. Park	W	98.4	
Prentiss Street Xover	E	97.5	
West Monument 601 +	E	97.2	2,687
East Monument 601 +	W	96.6	2,687
West CN Connection +	W	96.2	
Avery Lead	E	93.8	165
Transload Spur	E	93.2	
CP 92		92.3	CP
Long Lead Xover	W	90.7	
East Greenfield	W	84.7	2,546
GM Lead	E	82.7	
Buzzi Unicem +	E	82.2	1,320
Gold Coast Commodities +	E	81.0	730
Reckitt Benkaiser	E	80.9	760
West Rankin	E	75.9	4,679
East Rankin	W	74.9	4,679
Sand Hill	E	75.9	679
BOC Gas ++	W	75.7	270
West Pelahatchie	E	69.4	1,782
East Pelahatchie	W	69.0	1,782
Pelahatchie House Track	W	68.9	670
West Morton Pass	E	60.5	2,369
East Morton Pass	W	60.0	2,369
CP 58		58.6	CP
Koch Foods	E	58.6	IND
Koch Foods Track 2 ++	E	58.5	IND
Mississippi D.O.T	W	54.7	1,865
Central By-Products	W	52.6	1,800
West Forrest Pass	E	50.3	4,453
West Storage	W	49.6	2,023
East Forrest Pass	W	49.4	4,453
HJ Baker	W	49.2	2,285
East Storage	E	49.1	2,023
West Peco Foods	E	39.7	IND
Lawrence Team Track	W	34.8	1,069

US Southern Region Timetable

Name	DOE	MP	Footage
West Newton	E	31.5	1,992
East Newton	W	31.1	1,992
Louisville Connection	E	31.0	Conn
Bay Springs Ind. Spur	W	30.9	Conn
Chunky Team Track	E	17.0	658
West International Paper +	E	12.3	3,012
East International Paper +	W	11.8	3,012

+ Indicates Connected to Siding

++ Indicates Connected to Business Tracks

Switch Information

Vicksburg Yard

The following switches may be left as last lined:

- The first switch approximately 50 feet north of Depot Street.

Meridian

Southern Crossover: All switches of crossover must be lined to establish block signal protection. After lining crossover switches, wait five (5) minutes before fouling crossover.

Operation of East and West Lead Switches

East Switch:

Use channel 053-053 and enter the following codes:

Normal position - #091011

Reverse position - # 091022

West Switch:

Use channel 050-050 and enter the following codes:

Normal position - #091311

Reverse position - # 091322

Koch Foods

Dual control derrails are located at the clearance point of each track. These derrails are operated in conjunction with both the main and industry track dual-control switches operated by the train dispatcher. When required to operate either dual control switch by hand, it is also necessary to hand operate the derail for the track you will enter.

Peco Foods

A dual control derail is installed on the industry track. This derail operates in conjunction with the siding switch. When operating the dual control switch by hand it is also necessary to operate the split point derail by hand.

DTMF Yard Switches are installed on both the North Industry Track and South Industry Track of Peco Foods industry track. When entering the industry tracks it will be necessary to operate the DTMF switches.

North Industry track switch DTMF code: normal switch DTMF #039811 – reverse switch DTMF #039822.

South Industry track switch DTMF code: normal switch DTMF #039711 – reverse switch DTMF #039722.

General Information

The following restrictions apply to all manifest trains departing EWD from Vicksburg between MP 138.0 and MP 140.5:

- Empty cars 85 feet or longer, empty flat cars, wood racks and empty chip hoppers must be handled with no more than 7,000 trailing tons behind such cars.

- EWD trains that stall between MP 140.5 and MP 139 must not attempt to start train without helpers or distributed power.
- No more than 30 equivalent powered axles may be used on the head-end of the train and no more than 20 powered axles may be used on helpers or distributed power.
- Trains operating with excess of 7,000 trailing tons must have ten (10) loads (cars weighing over 50 tons) on the head end or be operated with distributed power or helper locomotives.

Vicksburg Yard

The following switches may be left as last lined:

- Double stack Intermodal Cars and Autoracks will not clear under Fairground Street Bridge in Vicksburg Yard.

Mississippi River Bridge – Vicksburg, MS MP 142.5

A bridge strike alarm monitors the bridge for water vessel impacts. If the CDU denotes that the alarm has been activated, trains must stop short of the bridge or bring train to a stop with proper train handling if already traversing the bridge. Once stopped, trains must remain stopped until Bridge Authority clears the bridge for movement.

Key Trains Between MP 138 And MP 140.3

Key trains or cut of cars meeting the definition of a Key Train must not be left unattended between MP 138.0 and MP 140.3.

Between MP 138 and MP 140.5

When approaching 10-degree curve at MP 139.7, be governed by ABTH Rule 104.3.2 B Dynamic Brake Limitations.

When train air brakes are required to reduce or control speed, the following will govern:

- If necessary to use train air brakes to reduce and maintain speed through this location the brakes must be applied sufficiently in advance to require no more than a minimum reduction to reduce train speed with throttle no higher than number 3 position.
- Do not exceed the throttle position in relation to the number of equivalent axles of power as follows:

Number of axles	Maximum Throttle Position
Less than 18	4
18 or more	3

Meridian

All trains must contact Meridian Yard prior to entering yard limits.

Jackson

Inbound trains must contact Jackson Yard and receive permission to enter.

Trains must not block Pearson Road or Deeb Street Crossings on the Meridian Subdivision. Trains being held out of Jackson Yard are to stop short of these two crossings.

Be governed by GCOR 5.13 (Blue Signal Protection) when protecting workmen on this track, also governed by ABTH Section 3, Rule 28.1.

US Southern Region Timetable

This track may be used under the direction of the supervisor in charge of Jackson Yard.

Switching Signals at Jackson

Before the train dispatcher may line the crossover from the switching lead to Main No. 2 at Jackson for movement through the crossover, or set any switching signal to a Stop indication, the dispatcher must contact the Manager on Duty. The Manager on Duty must verify that no train or switching job is using the signal and/or that they will remain clear of the signal.

Milepost Equalization:

- MP 135.0 on the Artesia Subdivision and MP 0.0 on the Meridian Subdivision are the same location.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	WESTWARD ↑	HAVERTY SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	EASTWARD ↓	Yard Limits	Siding Length	Continuos Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Meridian		Mile Post Location				
	B J	YL	0.0 0.8	(Meridian Sub) EAST MERIDIAN	0.0 0.8	MP 0.0 – MP 0.8	6,280		9.2 <

MPH	
MAXIMUM SPEED	40
Exceptions:	
MP 0.0 – MP 0.3	10
MP 0.3 – MP 0.5	15
MP 0.5 – MP 0.8	25
Tombigbee River Bridge (MP 46.3 – MP 46.7) ...	10
Through Turnouts and Crossovers.....	10
Other Than Main Track	10

Radio Channels

	AAR	Dispr Call In
Road	029-029	
Yard	007-007	
Disp.	097-029	1
Critical Incident Desk	097-029	3
NS Meridian Yard	092-092	

Movement Authority

Track Warrant Control is in use between MP 0.8 and MP 42.0.

AGR trains may use CPKC Main Track between MP 52 and Myrtlewood to interchange cars to CPKC at Myrtlewood. AGR crews must obtain authority from CPKC Dispatcher before train or engines may occupy CPKC Main Track. Until authority to occupy CPKC Main Track is received, Westward AGR trains must hold at Shiloh Street in Linden.

Yard Limits

East MP	West MP
0.8	East Meridian.....0.0
52.0	Naheola.....42.0

Equipment Restrictions

Six Axle Locomotives Prohibited on Customer Tracks unless Authorized.

Road Crossings

18th Ave - Crossing signal lights on the 18th Avenue Crossing (MP 0.5) in Meridian must be turned on and off manually when entering the crossing on Shop Lead Track, Woodyard 1, or Woodyard 2. The signal lights must be turned on and known to be operational for no less than 20 seconds before trains, engines or equipment may enter the crossing.

MP 19.1 - Crossing is closed, but not barricaded.

Trackside Warning Detectors

Mile Post	Type of Detector	Call Back
9.2	HBD/DED	#88
25.5	HBD/DED	
41.2	HBD/DED	

US Southern Region Timetable

**Other Tracks Not Shown as Stations
(Business Tracks)**

Name	DOE	MP	Footage
West MS Railcar	E	14.8	2391
East MS Railcar	W	15.4	2391
West Whynot House	E	15.7	1040
East Whynot House	W	15.9	1040
West Cromwell House	E	29.4	650
West GP Warehouse	E	42.8	648
East GP Warehouse	W	42.9	648
West Pennington House	E	43.1	612
East Pennington House	W	43.3	612
West Marco	E	43.5	1100
East Marco	W	43.7	1100
West GP Storage	E	44.7	
West Wood Yd Storage	E	45.0	
West Pass		49.5	
West Siding		49.5	

General Information**Tombigbee River Drawbridge:**

The normal position for the Naheola Tombigbee River Drawbridge is "Open". All movements across the bridge will be controlled by Engineering. A Form B is in effect to control movements across the bridge.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	BAY SPRINGS BRANCH STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Newton		Mile Post Location				
1287	B C	YL	0.0	(Meridian Sub) NEWTON	161.5	MP 161.5			
				2.0		-			
			2.0	END OF LINE	159.5	MP 159.5			

MAXIMUM SPEED **MPH**
10

Exceptions: None

Radio Channels

	AAR	Dispr Call In
Road	065-065	
Yard	065-065	
Critical Incident Desk	065-065	3

TrAM Area

The Bay Springs Branch is TrAM Area 1.

Yard Limits

North MP **South MP**
161.5Newton 159.5

General Information

MP 159.5 begins Mississippi Southern Railroad.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	ARTESIA SUBDIVISION STATION PAGE # DENOTES CONTROL POINT OR MANUAL INTERLOCKING	SOUTHWARD ↓	Yard Limits	Siding Length	Continuos Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Ruslor Jct.		Mile Post Location				
	A	YL	0.0	(Counce Branch) RUSLOR JCT. (Via NS)	330.5	MP 330.5 - MP 325.5			
			1.6	NS RRX	328.9				
			1.7	CORINTH SSS Corinth	328.8 325.5				
			11.6						
2000	B C	TWC	13.3	NSS Rienzi RIENZI SSS Rienzi	318.1 317.2 316.5		8,058		
2012			8.7						
2020			22.0	BOONEVILLE	308.5				
2041			21.5						
		TWC	43.5	NSS Saltillo SALTILLO SSS Saltillo	287.7 287.0 286.3		7,386		
2050	A B C		8.0						
2070			51.5	NSS Tupelo TUPELO (BNSF RRX) SSS Tupelo	280.5 279.0 276.0				
2067			7.4						
		TWC	58.9	GLEN	271.6				
2075			10.2						
2085			69.1	NSS Okolona OKOLONA SSS Okolona	261.9 261.4 260.0		9,481		
2089			7.1						
		TWC	76.2	NSS Egypt EGYPT SSS Egypt	254.6 254.3 253.8				
2096			8.6						
2102			84.8	NSS Prairie PRAIRIE SSS Prairie	246.6 245.7 245.6				
2106			4.4						
		TWC	89.2	NSS Muldon MULDON SSS Muldon	241.4 241.3 240.7				
2110	B C T		8.3						
			97.5	ABERDEEN JCT.	234.0				
			0.5						
		TWC	98.0	NSS West Point WEST POINT SSS West Point	234.0 232.5 230.0	MP 234.0 - MP 230.0			
			2.1						
			100.1	CGNRR CONN	230.4				
			3.4						
		TWC	103.5	NSS Tibbee SSS Tibbee TIBBEE	227.7 227.1 227.0				
			2.9						
			106.4	MAYHEW	224.1				
			4.9						
		YL	111.3	NSS Artesia ARTESIA SSS Artesia	222.0 219.2 215.5	MP 222. - MP 215.5			
				Continued on next page					

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	ARTESIA SUBDIVISION STATION PAGE # DENOTES CONTROL POINT OR MANUAL INTERLOCKING	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Latanier		Mile Post Location				
		TWC		8.3					
			119.6	CRAWFORD	210.9				206.1
2131				NSS Macon SSS Macon	198.5 197.8				
			132.8	MACON	197.7				190.0
				9.5					
2141			142.3	NSS Shuqulak SHUQULAK SSS Shuqulak	188.6 188.2 187.9				
				5.6					
2146			147.9	NSS Wahalak WAHALAK SSS Wahalak	183.3 182.6 182.0		5,933		
				13.7					172.4
2160			161.6	NSS Sucarnochee SUCARNOCHEE SSS Sucarnochee	169.3 168.9 168.2		5,062		
				15.6					158.5
2176			177.2	NSS Lauderdale LAUDERDALE SSS Lauderdale	153.4 153.3 152.4		5,117		
				13.3					144.6
2189		YL	190.5	NSS Marion MARION SSS Marion	140.2 140.0 139.1		5,294		
	A		194.8	4.3 NS RRX	135.7	MP 137.1 -			
				0.5					
1318	B C		195.3	NSS Meridian MERIDIAN (Meridian Sub)	137.1 135.2	MP 135.0			

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	LOUISVILLE CONNECTION STATION PAGE # DENOTES CONTROL POINT OR MANUAL INTERLOCKING	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From End of Line		Mile Post Location				
		YL	0.0	LOUISVILLE SUB CONN	87.6				
				0.3		MP 87.6 -			
			0.3	C&G RRX	87.3	MP 87.2			
				0.1					
			0.4	END OF LINE	87.2				

US Southern Region Timetable

MAXIMUM SPEED	MPH
	49
Exceptions:	
MP 330.5 – MP 280.5	10
MP 280.5 – MP 276.0	20
MP 276.0 – MP 234.0	25
MP 234.0 – MP 230.0	10
MP 230.0 – MP 227.7	25
MP 227.7 over bridge	10
MP 227.7 – MP 220.0	25
MP 222.0 – MP 215.5	HER 20
MP 160.3 – MP 159.8	40
MP 149.8 – MP 148.2	45
MP 148.2 – MP 144.7	40
MP 137.1 – MP 135.0	20
All Switches and Sidings	10
Louisville Connection	
MP 87.6 – MP 87.2	25
Tons per Operative Brake	
When maximum subdivision speed is over 45 MPH, the maximum speed permitted will be determined by the tons per operative brake.	
100 or less	No Restriction
101 to 110	55
111 to 120	50
Over 120	45

Radio Channels

	AAR	Dispr Call In
Meridian to West Point		
Road	065-065	
Yard	007-007	
Disp.	065-065	1
Critical Incident Desk	065-065	3
West Point to Corinth		
Road	053-053	
Yard	007-007	
Disp.	053-053	1
Critical Incident Desk	053-053	3

TrAM Area

The Artesia and Louisville Connection Subs are TrAM Area 1.

Movement Authority

Track Warrant Control (TWC) is in use between Corinth and Tupelo, Glen and Aberdeen Jct., Tibbee and Artesia, Crawford and NS RRX.

Positive Train Control (PTC)

PTC is in effect on the Artesia Sub.

Yard Limits

North MP	South MP
330.5	Ruslor Jct/Corinth 325.5
280.5	Tupelo..... 276.0
234.0	Aberdeen Jct/CGRR Conn..... 230.0
222.0	Artesia..... 215.5
137.1	NS RRX/Meridian..... 135.0
87.6	Louisville Connection..... 87.2

Equipment Restrictions

Six Axle Locomotives Prohibited From all Tracks EXCEPT:

- Main Track Tupelo to Corinth (SD40 Locomotives Only)
- Main Track Meridian to Tupelo
- Artesia Yard - All tracks
- Saltillo Siding MP 286.7 to 286.3
- Wahalak Siding MP 183.3 to 182.0
- Sucarnochee Siding MP 169.3 to 168.2
- Lauderdale Siding MP 153.4 to 152.4
- Marion Siding MP 140.2 to 139.1 six axle locomotives must not be used for switching.

Gross Weight

Cars with a gross weight more than 132 tons must not be handled on the following tracks:

- Louisville - North Union to West Point and Pearl Industrial lead to Sebastopol
- Artesia Sub - Northwest Point to Corinth only

Movement over Public Crossing

Automatic Warning Devices Used Infrequently:

- MP 134.2 – 29th Avenue (Meridian Yard Track 6 only)
- MP 182.5 – Wahalak Road (Siding only)
- MP 188.2 – MS 39 and MS 21 at Shuqulak (Siding only)
- MP 188.4 – Oak Street at Shuqulak (Siding only)
- MP 211.2 – Main Street Crawford (Siding only)
- MP 261.0 – Monroe Street at Okolona (Siding only)
- MP 245.6 – MS 382 at Prairie (Siding only)
- MP 316.8 – MS 356 Rienzi at (Siding only)

Trackside Warning Detectors

Mile Post	Type of Detector	Call Back
259.9	HBD/DED	#88
244.8	HBD/DED	
224.5	HBD/DED	
206.1	HBD/DED	
190.0	HBD/DED	
172.4	HBD/DED	
158.5	HBD/DED	
144.6	HBD/DED	

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
North Ruslor Jct.	S	330.5	7,733
Ruslor 812	S	329.0	SPUR
South Ruslor Jct.	N	328.9	7,733
North Corinth 001	S	328.7	2,481
North Corinth	S	328.7	7,401
Corinth 307 ++	N	328.7	CONN
North Corinth 1 Crossover ++	S	328.2	XO
South Corinth 001	N	328.2	2,481
South Corinth 1 Crossover	N	328.1	XO
North Corinth 2 Crossover	S	328.0	XO

US Southern Region Timetable

Name	DOE	MP	Footage	Name	DOE	MP	Footage
South Corinth 2 Crossover ++	N	328.0	XO	North Macon	S	198.5	3,156
North Corinth 801 ++	S	328.0	LEAD	Prime Line, Inc. +	S	198.2	1,000
South Corinth 801 ++	N	327.3	LEAD	South Macon	N	197.8	3,156
Intex ++	N	327.3	IND	GST Plastic	N	197.7	965
South Corinth	N	327.2	7,401	North Shuqualak	S	188.6	3,556
Alcorn Wood Yard	S	316.2	1,165	North Wood Yard	S	188.4	247
Heartland	N	309.9	1,482	South Wood Yard	N	188.1	286
North Westvaco Woodyard	S	305.6	1,869	South Shuqualak	N	187.9	3,556
South Westvaco Woodyard	N	305.2	1,869	Scooba	S	176.4	3,213
CP 301		301.0	CP	Brainerd Chemical	N	172.9	IND
Southern Diversified	S	299.1	600	Electric Mills	S	172.0	900
Flex Foam	N	298.5	600	Sucarnochee Team Track	N	168.3	1,000
CP 295		295.0	CP	Porterville Team Track	S	166.2	1,000
Norbord Lead	S	294.4	3,551	BWI Rail Spur	N	139.7	406
Turner Industrial park	S	286.0	4,240	Meridian Yard	S	135.5	YARD
BNSF Interchange	N	278.9	CONN	Meridian Yard 3	N	135.0	YARD
North Tupelo Yard Lead	S	278.3	LEAD	Meridian Yard 2	N	135.0	YARD
Tupelo House Track	S	278.0	803	+ Indicates Connected to Siding			
Daily Journal	N	278.0	IND	++ Indicates Connected to Business Tracks			
Malone Hyde	S	278.0	IND	Switch Information			
South Tupelo Yard Lead	N	277.8	LEAD	Ruslor			
Cooper Tire Warehouse	S	277.6	1,170	Normal position for the switch at Ruslor Junction will be for the NS.			
Cooper Tire	N	277.0	1,770	Tupelo			
Sunshine Mills	S	276.2	1,100	Main track switches on the switching lead at Tupelo Yard may be left lined and locked as last used between 0700 hours and 1900 hours.			
Ashley Furniture	S	273.1	IND	Artesia			
Sheller Globe	S	272.9	9,000	Switches within the Artesia Yard Limits may be lined as last used; however, crossovers must be in correspondence.			
Action Industries	N	272.7	950	Power Assisted Switches (PAS):			
Bryce – Toga	S	272.4	2,006	Saltillo (North)			
North Glen	S	272.2	4,665	Radio Channel 053-053			
South Glen	N	271.2	4,665	Normal DTMF #289011	Reverse DTMF #289022		
CP 266		266.0	CP	Saltillo (South)			
Cargill House Track	S	261.7	LEAD	Radio Channel 053-053			
North Egypt	S	254.6	4,045	Normal DTMF #285011	Reverse DTMF #285022		
South Egypt	N	253.8	4,045	Aberdeen Jct.			
North Prairie	S	246.6	4,899	Radio Channel 065-065			
South Prairie	N	245.6	4,899	Normal DTMF #233011	Reverse DTMF #233022		
North Muldon	S	241.4	3,167	Wahalak (North)			
Cargill ++	N	241.1	900	Radio Channel 065-065			
South Muldon	N	240.7	3,167	Normal DTMF #183211	Reverse DTMF #183222		
Seitz Lumber	S	233.2	877	Wahalak (South)			
Aberdeen Junction PAS	N	232.9	CONN	Radio Channel 065-065			
North IC Pass	S	232.8	949	Normal DTMF #182111	Reverse DTMF #182122		
South IC Pass	N	232.6	949	Marion (North)			
Southern Ionics	N	232.6	630	Radio Channel 065-065			
Morris Scrap Metal	S	232.0	IND	Normal DTMF #140211	Reverse DTMF #140222		
Louisville Sub Connection	S	232.0	CONN	Marion (South)			
CGRR Interchange	N	231.8	CONN	Radio Channel 065-065			
North Tibbee	S	227.7	3,018	Normal DTMF #139011	Reverse DTMF #139022		
South Tibbee	N	227.1	3,018				
Mayhew	N	224.0	938				
North Artesia	S	220.2	8,987				
North Artesia XO North	S	219.5	XO				
South Artesia XO North++	N	219.5	XO				
North Artesia XO South	S	219.1	XO				
South Artesia XO South++	N	219.0	XO				
South Artesia	N	218.4	8,987				
North American Tie Lead	S	215.9	IND				
North Crawford	S	211.2	2,381				
North Cargill Mill Track ++	S	211.1	531				
South Cargill Mill Track ++	N	210.9	531				
South Crawford	N	210.7	2,381				
Barge Lumber	N	200.9	IND				

Note: Reference Rule 8.21.1. The Switch Control Signs for the following locations are placed approx. 1 mile from the Power Assisted Switch location.

1. North Saltillo MP 289.0
2. South Saltillo MP 285.0

General Information

POSITIVE TRAIN CONTROL (PTC)

PTC Active track is in effect on the Artesia Subdivision from MP 137.1 to MP 215.5 and MP 222.0 to MP 230.0. PTC restrictions will be enforced in these limits.

PTC entry track is in effect from MP 215.5 to MP 222.0 and MP 230.0 to MP 330.5 and will not enforce PTC restrictions in these limits.

Local and Road switchers working within the limits from MP 222.0 and MP 230.0 will adhere to SSI 18.13 if PTC equipped locomotives are not available.

Ruslor

Before entering the NS main track at Ruslor Junction, crews must obtain NS dispatchers bulletin and permission from the dispatcher to enter the NS main track. NS Radio Channel 056-056 TONE 809, use radio channel 2 (048-009) to copy a Track Warrant or call 1-205-951-6645.

Artesia

MP 87.2 begins WATCO

Broken Rail Detection (BRD)

Broken Rail Detection (BRD) limits are in effect on the main track between MP230.0 and MP222.0 and between MP215.5 and MP137.1.

Begin BRD and End BRD signs will be posted at the outer limits of BRD Territory.

Limits monitored by BRD have indicators that display aspects for the condition of the track.

BRD Indicators

<u>Aspect</u>	<u>Indication</u>
Flashing Green	No defects
Flashing Red	Expect next indicator to be red
Red or Dark	Proceed at restricted speed until the leading wheels pass the next BRD indicator and report to the train dispatcher.

While moving within BRD territory, trains must comply with the indication of the BRD indicator.

If an indicator displaying a flashing green or flashing red changes to an indication requiring a train to proceed at restricted speed, the train must immediately reduce speed consistent with good train handling. Train must then move at restricted speed until the leading wheels pass the next BRD indicator and report such an indicator change to the train dispatcher.

When one of the following occurs, move at restricted speed until the leading wheels have passed the next BRD indicator or the end of BRD limits:

- The train enters the main track between BRD indicators.
- The previous BRD indicator is unknown.
- Movements in the opposite direction from which the BRD segment was entered.

Milepost Equalization:

- MP 0.0 on the Meridian Subdivision and MP 135.0 on the Artesia Subdivision are the same location.
- MP 87.6 on the Louisville Connection and MP 232.0 on the Artesia Subdivision are the same location.
- MP 89.1 on the Aberdeen Branch and MP 232.9 on the Artesia Subdivision are the same location.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	WESTWARD ↑	TUSCALOOSA SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	EASTWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Artesia		Mile Post Location				
2110	B C T	YL	0.0	(Artesia Sub) ARTESIA ESS Artesia	0.0 5.0	MP 0.0 - MP 5.0			
			9.6	9.6	9.6				
				GTR JCT.					
			4.4	4.4					
2814			14.0	WSS Columbus COLUMBUS, MS ESS Columbus	13.4 14.0 17.0				
			0.3	0.3					
	S		14.3	CG JCT.	14.3				
			0.8	0.8					
			15.1	BNSF CONNECTION	15.1				
			0.1	0.1					
	A		15.2	BNSF RRX	15.2				
			1.8	1.8					
			17.0	END OF LINE	17.0				

MAXIMUM SPEED	MPH
	25
Exceptions:	
MP 13.4 - MP 15.2	10
All Switches and Sidings	10

Radio Channels

	AAR	Dispr Call In
Road	065-065	
Yard	007-007	
Disp.	065-065	1
Critical Incident Desk	065-065	3
GTRA	038-038	

TrAM Area

The Tuscaloosa Sub is TrAM Area 1.

Movement Authority

Track Warrant Control (TWC) is in use between Artesia and End of Line.

Yard Limits

West MP	East MP
0.0	Artesia 5.0

Interlockings/Control Points

BNSF RRX at MP 15.2
WWD Approach: MP 16.38.
EWD Approach: MP 14.89.

When required to stop at any signal governing movement over an interlocking, the train must be stopped 200 feet or less from the home signal before working the interlocking release box.

**Other Tracks Not Shown as Stations
(Business Tracks)**

Name	DOE	MP	Footage
West Severstall	E	4.2	IND
East Severstall	W	5.4	IND
CMF	W	5.7	IND
West Bent Oak	E	5.9	4,170
East Bent Oak	W	6.9	4,170
Burk Halter	W	9.6	IND
Columbus Port	E	13.3	IND
East 5 Columbus	W	14.3	792
Omnova	E	16.3	IND

General Information

Artesia-Columbus

CAGY, GTRA, and ABS train and engines must verify CPKC Track Bulletins and receive a Track Warrant from CPKC Train Dispatcher prior to entering CPKC main track and report when clear of main track and release Track Warrant to CPKC train dispatcher.

Columbus

Columbus BNSF Connection VIA BNSF Memphis Division, Amory Subdivision).

Prior to entering the BNSF trackage, crews must obtain permission from the BNSF Train Dispatcher. BNSF radio Frequency 070-070 tone 23.

MP 17.0 begins Alabama Southern Railroad.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	ABERDEEN BRANCH STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Aberdeen		Mile Post Location				
2500		6.28	0.0	(End of Line) ABERDEEN	105.5				
				16.4					
2096			16.4	WEST POINT (Artesia Sub)	89.1				

MPH
10

MAXIMUM SPEED

Exceptions: None

Radio Channels

	AAR	Disp Call In
Road	065-065	
Yard	065-065	
Disp.	065-065	1
Critical Incident Desk	086-060	3

TrAM Area

The Aberdeen Branch is TrAM Area 1.

Rule 6.28 Other than Main Track

Other than Main Track used on the Aberdeen Branch.

Interlockings/Control Points

When required to stop at any signal governing movement over an interlocking, the train must be stopped 200 feet or less from the home signal before working the interlocking release box.

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
Kemira	N	104.1	400
Axiall	N & S	104.0	IND
S&B Industrial Minerals	N & S	100.9	2,006
BASF	N & S	100.0	1,815
North Yokohama	S	91.9	750
South Yokohama	N	91.6	750
Babcock & Wilcox	S	89.9	IND

General Information

S&B Industrial Minerals

No hazardous material cars allowed in S&B Industrial Minerals at MP 100.9.

BASF

No locomotives under the conveyer belt at BASF, MP 100.0.

Milepost Equalization:

MP 232.9 on the Artesia Subdivision and MP 89.1 on the Aberdeen Branch are the same location.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	COUNCE BRANCH STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuos Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location	
			Distance From Counce		Mile Post Location					
6900	B C	YL	0.0	(End of Line) COUNCE	16.1	MP 16.1 - MP 13.6				
				1.1						
6901	T			1.1	PRESTON					15.0
		BRT		1.1						
6902				2.2	BESSIE					13.9
					4.0					
6916	T			6.2	YELLOW CREEK					9.9
					0.1					
6906				6.3	SHARPS					9.8
					7.5					
6913				13.8	FIVEPOINTS					2.3
		YL		1.5		MP 1.5 - MP 0.0				
6915				15.3	MONROE					0.8
					0.7					
	B C			16.0	KENDRICK YARD					0.1
					0.1					
2000	B C		16.1	CORINTH (Artesia Sub)	0.0					

MAXIMUM SPEED **MPH**
10

Exceptions: None

Radio Channels

	AAR	Dispr Call In
Road	086-086	
Yard	007-007	
Disp.	053-053	1
Critical Incident Desk	053-053	3

TrAM Area

The Counce Branch is TrAM Area 1.

Movement Authority

Block Registry Territory is in effect between Bessie and Monroe.

Yard Limits

North MP	South MP
16.1	Counce/Bessie 13.6
1.5	Monroe/Corinth 0.0

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
PCA	N	16.1	IND
GEO Chemical	S	15.5	792
LTV Steel	N & S	14.5	1,170
Bessie	N & S	13.9	1,365
Sharps	N & S	9.8	2,200
Kimberly Clark	N	2.3	1,053
Monroe	N & S	0.8	2,923

General Information

Kendrick Yard

Number 4 track is designated as the Main Track.

Bessie

Do not exceed 5 MPH over the scale at Bessie.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	YELLOW CREEK BRANCH STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuos Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Yellow Creek		Mile Post Location				
6916		6.28	0.0	(Counce Branch) YELLOW CREEK	0.0				
				9.7					
			9.7	END OF LINE	9.7				

MAXIMUM SPEED **MPH**
10

Exceptions: None

Radio Channels

	AAR	Dispr Call In
Road	086-086	
Yard	007-007	
Disp	053-053	1
Critical Incident Desk	086-060	3

TrAM Area

The Yellow Creek Branch is TrAM Area 3.

Rule 6.28 Other than Main Track

Other than Main Track used on the Yellow Creek Branch.

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
Monotech of Mississippi	E	7.4	350
Farris Metal	W	9.0	IND
Yellow Creek Port	W	9.0	IND
Prosser	W	9.7	2,500

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	GULFPORT SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuos Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Hatiesburg		Mile Post Location				
1890		YL	0.0	(IC) HATIESBURG (Via IC)	67.5	MP 67.5 - MP 65.0			
				2.3					
1894			2.3	PALMER	65.2				
				0.2					
		TWC	2.5	BELL YARD	65.0		8,220		59.2
				5.1					
1900			7.6	CAMP SHELBY	59.9				
				2.8					
1902			10.4	NSS McLaurin MCLAURIN SSS McLaurin	57.4 57.1 55.8				
				7.5					
1907			17.9	BROOKLYN	49.6				
				10.8					
1916			28.7	MAXIE	44.3				
				3.8					
1925			32.5	WIGGINS	35.0				
				6.0					
1931			38.5	PERKINSTON	29.0				
				5.2					
1936			43.7	MCHENRY	23.8				
				6.4					
1945			50.1	HOVEY	17.4				
				8.1					
1951			58.2	LYMAN	9.3				
				5.4					
1977	T	YL	63.6	DELISLE JCT.	3.9	MP 5.0 - MP 0.0			11.9
				3.4					
1960	B C		67.0	GULFPORT	0.5				
				0.5					
	I		67.5	CSXT RRX (CSXT)	0.0				

MPH

MAXIMUM SPEED

49

Exceptions:

MP 67.5 - MP 65.0	20
MP 65.0 – MP 61.2	40
MP 59.0 – MP 58.0	40
MP 58.0 – MP 57.5	25
MP 57.5 - MP 56.2	40
MP 48.8 – MP 48.3	40
MP 44.3 – MP 43.5	40
MP 40.0 – MP 39.5	40
MP 35.3 – MP 34.1	10
MP 34.1 – MP 28.5	25
MP 26.0 – MP 25.0	40
MP 23.3 – MP 22.5	40
MP 21.6 – MP 19.5	40
MP 13.5 – MP 5.0	25
MP 5.0 – MP 1.0	20
MP 1.0 – MP 0.0	10
All Switches and Sidings	10

Delisle, MS

DuPont Chemical Industrial lead: Maximum speed between MP 1.0 and MP 13.5 10 MPH. Inside DuPont Chemical Plant, 5 MPH.

Gulfport, MS

Inside Dole and Chiquita Warehouse, 5 MPH.

Tons per Operative Brake

When maximum subdivision speed is over 45 MPH, the maximum speed permitted will be determined by the tons per operative brake.

100 or less	No Restriction
101 to 110	55 MPH
111 to 120	50 MPH
Over 120	45 MPH

US Southern Region Timetable

Radio Channels

	AAR	Disp Call In
Road	029-029	
Yard	029-029	
Disp.	029-029	1
Critical Incident Desk	029-029	3
CSXT Disp	094-094	3

TrAM Area

The Gulfport Sub is TrAM Area 1.

Movement Authority

Track Warrant Control (TWC) is in use between Bell Yard and Delisle Jct.

Yard Limits

North MP	South MP
67.5Hattiesburg/Bell Yard	65.0
5.0Delisle Jct. /CSXT RRX	0.0

Interlockings/Control Points

CSXT RRX at MP 0.02

Dual-controlled derrails are installed within the limits of the interlocking. CPKC signals will be requested through the use of the push buttons on either side of the interlocking, prompting CSXT's dispatcher to line the derrails and request the desired signal. Trains must be within 100' of signal to occupy the approach track. Once the appropriate approach track is occupied, the signal will clear.

CPKC signals can be requested via radio to the CSXT Dispatcher in lieu of the push button request.

To protect Roadway Workers, qualified CPKC employees will request authority from the CSXT Dispatcher to occupy the limits of the interlocker.

Equipment Restrictions

Six Axle Locomotives Prohibited From Operating On The Following Tracks:

- Seaway Lead
- DuPont Industrial Lead except the Wye only for single locomotive moves
- All Gulfport yard tracks, except the main, No. 1 track (North end only), No. 8 track, Middle Yard, the Roundhouse track, and West Pier Tracks.

Gross Weight

Cars with a gross weight more than 132 tons must not be handled on the following tracks of the Gulfport Subdivision:

- Seaway Lead
- North yard tracks 1, 2, 3, 4, 5 only

Trackside Warning Detectors

Mile Post	Type of Detector	Call Back
59.2	HBD/DED	#88
47.2	HBD/DED	
28.0	HBD/DED	
11.9	HBD/DED	

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
Palmer	N & S	65.2	2,029
Camp Shelby Long E Spur	S	60.1	2,650
Camp Shelby West Pass	S	60.0	1,522
Camp Shelby	N & S	59.9	1,338
Camp Shelby Wye	N & S	59.5	5,175
Maxie Team Track	N	44.3	1,320
Coastal Paper	S	33.6	832
IP / Hood Industries	S	33.4	4,851
Perkinston Spur	N	29.0	630
Lyman Team Track	S	9.3	310
DuPont Industrial Lead	N & S	3.9	Lead 13
Miles Green Country Farm Service	S	67.2	1,830

Switch Information

Bell Yard

All switches may be left as last lined.

Delisle Jct.

South Wye switch may be left lined in either the normal or reverse position.

Gulfport Yard

All switches may be left as last lined within Yard Limits.

General Information

MP 70.2 - MP 67.5: Via CN.

All tracks south of CSXT RRX, Rule 6.28.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation		NORTHWARD ↑	ALEXANDRIA SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
				Distance From CP 561		Mile Post Location				
			TWC / ABS	0.0	(Shreveport Terminal Sub) CP 561 (East MT)	561.0				
			ABS VIA UP	0.8	LOUISIANA JCT.	561.8				
			East MT	0.1						
			TWC	0.9	UP RRX (East MT)	561.9				
0370			West MT	0.3						
			East MT	1.2	ALEX JCT.	562.2				
				7.0						
3009				8.2	NSS Curtis CURTIS SSS Curtis	568.6 569.2 569.9		5,958		
				16.1						
3026				24.3	NSS Ninock NINOCK SSS Ninock	584.5 585.3 586.2		8,550		
				18.0						
3043				42.3	NSS IP Pass I.P. PASS SSS IP Pass	603.0 603.3 603.6				
				1.1						
3044				43.4	NSS Coushatta COUSHATTA SSS Coushatta	604.2 604.4 604.6				
				13.1						
3058				56.5	KRAFT	617.5				
				4.2						
3062				60.7	CAMPTI NSS Campti SSS Campti	621.7 621.8 623.9		10,396		
				4.8						
3063				65.5	PORT of NATCHITOCHES	626.5				
				15.8						
3082				81.3	NSS Montgomery MONTGOMERY SSS Montgomery	642.3 642.3 642.7				
				15.0						
3097				96.3	NSS Colfax COLFAX SSS Colfax	656.7 657.3 657.7				
				17.4						
3114				113.7	NSS Barrett BARRETT SSS Barrett	673.9 674.7 675.6		8,650		
				3.8						
	A			117.5	UP RRX	678.5				
				2.5						
				120.0	NSS Pineville PINEVILLE SSS Pineville	680.7 681.0 681.2		3,121		
				0.4						
	T			120.4	PINEVILLE JCT.	681.4				
				5.3						
				125.7	ALEXANDRIA IND. SPUR	686.9				
				5.2						
3133	C B	YL		130.9	NSS Latanier LATANIER (New Orleans Sub)	690.0 691.9	MP 690.0 – MP 691.9			

US Southern Region Timetable

	MPH
MAXIMUM SPEED	49
Exceptions:	
MP 561.0 – MP 562.2 East MT	20
MP 561.8 – MP 562.2 West MT	20
MP 562.2 – MP 564.0	HER 20
MP 588.0 – MP 589.0	40
MP 616.5 – MP 618.0	40
MP 678.5 – MP 678.6	40
MP 678.6 – MP 682.0	45
All Switches and Sidings unless listed below	10
Turnouts and Sidings	
Alex Junction.....	25
Ninock South End and Siding	25*
Barret South End and Siding.....	25*
*Indicates Loaded Bulk Commodity Trains	10
Tons per Operative Brake	
When maximum subdivision speed is over 45 MPH, the maximum speed permitted will be determined by the tons per operative brake.	
100 or less	No Restriction
101 to 110	55
111 to 120.....	50
Over 120	45

Radio Channels

	AAR	Dispr Call In
Road	010-010	
Yard	063-063	
Disp.	016-010	1
Critical Incident Desk	016-010	3

TrAM Area

The Alexandria Sub is TrAM Area 1.

Movement Authority

Track Warrant Control (TWC) is in use between CP 561 and Latanier.

Main Track Designation

Two main tracks are in use at CP 561 and Alex Jct.

Positive Train Control (PTC)

PTC is in effect on the Alexandria Sub.

Yard Limits

North MP	South MP
561.8	West MT Via UP
690.0	Latanier

Interlockings/Control Points

AUTOMATIC INTERLOCKING APPROACH

LOCATIONS (MT and Siding, if applicable)

- UP RRX at MP 678.5
NWD Approach: MP 680.6.
SWD Approach: MP 675.2
- UP RRX at MP 561.9
NWD Approach: MP 562.7

Movements over Public Crossings

Automatic Warning Devices Used Infrequently:

- MP 604.3 – LA 179 – Ringgold Street (House Track only)
- MP 621.5 – Edenborne Street (House Track only)

Trackside Warning Detectors

Mile Post	Type of Detector	Call Back
566.5	HBD/DED/Oversized Load (C) (N)	#88
579.3	HBD/DED	
590.6	HBD/DED	
599.3	HBD/DED	
606.1	High Water	
611.3	HBD/DED	
626.6	HBD/DED	
640.7	HBD/DED	
651.5	HBD/DED	
662.3	HBD/DED	
683.1	HBD/DED (C) & (S)	
686.9	DED	

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
Elm Grove N Switch	S	577.1	2,725
Elm Grove S Switch	N	577.7	2,725
East Point N Switch	S	592.0	1,450
East Point S Switch	N	592.3	1,450
North I.P. Pass	S	603.0	2,517
Hood Industrial N Switch++	S	603.2	1,000
Hood Industrial S Switch++	N	603.6	1,000
South I.P. Pass	N	603.6	2,517
North Coughatta	S	604.2	1,714
North Coughatta Team++	S	604.2	1,530
Grappe Bluff N Switch	S	614.9	3,638
Grappe Bluff S Switch	N	615.7	3,638
North Kraft	S	616.5	1,370
South Kraft	N	617.8	1,370
Campiti 726+	N	621.8	1,000
Port of Natchitoches	N	626.4	12,109
Linn		627.9	
Madden Spur	N	629.6	1,000
St. Maurice		634.2	
North Montgomery	S	642.3	1,660
South Montgomery	N	642.7	1,660
North Colfax	S	656.7	5,254
Colfax Team Track++	S	657.0	1,549
South Colfax	N	657.7	5,254
CP 665		665.0	
North Mallin	S	678.6	2,835
South Mallin Lead	N	679.2	2,835
North House Track	S	680.5	814
North Pineville	S	680.7	2,100
South Pineville	N	681.2	2,100
Pineville Jct.	N	681.4	Conn
Alexandria Industrial Spur	N	686.9	Lead
North Latanier		690.0	

+ Indicates Connected to Siding

+ + Indicates Connected to a Business Track

US Southern Region Timetable

General Information

Grappe Bluff

All Northbound trains doing work at Grappe Bluff must leave the first crossing South of the South Switch at Grappe Bluff clear at all times while making a pickup or set out.

Kraft

Trains that will work Kraft will need to contact TNT Rail Services before arrival. SWD trains need to contact TNT at MP 615.0 and NWD trains need to contact TNT at MP 619.0.

Milepost Equalization – MP 686 & MP 687

There is 11,687 feet between MP 686 and MP 687.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	NEW ORLEANS SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Latanier		Mile Post Location				
3133	CB	YL	0.0	(Alexandria Sub) LATANIER SSS Latanier	691.9 695.5	MP 691.1 – MP 695.5			
				8.6					
3141			8.6	NSS Bijou BIJOU SSS Bijou	700.0 700.5 701.0				702.4 705.6
				9.0					
3149			17.6	NSS Hessmer HESSMER SSS Hessmer	708.6 709.5 710.5		9,556		713.3 724.5
				17.4					
3167			35.0	NSS Hyde HYDE SSS Hyde	726.5 726.9 727.4				727.7
				2.3					
	A		37.3	ATCHAFALAYA RIVER BRIDGE	729.2				729.7
				3.4					
3173			40.7	NSS Keller KELLER SSS Keller	731.5 732.6 733.9		12,489		737.2
				10.5					
3175			51.2	NSS Batchelor BATCHELOR SSS Batchelor	742.6 743.1 743.6				745.2 747.1 749.8
				7.9					
3176			59.1	NSS Morganza MORGANZA SSS Morganza	750.9 751.0 751.3				
				4.0					
3195			63.1	NSS Labarre LABARRE SSS Labarre	754.1 755.0 755.8		8,749		758.6
				5.7					
3177			68.8	NSS New Roads NEW ROADS SSS New Roads	760.5 760.7 761.0				
				1.9					
			70.7	CAJUN ELECTRIC SPUR	762.6				776.3
				17.3					
3225			88.0	# Lobdell North LOBDELL	779.1 779.9		8,119		
				0.8					
			88.8	# LOBDELL JCT.	780.7				
				0.8					
			89.6	# WEST JCT.	781.5				782.3 783.2
				3.3					
			92.9	# EAST JCT.	784.8				
				0.4					
		YL	93.3	BRIDGE JCT.	785.2	MP 784.8 – MP 787.3			785.0
				2.2					
	G	6.28	95.5	CN RRX	787.4				
				1.0					
3227	C B T	YL	96.5	BATON ROUGE	788.4	MP 788.3 – MP 790.3			792.5
				6.3					
3236		TWC ABS	102.8	NSS Essen ESSEN SSS Essen	794.0 794.7 795.4		6,824		
				Continued next page					

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	NEW ORLEANS SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuos Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Latanier		Mile Post Location				
				15.0					802.7
3251		TWC ABS	117.8	NSS Gonzales GONZALES SSS Gonzales	809.1 809.7 810.3		5,897		815.3
				8.4					
3259			126.2	NSS Barmen BARMEN SSS Barmen	817.5 818.1 818.6				
				2.4					
3261			128.6	NSS McElroy MCELROY SSS McElroy	820.4 820.5 820.7				
3269	T		136.5	NSS Gramercy GRAMERCY SSS Gramercy	827.9 828.4 828.9	MP 834.5 – MP 836.1		832.1	
			6.7						
3276	C B T	ABS YL	143.2	NSS Reserve RESERVE SSS Reserve	834.5 835.1 836.1				
				4.3					
3280		TWC ABS	147.5	NSS Montegut MONTEGUT SSS Montegut	838.8 839.4 840.0				5,832
				8.0					
3287			155.5	NSS Norco NORCO SSS Norco	846.8 847.4 847.8				
				7.5					
3295			163.0	NSS Frellsen FRELLSEN SSS Frellsen	854.3 854.9 855.5	5,991			
				10.1					
			Operation via CN RR between Frellsen Jct. (CN MP 443.5 Baton Rouge Subdivision) and Shrewsbury Old Main (CN MP 906.9 McComb Subdivision)						
3308	B T	6.28	173.1	NEW ORLEANS (End of Line)	865.0				

	MPH
MAXIMUM SPEED	49
Exceptions:	
MP 728.8 – MP 729.5	20
MP 747.3 – MP 748.1	40
MP 754.1 – MP 755.8	40
MP 780.7 – MP 790.3	20
MP 790.3 – MP 793.6	HER 30
MP 844.5 – MP 846.3	10
MP 846.3 – MP 848.6	25
MP 855.5.....	HER 20
All Switches and Sidings unless listed below	10
Through Turnouts and on Sidings	
Hessmer North End & Siding	25*
Keller South End & Siding.....	25*
Essen South End & Siding	25*
LaBarre Both Ends & Siding	40
* Indicates Loaded Bulk Commodity Trains	
	10

Yard Tracks (Including Turnouts)	
New Orleans West Yard	
Zone 2 Tracks 1-15	15
Zone 2 Track 500	15
Baton Rouge Yard	
Zone 1 Track 1	20
Zone 1 Track 2	15
Zone 1 Track 500 (ML).....	15
Through Turnouts and on Sidings	
Zone 1 Tracks 3-21	15
Zone 1 South Lead.....	15
*North Lead Turnouts limited	10
Latanier Yard	
Zone 6 Track 601	15
Zone 6 Track 1-5.....	15

US Southern Region Timetable

Tons per Operative Brake

When maximum subdivision speed is over 45 MPH, the maximum speed permitted will be determined by the tons per operative brake.

100 or less	No Restriction
101 to 110	55
111 to 120	50
Over 120	45

Radio Channels

	AAR	Dispr Call In
Road	010-010	
Yard	063-063	
Disp.	016-010	1
Critical Incident Desk	016-010	3
CN	054-054	5

TrAM Area

The New Orleans Sub is TrAM Area 1.

Block System

Centralized Traffic Control (CTC) is in use between Lobdell and East Jct. and between CN MP 855.7 – MP 862.9.

Movement Authority

Track Warrant Control (TWC) is in use between Bijou and Lobdell, Essen and Reserve, Montegut and Frellsen.

Positive Train Control (PTC)

PTC is in effect on the New Orleans Sub.

Yard Limits

North MP		South MP
691.1	Latanier	695.5
784.4	Bridge Jct.	787.3
788.3	Baton Rouge	790.3
834.5	Reserve	836.1

Interlockings/Control Points

MANUAL INTERLOCKING APPROACH

LOCATIONS (Main Track and Siding, if applicable):

- East Bridge CN RRX at MP 906.4 (CN McComb Subdivision) NWD Approach: MP 863.1

Automatic Interlocking Approach Location:

(Main Track and Siding, if applicable)

- D&E RRX at MP 433.8
NWD Approach: MP 438.0; SWD Approach: MP 428.8

ATCHAFALAYA RIVER BRIDGE, MP 729.2, AUTOMATIC INTERLOCKING INSTRUCTIONS

If Home Signal Fails to Display a Proceed Indication:

1. Operate button on signal mast at home signal and hold 5 seconds before releasing.
2. If signal does not change to a favorable indication after waiting 5 minutes:
 - a) Place first derail in hand position and line for rail traffic. Proceed over derail on proper signal from crew member.
 - b) After one unit or one car has passed over first derail, restore derail to Power position.

- c) Ascertain from the Bridge Tender or by a member of the crew inspecting the moveable span bridge, that the rails are aligned properly and supported at each end of the turn span. Train may then proceed to opposite end of the bridge.
- d) Place derail on opposite end of bridge in hand position and line for rail traffic. Proceed over second derail on proper signal from crew member.
- e) After one unit or one car has passed over second derail, restore derail to Power position.
- f) Notify train dispatcher of signal problem.

Home signals at bridge will not display proceed indication for reverse movement until train has cleared the IA circuit located at MP 727.0 and MP 731.7.

Equipment Restrictions

Six Axle Locomotives Prohibited from Operating On The Following Tracks:

- Baton Rouge Yard Tracks 8 – 23

Movement over Public Crossing

Automatic Warning Devices Used Infrequently:

- MP 785.7 – Gulf States Road (Track 48 only)
- MP 786.4 – Exxon 12th Street (Track 48 and East Pass only)

Trackside Warning Detectors

Mile Post	Type of Detector	Call Back
702.4	HBD/DED/Oversized Load (C) (N)	#88
705.6	DED	
713.3	HBD/DED	
724.5	HBD/DED/Oversized Load (C) (S)	
727.7	DED	
729.7	DED	
737.2	HBD/DED/Oversized Load (C) (N)	
745.2	DED	
747.1	HBD/DED	
749.8	DED	
758.6	HBD/DED	
776.3	HBD/DED/Oversized Load (C) (S)	
782.3	DED	
783.2	DED	
785.0	DED	
792.5	HBD/DED	
802.7	HBD/DED	
815.3	HBD/DED	
832.1	HBD/DED	
843.5	DED	
846.8	DED	
850.0	HBD/DED	

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
North Bijou	S	700.0	5,465
South Bijou	N	701.1	5,465
Hessmer House Track	N	708.8	400
Moreauville		717.2	
North Hyde	S	726.5	4,089
South Hyde	N	727.4	4,089
Keller Wood Yard +	S	733.9	2,000

US Southern Region Timetable

Name	DOE	MP	Footage
North Morganza	S	750.9	1,594
South Morganza	N	751.3	1,594
North New Roads	S	760.5	1,933
South New Roads	N	761.0	1,933
Cajun Electric	N	762.6	
Glynn	S	768.2	100
UP Connection	S	780.7	IND
Baton Rouge		790.4	
Prairieville	N	805.2	450
Gonzales Team Track	S	810.4	550
Economy Brick	N	810.8	530
Smith Tank & Steel	S	812.5	1,500
Sorrento	S	815.8	500
North Barmen	S	817.5	5,336
South Barmen	N	818.6	5,336
McElroy North Switch	S	820.4	1,427
McElroy South Switch	N	820.7	1,427
North Gramercy	S	827.9	4,379
South Gramercy	N	828.9	4,379
Colonial North Wye Switch	S	828.6	IND
Colonial South Wye Switch	N	828.9	IND
Kaiser North Wye Switch	S	829.8	WYE
Kaiser South Wye Switch	N	830.0	WYE
Marathon	S	833.5	LEAD
Reserve North Wye Switch	S	835.2	WYE
Reserve South Wye Switch	N	835.5	WYE
Baumer Foods	S	835.8	650
DPC Enterprises	S	836.0	2,117
North Norco	S	846.8	4,822
South Norco	N	847.8	4,822
North Diamond Green	S	848.1	1,750
Good Hope Refinery	S	848.2	IND
South Diamond Green	N	848.4	IND
Welling Truck Services	S	854.9	1,120
Frellsen Jct.		855.6	

+ Indicates Connected to Siding

Switch Information

Radio Controlled Switches

Norco North Diamond Green

Radio Channel 010-010

Normal DTMF #848011 Reverse DTMF #848022

Norco South Diamond Green

Radio Channel 010-010

Normal DTMF #848411 Reverse DTMF #848422

Industry Route Reverse DTMF #848433

Power Assisted Switches (PAS):

LaBarre (North)

Radio Channel 010-010

Normal DTMF #754111 Reverse DTMF #754122

LaBarre (South)

Radio Channel 010-010

Normal DTMF #755811 Reverse DTMF #755822

Spring Switch Locations

North Hessmer – MP 708.6

South Keller – MP 733.9

South Essen – MP 795.4

North Gonzales – MP 809.1

North Barmen – MP 817.5

South Montegut – MP 840.0

North Frellsen – MP 854.3

General Information

CPKC-Up Joint Track Between MP 735.6 Lettsworth And MP 780.7 Lobdell Junction

UP employees will be governed by the GCOR, CPKC Timetable, Special Instructions, and CPKC General Orders.

Labarre

The west track is designated as the siding.

Lobdell - Baton Rouge Terminal Area

1. Trains doubling over the Mississippi River Bridge (MP 783.2) must not leave any part of the train on the steel structure.

CPKC dispatcher controls CTC between East Junction (MP 784.8 and North Lobdell MP 779.1).

Northward trains must contact yardmaster before passing South Essen – MP 795.4.

All Northward movements entering CTC at East Junction, MP 784.8, must obtain verbal permission from CPKC train dispatcher.

Southward trains must contact CPKC train dispatcher for TWC authority before leaving Baton Rouge.

Do not exceed five (5) MPH from West Jct. Switch to West Switch at Port Yard

Southward Trains and Engines must contact Baton Rouge Yardmaster before entering Yard Limit at East Jct. MP 784.8.

Bridge Junction

The switch at Bridge Junction, Mile Post 785.2, is operated by radio control (DTMF CONTROLLED) and is equipped with a switch point indicator as defined by GCOR Rule 8.10.

To line the switch for the Main Line use road channel 010-010 and press in code #785211.

To line the switch for the "D" Line use road channel 010-010 and press in code #785222.

Switch Point Indicator at the switch will indicate the switch positions as follows:

GREEN light will indicate switch is lined for the Main Line.

YELLOW light will indicate switch is lined for the "D" Line.

RED light will indicate switch is not lined or out of correspondence and movement must be stopped short of the switch.

When a Red indicator light is encountered the switch must be operated by hand. If necessary to operate the switch by hand, do not restore the switch to power operation until at least one unit or car has passed over the switch points. When a train or engine is within 300 feet of the switch, the switch will be locked and cannot be operated by radio control. The switch can be left lined as last used.

US Southern Region Timetable

2. "D" Line Operations: MP D-209.7 - D-221.4: All movements must be made as per Rule 6.28 between MP D-209.7 and D-213.0 movements must not exceed 10 MPH. Between MP D-213.0 and MP 221.4 movement must not exceed 20 MPH.

Automatic interlocking with CN located MP D-220.1.

Automatic interlocking with CN located at MP D-217.99.

3. UTL lead off "D" Line, MP D-216.0 begins the Baton Rouge Southern Railroad.

CN RRX at MP 787.4 is protected by a gate.

Norco

1. The first road crossing north of the south siding switch at Norco, commonly referred to as the "Rubber" crossing, serves the Shell Oil Company Polypropylene Plant and must not be blocked with cars. Cars set out by through trains must be left clear of this crossing.

2. Do not exceed five (5) MPH over Norco Plant Lead.

3. Do not exceed five (5) MPH over L&A 3 and 4.

4. Do not exceed five (5) MPH inside CII Carbon Plant at Norco.

Diamond Green

North and South Diamond Green are equipped with Radio Control Switches (RCS). These switches can be controlled by DTMF on the radio keypad, or by using a push button located at the switches.

These switches will restore to the normal position 60 seconds after movement has been made through the limits of the OS. Movement over the switches will be governed by ABS signals. At RCS locations, there will be signals marking the limits of the OS. For the RCS to operate by DTMF or by push button located at the switch, the limits of the OS must not be occupied. Do not exceed 5 MPH while weighing cars on Diamond Green.

Operating a Radio-Controlled Switch:

1. To operate a Radio-Controlled Switch (RCS), a crew member must perform the following:

Upon passing the wayside sign reading "switch control" placed for South bound trains at MP 846.17 and for North bound trains at MP 850.87, a crew member must enter the proper DTMF sequence for the desired switch position for BOTH North and South Diamond Green.

2. A train must approach a Radio-Controlled Switch prepared to stop short of the OS until:

A. A DTMF command has been issued to request the switch for the desired position.

and

B. The ABS signal approaching the Radio Controlled Switch displays a more favorable aspect than approach.

or

C. The signal at the switch displays that the switch is properly lined for movement.

3. If the train has not passed the signal at the requested switch within 15 minutes after entering the proper DTMF sequence, the train must approach the Radio Controlled Switch prepared to stop.

4. If a change is needed from the original requested route, the train must stop outside the limits of the OS at the Radio-Controlled Switch and:

A. Wait 15 minutes then enter the proper DTMF sequence for the desired position,

or

B. Wait 15 minutes and operate the push button located on the signal case to line the switch for the desired position.

NOTE: Permission to operate the dual control switch by hand in accordance with GCOR Rule 9.13.1 is granted without having to contact the control operator.

5. If the signal approaching a Radio-Controlled Switch displays a more favorable aspect than approach and the Radio-Controlled Switch signal displays a red or dark aspect, the crew must:

A. Stop the train before entering the OS if consistent with good train handling

B. Inspect the switch

and

C. Report it to the control operator

NOTE: Permission to operate the dual control switch by hand in accordance with GCOR Rule 9.13.1 is granted, but the control operator must be notified of the signal indication.

6. If after entering the proper DTMF sequence, the signal continues to display a stop indication and the train is authorized beyond the signal, the train has permission to pass the stop indication at restricted speed without contacting the control operator, only after operating the RCS by hand.

7. The industry track switch in the scale track at Diamond Green operates in conjunction with the South main line switch (i.e., if entering the code to occupy the scale track or industry track, the main line switch and the switch in the scale track will both line and lock for movement into the designated route.)

NOTE: Only one of the three codes needs to be entered for a given route at South Diamond Green.

Movement across CNIC Track from Frellsen Jct. To CPKC New Orleans

Baton Rouge: Southward trains before departing Baton Rouge for New Orleans must have a copy of current CN Daily Operating Bulletins for the McComb and Baton Rouge Districts. Train crews will verify Daily Operating Bulletin number(s) with CN Rail Traffic Controller (RTC) and have permission from CN Mays Yard before passing South Frellsen.

New Orleans Yard: Northward trains departing New Orleans must have a copy of the current CN Daily Operating Bulletins for the McComb and Baton Rouge Districts. Train crews will verify Daily Operating Bulletin number with CN RTC and have permission from CN Mays Yard before departing New Orleans Yard.

All trains must keep radio on CN Channel 054-054 while operating on CN track. The CN train RTC can be contacted on this channel.

CN Telephone Numbers are:

CN Desk 5 Disp 833-493-7827 Press 1 Ext 5810

CN Chief Dispatcher (708) 332-6750

CN Chief Dispatcher FAX..... (708) 206-6775

New Orleans Yard

1. The train dispatcher will issue TWC authority to northward trains before arriving Frellsen Jct. This will not modify or supersede rules or instructions governing operation via CN but permits trains to depart New Orleans yard after verbal authority is obtained to enter CN CTC territory.
2. CPKC train and engine movements between Frellsen JCT and CPKC New Orleans yard will be made via CN railroad and east bridge interlocker. Be governed by CN Operating Rules, CN Timetable and special instructions, and CN TGBO.
3. The Maximum Authorized Speed through the turnout in the East Bridge interlocking is 10 MPH.
4. CPKC train movements between New Orleans yard and the NOPB's Cotton Warehouse yard will be made via the CN Railroad at Lambert Jct. for approximately 1800 feet to the NOPB connection. Movements via this route will be controlled by and authorized by East Bridge Tower. CN Operating Rules will govern CPKC train movements between Lambert Junction and NOPB Connection. NOPB General Code of Operating Rules, Timetable, General Orders and Bulletins will govern CPKC train movements while occupying NOPB.
5. All movements between Lambert Junction and Southport will be made per GCOR 6.28.
6. All tracks at Cotton Warehouse Yard, located at NOPB New Orleans are designated as interchange tracks for CPKC interchange to CSXT Railroad.

NOTE: Do not exceed 8,000 feet for CSXT train in New Orleans.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	BEAUMONT SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Frierson		Mile Post Location				
0577		CTC	0.0	(Shreveport Terminal Sub) FRIERSON	577.0				578.2
				3.5					
0580	T		3.5	# Bayou Pierre North BAYOU PIERRE # Bayou Pierre South	580.3 580.5 580.8				
				10.8					588.6
0592			14.3	# Mansfield North MANSFIELD # Mansfield South	588.9 591.3 591.7		13,834		
				6.7					
0599			21.0	TRENTON	598.0				601.0
				6.5					
0605			27.5	BENSON	604.5				
				5.6					
0611			33.1	# Converse North CONVERSE # Converse South	609.6 610.1 611.5		9,373		
				11.7					614.9
0623			44.8	ZWOLLE	621.8				
				4.1					
0627			48.9	# Loring North LORING # Loring South	625.3 625.9 626.5		5,600		
				7.4					629.3
0634			56.3	MANY	633.3				
				5.6					
0640			61.9	FISHER # Fisher North # Fisher South	638.9 639.0 641.3		11,266		
				19.7					645.2
0660			81.6	# Anacoco North ANACOCO # Anacoco South	658.0 658.6 659.6		8,376		
				9.8					663.0
0669	B C		91.4	# Leesville North LEESVILLE # Leesville South	668.2 668.4 670.3		10,495		
				4.2					
	T		95.6	DAUB (Fort Polk)	672.6				
				7.3					
0680			102.9	# Neame North NEAME # Neame South	678.9 679.9 681.0		8,835		
				7.1					683.4
0687			110.0	LUDINGTON	687.0				
				2.2					
0690			112.2	DERIDDER	689.2				
				0.6					
	A		112.8	TIBR RRX	689.8				697.3
				15.3					
0705			128.1	# Singer North SINGER # Singer South	704.4 705.1 705.8		6,906		
				13.9					708.8
0719	T		142.0	DEQUINCY	719.0				717.5
				1.3					
			143.3	# CS JUNCTION (UP Conn)	720.3				
				Continued next page					

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation		NORTHWARD ↑	BEAUMONT SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
				Distance From Frierson		Mile Post Location				
				143.7	0.4 # LONG LEAD (UP Conn)	720.7				
					2.9					
0724				146.6	# Helme North HELME # Helme South	723.1 723.6 725.3		10,574		
					4.8					
0729				151.4	# Lucas North LUCAS # Lucas South	726.6 728.4 729.0		11,887		
					6.8					
0736				158.2	# Starks North STARKS # Starks South	734.2 735.2 735.9		8,133		
					5.4					
0741				163.6	RULIFF	740.6				
					9.6					
0751				173.2	# Mauriceville North MAURICEVILLE # Mauriceville South	748.1 750.2 750.2		10,528		
					0.0					
				173.2	SRN RRX	750.2				
					10.2					
0761				183.4	# Vidor North VIDOR # Vidor South	760.1 760.4 762.8		13,448		
					4.5					
				187.8	# CP 765	764.9				
					1.1					
	M			189.0	BEAUMONT (Neches River Bridge)	766.0				
					0.1					
	M	C T C	C T C	189.1	PORT OF BEAUMONT RRX	766.1				
					0.6					
	T	W MT	E MT	189.6	# STATION 13 GCL JCT. (East MT)	766.5			CQ 766.3 to 766.5	
					2.4					
0769	B C			192.1	CHAISSON	769.1				
					0.7					
	A			192.8	UP RRX	769.8				
					9.8					
0779	T			202.6	NECHES JCT.	779.6				
					6.5					
0787				209.1	PORT ARTHUR (UP)	786.1				

MAXIMUM SPEED	MPH
	59
Exceptions:	
MP 583.1 – MP 583.5	45
MP 588.0 – MP 588.5	40
MP 588.5 – MP 591.0	50
MP 607.0 – MP 608.0	45
MP 615.5 – MP 620.0	45
MP 623.0 – MP 631.0	45
MP 635.0 – MP 639.0	45
MP 645.9 – MP 647.7	45
MP 647.7 – MP 650.3	40

	MPH
MP 650.3 – MP 657.2	45
MP 657.2 – MP 660.0	50
MP 665.5 – MP 666.2	45
MP 674.5 – MP 677.9	50
MP 689.7 – MP 689.9	40
MP 718.7 – MP 720.3	40
MP 750.2 – MP 750.2	40
MP 764.9 – MP 765.1	HER 20
MP 765.6 – MP 766.1	20
East and West MT	
MP 766.1 – MP 766.9	20

US Southern Region Timetable

MPH

Wall St MT

MP 766.8 – MP 767.210

Chaison MT

MP 766.5 – MP 766.6 10

MP 766.6 – MP 768.0 20

MP 768.0 – MP 769.8 10

MP 769.8 – MP 779.120

MP 779.2 Port Neches Jct. Wye10

MP 779.3 – MP 779.520

MP 779.6 Port Neches Jct. Wye10

MP 779.7 – MP 784.8 20

MP 784.8 – End of Track 10

All Switches and Sidings unless listed below10

Turnouts and Sidings

Converse, Anacoco, Neame,

Singer, Starks, Mauriceville25

Loring 25*

Mansfield & Fisher30

North DeQuincy40

Helme and Lucas40

Station 1425

CS Junction25

Vidor30

UPRR Connection (CP 765)25

*Indicates Bulk Commodity Trains10

Bayou Pierre Ind. Lead

Maximum speed 20 MPH between East Wye switch and International Paper Co., Marshalling Yard.

Tons per Operative Brake

When maximum subdivision speed is over 45 MPH, the maximum speed permitted will be determined by the tons per operative brake.

Over 150 45

Radio Channels

	AAR	Dispr Call In
Road	013-013	
Yard-North Frierson to MP 777	063-063	
Yard-MP 777 to Port Arthur	076-076	
Disp.	052-013	1
Critical Incident Desk	052-013	3

TrAM Area

The Beaumont Sub is TrAM Area 2.

Block System

Centralized Traffic Control (CTC) is in use between Frierson and Chaison.

Main Track Designation

Two main tracks are in use at between Port of Beaumont and Chaison.

Rule 6.28 Other than Main Track

Other than Main Track used between Chaison and Port Arthur.

Positive Train Control (PTC)

PTC is in effect on the Beaumont Sub.

Interlockings/Control Points

Automatic Interlocking Approach Locations:

(Main Track and Siding, if applicable)

- SRN RRX at MP 750.2
 - NWD Approach MP 752.9
 - SWD Approach MP 748.1
- TIBR RRX at MP 698.8
 - NWD Approach MP 692.8
 - SWD Approach MP 688.0
- Station 14 (East & West MT) MP 766.1
- Station 12 (Chaison MT & Wall Street MT) MP 766.7
- Station 11 (East & West MT & Wall Street MT) MP 766.8
- North Dequincy Wye MP 718.8

Deridder

The interlocking signals at the CPKC/TIBR crossing at MP 689.8 are also designated as a control point. When a crew encounters a STOP signal at this location and fails to receive a proceed indication after following instructions in the release box, authority must be received from the train dispatcher before proceeding, except when operating within the limits of track and time.

Neches River Bridge, MP 765.8

The drawbridge is a manual interlocking controlled by the CPKC Train Dispatcher. Trains encountering a STOP indication must communicate with the Train Dispatcher after stopping, and if given verbal authority to pass the STOP indication, must inspect moveable span bridge and determine that the rails are aligned properly and that the rails are supported at each end of the span before proceeding.

Mauriceville

The interlocking signals at the CPKC/SRN crossing at MP 750.0 are also designated as a control point. When a crew encounters a STOP signal at this location and fails to receive a proceed indication after following instructions in the release box, authority must be received from the train dispatcher before proceeding, except when operating within the limits of track and time.

UP Interlocking Instructions - Beaumont

Trains and engines encountering a STOP indication at the UP interlocking located at MP 769.8, after verifying that signals on the conflicting route indicate STOP and no conflicting movement is evident, may proceed through the interlocking at Restricted Speed. When signals on the conflicting route do not indicate STOP and conflicting movement is evident, train or engine must not proceed until both crews agree on the next movement.

US Southern Region Timetable

Equipment Restrictions

Train Make-Up Restrictions

Distributed Power:

Other than unit trains, southbound trains in excess of 10,000 tons must have distributed power.

Southbound trains and northbound trains originating in Beaumont/Port Arthur exceeding 10,000 feet must have distributed power placed in train approximately two thirds of the train's length from the lead locomotive consist.

Six Axle Locomotives Prohibited From Operating On The Following Tracks:

- Asbury Graphite (Green Island) – MP 726.8
- SRN Conn (Lemonville) – MP 748.1
- Mauriceville Team – MP 750.0
- Vidor Team – MP 760.2
- Chaison Branch beyond track 760 – MP 768.4
- Gulf Yard Main Line past the Oxbow Switch – MP 786.0

Continuous Quiet Zone – GCOR 5.8.4

Neches St MP 766.37
Eastham Forge..... MP 766.53

Electric Locks

Station	MP	Location of switch
Trenton	597.6	North Trenton
Trenton	598.4	South Trenton
Benson	604.0	North Benson
Benson	605.0	South Benson
Zwolle	621.5	North Zwolle
Zwolle	622.3	South Zwolle
Daub	672.6	Daub N Leg Wye
Daub	673.2	Daub S Leg Wye
Ludington	686.4	N Ludington Storage
Ludington	687.2	S Ludington Storage
Ludington	687.4	Boise Cascade
Deridder	689.1	North Deridder
Westvaco	690.3	Westvaco
DeQuincy	719.2	N DeQuincy Pass
DeQuincy	720.2	S DeQuincy Pass
DeQuincy	720.2	DeQuincy Yard
DeQuincy	721.5	DeQuincy Ind. Park

Trackside Warning Detectors

Mile Post	Type of Detector	Call Back
578.2	HBD/DED	#88
588.6	HBD/DED	
601.0	HBD/DED	
614.9	HBD/DED	
629.3	HBD/DED	
645.2	HBD/DED	
663.0	HBD/DED/Oversized Load	
683.4	HBD/DED/Oversized Load	
697.3	HBD/DED	
708.8	HBD/DED	
717.5	HBD/DED	
726.0	HBD/DED	
743.4	HBD/DED	
752.3	HBD/DED	
763.8	HBD/DED (C) (S)	
764.9	DED/Oversized Load	
766.4	DED/Oversized Load	

FRA Excepted Track

FRA Excepted Track from Bayou Pierre International Paper at Marshalling Yard Track 700 through 730 including the main track.

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
Blazer	S	591.2	1,100
Madden North	S	595.5	2,950
N Madden Construction ++	S	595.5	2,656
S Madden Construction ++	N	596.1	2,656
Madden South	N	596.1	2,950
North Trenton	S	597.6	3,530
South Trenton	N	598.4	3,530
North Benson	S	604.0	4,634
South Benson	N	605.0	4,634
Converse Team Track +	N	610.3	125
Willamette Industry	S	621.4	261
North Zwolle	S	621.5	3,550
Zwolle Railcar Company ++	N	622.2	200
South Zwolle	N	622.3	3,550
Many Storage	S	633.1	800
Many Team Track +	S	633.2	250
Boise Cascade	S	641.3	284
Florien	S	642.3	1,600
Hawthorne	S	664.0	600
Prairie Rock Track +	S	668.5	4,600
North Yard Lead +	S	668.6	2,300
North Leesville Yard ++	S	668.6	4,455
South Leesville Yard ++	N	669.5	4,455
South Yard Lead +	N	669.5	2,300
Daub North Leg Wye	S	672.6	WYE
Daub South Leg Wye	N	673.2	WYE
North Ludington Storage	S	686.4	3,156
North Ludington Storage YD 1 S	S	686.5	3,297
North Ludington Storage YD 2 S	S	686.5	3,146
South Ludington Storage YD 2N	S	687.2	3,146
South Ludington Storage YD 1N	S	687.2	3,297
South Ludington Storage	N	687.2	3,156
Ampacet	S	687.3	290
Boise Cascade	S	687.4	LEAD

US Southern Region Timetable

Name	DOE	MP	Footage
North Deridder	S	689.1	1,952
Prairie Rock Plant ++	S	689.1	1,250
CP 689		689.8	CP
Chevron Track ++	N	690.0	500
Deridder Team Track	N	690.0	560
Westvaco	S	690.3	1,003
Singer Team Track +	S	704.6	680
North DeQuincy Pass	S	719.2	4,495
South DeQuincy Pass	N	720.2	4,495
DeQuincy Yard	N	720.2	5,600
DeQuincy Industrial Park	N	721.5	1,100
Asbury Graphite +	S	726.8	1,145
DeQuincy Industrial Park	N	721.5	1,100
Asbury Graphite +	S	726.8	1,145
SRN Conn +	S	748.1	LEAD
Mauriceville Team +	N	750.0	200
Vidor Team	S	760.2	200
CP 765		764.9	CP
North Star Steel	N	765.0	1,515
Jefferson Refinery	S	765.0	IND
Station 15 (Neches River Bridge)		765.8	
Station 14 (East & West MT)		766.1	
BNSF Port Conn	N	766.1	IND
CPKC/UP Port Conn	N	766.1	IND
Station 12 (Chaison MT & Wall St MT)		766.7	
Station 11 (E&W MT & Wall St MT)		766.8	
Wilson Warehouse	N	770.1	1,250
Texas Gulf Sulphur	N	771.4	YARD
DuPont Big 3	S	773.4	IND
DuPont Corp.	N	773.5	LEAD
Sun Team Track	S	774.9	1,280
Sun Jct.	S	775.1	1,609
Sunoco PAS	S	775.5	IND
North Neches Jct. Wye	S	779.2	WYE
South Neches Jct. Wye	N	779.6	WYE
North Neches Jct. Yard	S	779.6	3,526
South Neches Jct. Yard East	N	780.3	IND
South Neches Jct. Yard West	N	780.3	3,526
North Motiva	S	784.1	YARD
South Motiva	N	785.1	YARD
North Port Arthur Yard	S	785.6	YARD

+ Indicates Connected to Siding
++ Indicates Connected to Business Track

Switch Information

Madden

Dual control derails are installed on the Madden industry tracks. These derails operate in conjunction with the main line switches. When operating the North dual control switch by hand it is also necessary to operate the switch point derail by hand. When operating the South dual control switch by hand it is also necessary to operate the switch point derail by hand.

DTMF Yard Switches are installed on both ends of Madden industry track. When entering the industry tracks it will be necessary to operate the DTMF switches.

North industry track switch DTMF code: normal switch to 702 Track DTMF #595511 – reverse switch to 701 Track DTMF #595522.

South industry track switch DTMF code: normal switch to 702 Track DTMF #596111 – reverse switch to 701 Track DTMF #596122.

Neches Junction

DTMF Yard Switches are installed on the Neches Junction North Wye, Neches Junction East Wye, and Neches Junction South Wye. When approaching a Wye Yard switch, it will be necessary to operate the DTMF switches.

Neches Junction North Wye switch DTMF code: normal switch DTMF #779211– reverse switch DTMF #779222.

Neches Junction East Wye switch DTMF code: normal switch (South Leg) DTMF #779311 – reverse switch (North Leg) DTMF #779322.

Neches Junction South Wye switch DTMF code: normal switch DTMF #779511 – reverse switch DTMF #779522.

South USA Rail Terminal

A DTMF Yard Switch is installed for the USA Rail Terminal. A power derail is installed on the industry track that works in conjunction with the main line switch. If necessary to operate the main line switch by hand, the derail must also be operated by hand. When entering the industry track it will be necessary to operate the DTMF switches.

DTMF code: normal switch DTMF #780511 – reverse switch DTMF #780522.

Jefferson Refinery

A dual control derail is installed on the industry track. This derail operates in conjunction with the dual control main line switch. When operating the main line switch by hand it is also necessary to operate the derail by hand.

Beaumont

Signals and dual control switches between Langham Road and Wall Street and between South Street and Crockett Street are controlled by UP control operators.

Sunoco

Dual control derail is installed on the industry track. This derail operates in conjunction with the main line PAS switch.

When operating the PAS switch by hand, it is also necessary to operate the power derail by hand.

Port Neches Branch and Belt Line

The switch to SLIC track 700, must be lined and locked for the Port Neches Belt Line when not in use. The normal position of this switch will be lined to go toward Pab-Tex.

A DTMF Yard Switch is installed for the Port Arthur Terminal. A power derail is installed on the lead track that works in conjunction with the main line switch. If necessary to operate the main line switch by hand, the derail must also be operated by hand. When entering the lead track, it will be necessary to operate the DTMF switches.

DTMF code: Normal DTMF #005811 – Reverse DTMF #005822.

US Southern Region Timetable

Power Assisted Switches (PAS):

Sunoco Industry Track

Radio Channel 063-063

Normal DTMF #775511 Reverse DTMF #775522

General Information

Fort Polk Military Base

Fort Polk Military Base has installed an electric security gate at the track entrance to the Fort Polk base, Milepost 3.5 at Highway 467. The gate will automatically open when a train is within 400 feet of either side of gate. All trains must be prepared to stop at the gate until the gate is fully open. The gate may only be manually operated from inside the base through the use of a manual switch located inside the gate.

Dequincy

Number 1 Track (south leg of the wye) at DeQuincy is other than main track.

Trains moving via Number 1 Track at DeQuincy must be within fifty (50) feet of either side of Louisiana Highway 12 (Fourth Street) to activate highway crossing warning devices.

Lemonville

Trains and engines will not exceed 5 MPH within 2,000 feet of the north and south switches to the SRN interchange tracks.

CPKC trains and engines may enter and occupy SRN tracks at Lemonville (within 2,000 feet of the north and south switches to the SRN interchange tracks) without flag protection.

Foreign Line Trains And Engines

Foreign line trains must receive and verify CPKC Track Bulletin before entering the main track at CS Junction MP 720.3, Tower 31 MP 764.8, and Station 11 (Wall Street) MP 766.9. CPKC does not issue track warrants for bulletins.

Contact CPKC Train Dispatcher (refer to System Special Instructions for phone number) to establish signal indication, or obtain verbal authority, to enter CTC at CS Junction, Tower 31, or Station 11.

Beaumont

SWD trains on CPKC Beaumont Subdivision operating via Chaison Yard must obtain verbal permission from the CPKC Yardmaster before departing Vidor and before departing Chaison Yard southbound.

NWD trains must obtain verbal permission from the CPKC Yardmaster and CPKC Train Dispatcher before departing Chaison Yard.

EWD trains on UP Lafayette Subdivision operating via Chaison Yard must obtain verbal permission from the CPKC Yardmaster before departing Wall Street and before departing Chaison Yard southbound.

Port Arthur

Northward trains departing Port Arthur must receive verbal permission from the Yardmaster at Port Arthur before departing Port Arthur yard.

No six axle locomotives or loaded unit trains on track 532 (zero track).

Port Arthur Remote Operations

Port Arthur has been established as a Remote Control Operating Area.

A Remote-control zone is established on the North end of the Port Arthur Yard on the work lead between the clearance point of the middle track, and the south roundhouse (18 track) switch. This zone shall be identified as RCZ1.

A Remote-Control Zone is established on the south end of the Port Arthur Yard on the work lead between county road crossing, zero track switch and 18 switch. This zone shall be identified as RCZ2.

Port Arthur Roundhouse

Power operated derails, equipped with blue lights, are located at the north and south ends of the diesel shop.

To enter the limits of the blue signal:

- If blue signal is displayed, the employee must contact locomotive servicing personnel for permission to enter the limits. The employee must verify the derail is in the non-derailing position before entering the limits.
- If blue signal is not displayed, the employee must contact the yardmaster to determine if locomotive servicing personnel are on duty. If locomotive servicing personnel are on duty, the employee must receive permission from the locomotive servicing personnel to enter the limits. If locomotive servicing personnel are not on duty, the employee may enter the limits after verifying the derail is in the non-derailing position.

Before moving a locomotive within the limits of the blue signal, the employee must receive permission from locomotive servicing personnel. If unable to contact locomotive servicing personnel, determine from the yardmaster if locomotive servicing personnel are on duty. If no locomotive servicing personnel are on duty, the employee may move the locomotive. The employee must verify the derail is in the non-derailing position before departing the limits.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	LAKE CHARLES SUBDIVISION STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From DeQuincy		Mile Post Location				
0719	T	CTC	0.0	(Beaumont Sub) DEQUINCY	B-719.0				B-726.4
				0.6					
	A		0.6	UP RRX	B-719.6				
				9.1					
2729			9.7	# Buhler North BUHLER # Buhler South	B-727.5 B-728.7 B-729.1		7,546		
				4.0					
2733		6.28	13.7	# GULF STATES UTILITIES	B-732.7				
				0.7					
2734	A		14.4	TIBR RRX	B-733.4				
				2.0					
2736	B C		16.4	MOSSVILLE	B-735.4				
				3.7					
2740			20.1	WESTLAKE	B-739.1				
	A			0.3					
			20.4	END OF LINE	B-739.4				

MAXIMUM SPEED **MPH 45**

Exceptions:

MP B-719.0 - MP B-720.0	20
MP B-732.2 - MP B-732.7	25
MP B-732.7 - MP B-734.7	20
MP B-734.7 - MP B-736.7	
Including Yard Track 1-14 and the Pass	15
MP B-736.7 - B-739.4	10
All Switches and Sidings unless listed below	10

Turnouts and Sidings

Buhler.....	25*
*Indicates Loaded Bulk Commodity Trains	10

Radio Channels

	AAR	Dispr Call In
Road	013-013	
Yard	063-063	
Disp.	052-013	1
Critical Incident Desk	052-013	3
UPRR Channels		
Road	017-017	
Rosebluff Yard	040-040	
Lake Charles Yard	020-020	
West of HWY 108 Yard	024-024	

TrAM Area

The Lake Charles Sub is TrAM Area 1.

Block System

Centralized Traffic Control (CTC) is in use between DeQuincy and Gulf States Utilities.

Rule 6.28 Other Than Main Track

Rule 6.28 is in use between TIBR RRX and End of Line.

Rosebluff

All movements at Rosebluff are Rule 6.28 and include:

- PPG A – Plant Lead – 0.43 miles
- PPG B – Plant Lead – 0.75 miles
- Jupiter Chemical Lead – 1.03 miles
- CertainTeed Corp. Lead – 1.30 miles
- B.W. Service Lead – 2.00 miles

Do not exceed 5 MPH on any track within CertainTeed.

Positive Train Control (PTC)

PTC is in effect on the Lake Charles Sub.

Interlockings/Control Points

Automatic Interlocking Approach Location: (Main Track and Siding, if applicable)

- UP RRX at MP B-719.6.

NWD Beaumont Subdivision Approach: B-721.5

SWD Beaumont Subdivision Approach: B- 714.1

NWD Approach: B-724.3

US Southern Region Timetable

Movement over Public Crossings

Lotte-Axial Industry

A DTMF controlled warning device has been installed at Pete Manena Road crossing entering the Lotte-Axial Industry at Rosebluff.

When approaching the crossing it will be necessary to activate the warning devices to occupy the crossing and deactivate the warning device when clear of the crossing using DTMF tones.

DTMF 123* will activate; DTMF 123# will de-activate

Trackside Warning Detectors

Mile Post	Type of Detector	Call Back
B-726.4	HBD/DED	#88

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
South DeQuincy Wye +	N	719.2	LEAD
North Buhler Back Track +	S	727.6	7,274
South Buhler Back Track +	N	729.0	7,274
Energy Gulf States	S	732.7	IND

+ Indicates Connected to Siding

Switch Information

Mossville New Yard

DTMF Yard Switches are installed on the Main Track at milepost B-733.5 and on the Mossville North Lead milepost B-734.5. When approaching a DTMF Yard switch it will be necessary to operate the DTMF switches.

Main Track switch DTMF code:

normal switch – DTMF #733511; reverse switch to Mossville North Lead – DTMF #733522.

Mossville North Lead switch DTMF code:

normal switch - DTMF #734511; reverse switch to Mossville Lower Yard Lead - DTMF #734522

Scale Track

DTMF yard switch is installed at the south end of the scale track. When approaching a DTMF Yard switch it will be necessary to operate the DTMF switch.

South Scale Track DTMF Code: normal switch DTMF # 736011 – reverse switch DTMF #736022

Do not exceed 3 MPH over the scales when weighing and 5 MPH when not weighing.

General Information

Distributed Power

Northbound trains in excess of 10,000 feet must have distributed power placed in train approximately two thirds of the train's length from the lead locomotive consist.

Gulf States Power Plant Spur

Train crews operating empty coal trains will perform a Class IA air brake test prior to departing Buhler.

Mossville New Yard

Before leaving equipment unattended on the main track, pass, or the group of tracks numbered 1 through 14 within CPKC Mossville New Yard equipment will be secured by applying 3 handbrakes on each track, after ensuring all equipment is fully coupled. This will not apply when engaged in continuous switching operations.

Mossville

For access to Conoco, contact Phillips 66 main gate on Channel 063-063.

Remote Operations

Mossville/Westlake has been established as a Remote Control Operating Area.

A Remote-Control Zone is established on the North end of Mossville New Yard on the North lead between the two (2) track switch extending northward to the clearance point of the Mainline DTMF switch at MP B-733.5. This zone shall be identified as RCZ 1.

Prior to activating RCZ 1, the crew must disable the power functionality of the North lead switch ("Switch 45") at MP B-734.5 by placing the power toggle switch in "Disable", locking the door to the power toggle switch, and tagging the door with a sign indicating "Remote Control Mode". The switch must be restored to the power function, with locks and tags removed, prior to the remote-control crew ending tour of duty.

Westlake:

1. Trains will not perform switching over Sampson Street MP B-738.7, between 1530 hours and 1630 hours, Monday through Friday. Through movements are permissible during this time.

2. At the Trousdale road crossing, MP B-736.72, allow a minimum of twenty (20) seconds for the flashers to operate before moving over this crossing.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	ROSENBERG SUBDIVISION STATION PAGE TRAM AREA 1 # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuos Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Rosenberg		Mile Post Location				
1600		CTC UP	0.0	(UP) # ROSENBERG	892.3				
				12.2					898.1
1625	X B C		12.2	# CP 902 KENDLETON # CP 905	902.1 904.5 905.3		8,764		906.0 908.8 912.8
				13.4					
1640			25.6	# Wharton North # Wharton South WHARTON	914.8 917.2 917.9		11,644		
				13.4					
1650			39.0	EL CAMPO	931.3				923.0
				8.5					
1665			47.5	# Louise North LOUISE # Louise South	938.7 939.8 940.8		10,058	CQ MP 917.28 To MP 959.41	942.6 950.3 954.5 956.2
				18.8					
1685			66.3	EDNA	958.6				
				5.1					
1690			71.4	# El Toro North EL TORO # El Toro South	962.7 963.7 964.6		9,410		
				10.4					968.5
1695			81.8	# Telferner North Telferner # Telferner South	972.9 974.1 975.3		11,934		
				4.5					
1705			86.3	THRASHER	978.6				
				0.7					
2175	T	CTC UP	87.0	# VICTORIA (UP)	979.3				

MAXIMUM SPEED	MPH
59	
Exceptions:	
MP 917.4 – MP 919.3	35
MP 930.5 – MP 932.5	25
All Switches and Sidings unless listed below	10
Through Turnouts and on Sidings	
CP 902 Switch Only	25
CP 903 North XO	25
CP 903 South XO.....	30
CP 905 Switch and Siding.....	30
Wharton	40
Louise and El Toro.....	30
Telferner.....	40
Zone 7	
Tracks 101 & 102 including X-over	15
Tracks 201 & 202	15
Kendleton	
The Kendleton switching lead is governed by Rule 6.28 not to exceed	20

Tons per Operative Brake

When maximum subdivision speed is over 45 MPH, the maximum speed permitted will be determined by the tons per operative brake.

Over 15045 MPH

Radio Channels

	AAR	Dispr Call In
Road	067-067	
Yard	047-047	
Disp.	097-067	1
Critical Incident Desk	097-067	3

TrAM Area

The Rosenberg Sub is TrAM Area 1.

Block System

Centralized Traffic Control (CTC) is in use between Rosenberg and Victoria.

Positive Train Control (PTC)

PTC is in effect on the Rosenberg Sub.

US Southern Division Timetable

Continuous Quiet Zone – GCOR 5.8.4

FM 102	MP 917.28
Spanish Camp	MP 917.75
W. Milam Street	MP 917.91
Sam Bishkin Road	MP 929.82
FM 653	MP 930.55
Higbee Street	MP 930.78
Washington Street	MP 931.06
Mechanic Street	MP 931.13
Alamo Street	MP 931.20
Hoskins Broadway	MP 931.35
Palacios Street	MP 931.78
Gladys Street	MP 932.12
Meadow Lane.....	MP 932.39
Wharton Street	MP 941.14
Colorado Street	MP 941.28
Orange Street	MP 941.71
East Street	MP 958.31
Wells Street/SH 111	MP 958.46
Allen Street	MP 958.66
Pumphrey Street	MP 958.95
Colorado Street.....	MP 959.16
Apollo Street/FM 1822	MP 959.41

Electric Locks

Station	MP	Location of switch
Edna	959.4	North Edna Switch
Edna	960.3	South Edna Switch
Thrasher	978.5	North Thrasher Switch
Thrasher	979.2	South Thrasher Switch

Trackside Warning Detectors

Mile post	Type of Detector	Call Back
898.1	HBD/DED	#88
906.0	DED	
908.8	DED	
912.8	HBD/DED/Oversized Load (C) (S)	
923.0	HBD/DED/Oversized Load (C) (N)	
942.6	HBD/DED	
950.3	DED	
954.5	DED	
956.2	HBD/DED/Oversized Load (C) (S)	
968.5	HBD/DED/Oversized Load (C) (N)	

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
N Kendleton Switching Lead	S	902.1	7,037
N Kendleton IM Switching Lead ++	S	902.3	5730
N Kendleton Switching Lead North X-Over ++	S	903.4	XO
N Kendleton IM Lead++	S	903.4	LEAD
N Kendleton Switching Lead South X-Over ++	S	903.5	XO
N Kendleton Team Track 1++	S	903.5	8,734
CP 903 X-Over/ +			
Kendleton Siding X-Over	S	903.5	XO
CP 903 X-Over/South			
Kendleton Switching Lead	N	903.6	7,037

Name	DOE	MP	Footage
Kendleton Siding			
Crossover – Main track	S	903.6	XO
Kendleton Siding +			
Crossover – Siding	N	903.7	XO
S Kendleton Team Trk 1 +	N	905.2	8,734
N Wharton Setout E +	N	914.9	300
N Wharton Setout	N	919.5	833
El Campo		927.6	CP
N Louise Team Track	S	938.8	1,396
S Louise Team Track	N	939.2	1,396
Ganado		940.8	CP
N Edna	S	959.4	4,075
S Edna Storage ++	S	960.3	275
S Edna	N	960.3	4,075
N El Toro Team Track +	S	962.8	1,842
S El Toro Team Track +	N	963.2	1,842
Telferner		972.9	CP
N Thrasher	S	978.5	3,738
S Thrasher	N	979.2	3,738
Caterpillar Industry Lead ++	N	979.1	919

+ Indicates connected to siding

++ Indicates connected to business track

General Information

Kendleton

The Kendleton switching lead is governed by Rule 6.28 not to exceed 20 MPH.

North Kendleton Intermodal Switching Lead

DTMF Yard Switch is installed on the North Kendleton Intermodal Switching Lead. The proper DTMF Code must be entered on Radio Channel 047-047 before movement is made over the switch. To operate the DTMF yard switch: normal switch DTMF #902311 – reverse DTMF #902322

North Kendleton Switching Lead Crossover

DTMF Yard Switches are installed on the North Kendleton Switching Lead X-Over. The proper DTMF Code must be entered on Radio Channel 047-047 before movement is made over the switches. To operate the DTMF yard switches: normal switch DTMF #903411 – reverse DTMF #903422

Rosenberg Subdivision

T&E employees will be governed by UP form 20849 conductor report in lieu of CPKC form 4751.

Milepost Equalization:

- CPKC Rosenberg Subdivision MP 894.8 = UPRR Rosenberg Subdivision MP 2.5.
- CPKC Rosenberg Subdivision MP 979.3 = UPRR MP 87.0.

---END---

US Southern Division Timetable

Station Number	GCOR 4.3	Method of Operation	EASTWARD ↑	LAREDO SUBDIVISION STATION PAGE # DENOTES CONTROL POINT OR MANUAL INTERLOCKING	WESTWARD ↓	Yard Limits	Siding Length	Continuos Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Corpus Christi		Mile Post Location				
2157	B C T	YL	0.0	(UP) CORPUS CHRISTI	157.0	MP 159.5 - MP 145.5			144.7
				10.1					
2145		CTC	10.1	ROBSTOWN	146.9				133.4
				1.4					
	A		11.5	# UP CROSSING	145.5				
				0.4					
			11.9	UP CONNECTION	145.1				
				2.1					
2143			14.0	# Spear East SPEAR # Spear West	144.3 143.0 142.2		10,135		
				14.7					
2129			28.7	# Bentonville East BENTONVILLE # Bentonville West	129.3 128.3 127.3		9,832		
				8.8					
2119			37.5	ALICE	119.5				
				8.6					
2110			46.1	# Matthews East MATTHEWS # Matthews West	111.5 110.9 110.2		6,173		
				4.1					
2109			50.2	# San Diego East SAN DIEGO # San Diego West	107.8 106.8 105.7		10,221		
				22.2					
2089			72.4	# Berry East Berry # Berry West	85.8 84.6 83.5		11,340		
				7.3					
2077			79.7	REALITOS	77.3				
				14.1					
2062			93.8	# Hebbronville East HEBBRONVILLE # Hebbronville West	65.1 63.2 62.3		14,305		
				15.3					
2049			108.8	BRUNI # Bruni East # Bruni West	47.9 48.0 45.9		10,089		
				23.4					
2025			132.2	# Killam East KILLAM # Killam West	25.8 24.8 23.8		9,991		
				6.3					
			138.5	# CP 18	18.5				
				1.4					
2017			139.9	# Milagro East Milagro # Milagro West	18.4 17.1 15.8		13,044		
				5.9					
			145.8	# CP 11	11.2				
				2.2					
		YL	148.0	LAREDO YARD	9.0	MP 10.0 - MP 0.0			18.5
				6.1					
2003	B C		154.1	LAREDO (Saltillo Sub)	2.9				4.2 0.4

US Southern Region Timetable

MAXIMUM SPEED	MPH
59	
Exceptions:	
MP 159.5 – MP 155.7	10
MP 155.7 – MP 145.0	20
MP 145.0 – MP 142.0	HER 30
MP 142.0 – MP 135.5	50
MP 135.5 – MP 135.0	45
MP 135.0 – MP 123.2	50
MP 123.2 – MP 120.5	40
MP 120.5 – MP 118.0	25
MP 118.0 – MP 117.0	40
MP 117.0 – MP 112.0	55
MP 112.0 – MP 111.0	40
MP 111.0 – MP 109.7	35
MP 109.7 – MP 109.0	HER 25
MP 109.0 – MP 107.8	35
MP 107.8 – MP 97.3	50
MP 97.3 – MP 97.0	40
MP 97.0 – MP 95.0	45
MP 95.0 – MP 92.5	50
MP 92.5 – MP 87.2	40
MP 83.6 – MP 82.5	50
MP 82.5 – MP 80.7	45
MP 73.8 – MP 73.5	50
MP 68.7 – MP 67.7	45
MP 63.0 – MP 60.8	50
MP 51.5 – MP 49.1	50
MP 49.1 – MP 48.6	45
MP 39.8 – MP 39.5	50
MP 38.7 – MP 35.0	45
MP 35.0 – MP 30.0	50
MP 30.0 – MP 29.0	50
MP 27.0 – MP 26.5	50
MP 22.4 – MP 11.0	50
MP 11.0 – MP 10.0	45
MP 10.0 – MP 0.0	20
All Switches and Sidings unless listed below	
Through Turnouts and on Sidings	
Bentonville, San Diego, Berry, Bruni & Milagro	40
Spear & Killam	30
Hebbronville	25
CP 11 (Switch)	25
East Laredo YD XO (MP 9.2)	25
East Intermodal Lead (MP 9.2)	25
Laredo West XO's (MP 6.9 – 6.7)	25
J.O. Alvarez XO (MP 6.7)	25
West Main 3 (MP 4.3)	25
West Main 2 (MP 4.2)	25
West Main 1 (MP 4.2)	25
Zone 3 Tracks	
1 – 9	15
100 – 106	15
224 & 225	15
700	15
Tons per Operative Brake	
When maximum subdivision speed is over 45 MPH, the maximum speed permitted will be determined by the tons per operative brake.	
Over 150	45

Radio Channels

	AAR	Dispr Call In
Road	074-074	
Yard	039/051/009- 039/051/009	
Disp.	097-074	1
Critical Incident Desk	097-074	3

TrAM Area

The Laredo Sub is TrAM Area 1.

Block System

Centralized Traffic Control (CTC) is in use between Robstown and Laredo Yard.

Positive Train Control (PTC)

PTC is in effect on the Laredo Sub.

Yard Limits

East MP	West MP
159.6	Corpus Christi 145.5
10.0	Laredo 9.2
7.3	Laredo (#3 MT) 4.3
9.2	Laredo (#1 MT) 4.2
9.1	Laredo (#2 MT) 4.2
4.2	Laredo 0.0

Interlockings/Control Points

Automatic Interlocking Approach Locations:

(Main Track and Siding, if applicable)

- UP RRR at MP 145.5
WWD Approach: MP 148.08.
EWD Approach: MP 142.17.

The interlocking signals at the UP crossing are also designated as a control point. When a crew encounters a STOP signal at this location and fails to receive a proceed indication after following instructions in the release box, authority must be received from the train dispatcher before proceeding, except when operating within the limits of track and time.

Equipment Restrictions

Six Axle Locomotives Prohibited From Operating On All Industry and Wye Tracks:

Except:

- Commercial Metals – MP 154.2
- CCPC – MP 150.2
- Weatherford – MP 128.3, MP 127.9
- Carbo Ceramics/Santrol – MP 117.5, MP 117.2
- Wright Brothers – MP 73.9
- Laredo Aggregate – MP 18.5

Six Axle Locomotives May Be Used To the Clearance Point Only On:

- Bell Processing
- Titan Services
- Nor-Alcoa/Tetra
- Stock Track
- Realitos Siding

US Southern Region Timetable

Electric Locks

Station	MP	Location of switch
Weatherford	129.7	West Weatherford Switch
Bentonville	127.5	Team Track
Alice	119.3	East Alice House Track
Alice	118.9	West Alice House Track
Wright Brothers	73.9	Wright Brothers
Bruni	46.0	Bruni Team Track

Trackside Warning Detectors

Mile Post	Type of Detector	Call Back
144.7	DED	#88
133.4	HBD/DED	
122.4	HBD/DED	
113.1	HBD/DED	
98.1	HBD/DED	
86.9	HBD/DED	
71.9	HBD/DED	
60.0	HBD/DED	
42.0	HBD/DED	
30.8	HBD/DED	
18.5	HBD/DED	
4.2	DED/Oversized Load	
0.4	DED	

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
H&H Recycling	E	159.4	300
Ingram Ready Mix	W	158.6	IND
East HEB Run Around	W	158.1	1,073
Savage Industrial Lead	E	158.0	IND
West HEB Run Around	E	157.9	1,073
HEB Lead	W	157.9	IND
Old Scale Track	W	157.1	YARD
East Corpus Christi Yard 3	W	157.1	YARD
East Corpus Christi Yard Lead	W	157.0	YARD
West Corpus Christi Yard Lead	E	156.4	YARD
West Corpus Christi Yard 3	E	155.9	YARD
Commercial Metals	E	154.2	1,150
Mineral Processing	E	154.0	IND
Rangeland Energy Lead	E	153.4	IND
CCPC	W	150.3	7,500
Tex Mex Jct. (CP J141)		145.4	CP
Robstown Team Track +++	E	145.2	811
CP 145	E	145.1	CONN
East Weatherford	W	128.7	3,868
Bentonville Team Track +	W	127.5	1,504
Alice		121.3	CP
East Alice House Track	W	119.3	1,506
Alice Rip Track ++	E	119.0	790
Alice Track #6 Industrial ++ /			
Park Bell Processing Titan +++			
Services Nor-Alcoa/Tetra	E	119.0	15,000
West Alice House Track	E	118.9	1,506
East Carbo Ceramics/Santrol	W	117.5	1,500
West Carbo Ceramics/Santrol	E	117.2	1,500
CP 95		95.0	CP
Benavides Team Track +++	W	92.2	2,442
CP 85		85.0	CP
East Realitos	W	77.8	6,459

Name	DOE	MP	Footage
Wright Brothers	W	73.9	9,000
CP 74		73.9	CP
Baker Hughes/Milpark +	W	62.6	546
M.I. Drilling/Trans Texas +			
(City Track #1)	W	62.5	2,573
Bruni Team Track +	E	46.0	1,435
Mirando City		36.8	CP
Aguilares Team Track +++	E	30.8	750
Killam Storage + / +++	E	23.9	513
CP 18		18.5	CP
Laredo Aggregates D+	E	18.5	IND
CP 10		10.0	CP
East Intermodal Lead ++	W	9.2	Yard
West Intermodal Lead	E	7.3	Yard
J.O. Alvarez	W	5.3	IND
West Main 3	E	4.3	15,899
West Main 2	E	4.2	25,750
East Delivery Track +++	W	3.3	IND
Laredo Switching Lead D	W	1.2	10,110
Laredo Team Track	W	0.4	1,510
UP Yard Connection	E	0.1	YARD

+ Indicates Connected to Siding

++ Indicates Connected to Business Track

+++ Indicates MW Equipment only

Switch Information

Corpus Christi Terminal

All switches within yard limits, MP 159.5 and 145.5 - Corpus Christi Terminal, may be left as last used.

Exception: This will not apply to the Savage Lane Switch. The normal position for the Savage Lane Switch at MP 158.0, serving trackage to the CCTR, is lined for movement to Savage Lane. All movements between MP 158.0 to the CCTR connection on Savage Lane Track are to be made per Rule 6.28.

Laredo Terminal

All switches within yard limits MP 0.0 and MP 10.0 Laredo Terminal may be left as last used.

DTMF Yard Switch is installed on the International Bridge Switch CPKC to UP Lead. The proper DTMF Code must be entered on Radio Channel 010-010 before movement is made over the switch. To operate the DTMF yard switch:

normal switch DTMF #000111

reverse switch DTMF # 000122.

The switch point indicator will indicate the following:

Green - normal position (CPKC Main Track)

Yellow - reverse position (UPRR Yard)

Red - in transition or out of correspondence

Note: OS Signs are installed on each side of the switch. The OS must not be fouled until the switch is lined for intended movement.

Laredo Aggregates

Dual control derail is installed on the industry track. This derail operates in conjunction with the main line CP18 switch. When operating the dual control switch by hand, it is also necessary to operate the power derail by hand.

Power Assisted Switches (PAS):

Robstown North (East Robstown).

Radio Channel 074-074

Normal DTMF #148011 Reverse DTMF #148022

Robstown South (Old East Robstown).

Radio Channel 074-074

Normal DTMF #147211 Reverse DTMF #147222

Robstown South (Old West Robstown).

Radio Channel 074-074

Normal DTMF #146211 Reverse DTMF #146222

Robstown North (West Robstown).

Radio Channel 074-074

Normal DTMF #146011 Reverse DTMF #146022

General Information

US BORDER PATROL INSPECTIONS

The U.S. Border Patrol will inspect all eastward trains at Hebbronville.

Communication with inspectors will be made on channel 074-074. While this inspection is in progress, the Engineer will not move without sounding Whistle Signal GCOR Rule 5.8.2(3). A train may depart when the inspector notifies the crew that the inspection is complete.

Realitos Siding

Siding between MP 76.5 and MP 77.7 is for MW equipment only.

Spear Sidings

Sidings are identified geographically north to south as Spear 2, North, and South.

Corpus Christi Terminal

A sign reading "R/R Scale Ahead" is located approximately 50 feet in advance of a track scale at the Commercial Metal Company. Do not pass this sign with a locomotive.

At the Corpus Christi Grain Elevator, a locomotive must not occupy the scale.

All Northbound trains departing Robstown and Corpus Christi must report departure time from CPKC tracks to dispatcher.

Trains Transporting Transformers

Transformers being transported across the Laredo Subdivision must remain on the mainline unless permission is granted by the Roadmaster.

Eastward Train Movement To UPRR Trackage

Eastward trains en route to the UP-trackage rights must not pass East Spear MP 144.3 until the train crew has permission from the UP-train dispatcher to enter Control Point (CP J141).

Laredo Terminal

All tracks within Laredo Yard are designated as Interchange Tracks for all trains to and from CPKCM.

Trains coming into the U.S. from Mexico may proceed to Laredo Yard if a brake release is indicated by an end of train device located at the rear of the train with at least a 5 psi increase after releasing the automatic brake is replaced with:

A Class III brake test must be performed before departing the International Bridge at Laredo.

UP Yard Connection

DTMF Yard Switch is installed on the International Bridge Switch CPKC to UP Connection. The proper DTMF Code must be entered on Radio Channel 010-010 before movement is made over the switch. To operate the DTMF yard switch: normal switch DTMF #000111 – reverse DTMF #000122.

The switch point indicator will indicate the following:

Green – normal position (CPKC Main Track)

Yellow – reverse position (UPRR Yard)

Red – in transition or out of correspondence

Note: OS Signs are installed on each side of the switch. The OS must not be fouled until the switch is lined for intended movement

Arkansas Avenue

DTMF Yard Switches are installed on the West Main 1 and West Main 2. The proper DTMF Code must be entered on Radio Channel 051-051 before movement is made over the switch. To operate the DTMF yard switch:

- Main to Main 1 – DTMF code #042211
- Main to Main 2 – DTMF code #042222
- Main to Main 3 – DTMF code #042233

East Laredo Crossover

DTMF Yard Switches are installed on the East Yard Lead East X-Over. The proper DTMF Code must be entered on Radio Channel 051-051 before movement is made over the switch. To operate the DTMF yard switch: normal switch DTMF #010211 – reverse DTMF #010233.

East Intermodal Lead

DTMF Yard Switch is installed on the East Intermodal Lead. The proper DTMF Code must be entered on Radio Channel 051-051 before movement is made over the switch. To operate the DTMF yard switch: normal switch DTMF #010111 – reverse DTMF #010133.

Laredo Aggregates

A dual control derail is installed on the industry track. This derail operates in conjunction with the dual control industry switch. When operating the industry switch by hand, it is also necessary to operate the split point derail by hand.

BROKEN RAIL DETECTION (BRD)

Broken Rail Detection (BRD) limits are in effect on the main track between MP 0.34 and MP 04.16.

Begin BRD and End BRD signs will be posted at the outer limits of BRD Territory.

Limits monitored by BRD have indicators that display aspects for the condition of the track.

BRD INDICATORS

Aspect	Indication
Flashing Green	No Defects
Flashing Red	Expect next indication to be red
Red or Dark	Proceed at restricted speed until the leading wheels pass the next BRD indicator and report to the Train Dispatcher

While moving within BRD territory, trains must comply with the indication of the BRD indicator.

If an indicator displaying a flashing green or flashing red changes to an indication requiring a train to proceed at restricted speed, the train must immediately reduce speed consistent with good train handling. Train must then move at restricted speed until the leading wheels pass the next BRD indicator and report such an indicator change to the train dispatcher.

When one of the following occurs, move at restricted speed until the leading wheels have passed the next BRD indicator or the end of BRD limits:

- The train enters the main track between BRD indicators.
- The previous BRD indicator is unknown.
- Movements in the opposite direction from which the BRD segment was entered.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	PORT NECHES BELT LINE STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuos Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From Port Neches Wye		Mile Post Location				
		6.28	0.0	(Beaumont Sub) PORT NECHES WYE	A-1.74				
				6.6					
			6.6	END OF LINE	A-8.38				

MAXIMUM SPEED		MPH
		20
Exceptions:		
MP A-6.35 – MP A-7.17	10	
MP A-7.17 – MP A-8.22 (Pabtex Loop 735).....	10	
MP A-7.29 – MP A-8.38 (Pabtex Loop 729).....	10	
Switches and Sidings	10	

Radio Channels

	AAR	Dispr Call In
Road	013-013	
Yard	076-076	
Disp.	052-013	1
Critical Incident Desk	052-013	3

TrAM Area

The Port Neches Belt Line is TrAM Area 1.

Rule 6.28 Other than Main Track

Other than Main Track used between Port Neches Wye and End of Line.

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
South Port Neches Wye	N	A-1.95	WYE
Calabrian 730	N	A-3.45	IND
Atreco Team Track	N	A-5.09	IND
Total Petrochemical 725	N	A-5.12	IND
USD Lead	S	A-5.87	IND
North Pabtex Loop 735	S	A-7.0	IND

General Information

The switch to SLIC track 700, must be lined and locked for the Port Neches Belt Line when not in use. The normal position of this switch will be lined to go toward Pab-Tex.

A DTMF Yard Switch is installed for the USD Lead. A power derail is installed on the lead track that works in conjunction with the switch. If necessary to operate the switch by hand, the derail must also be operated by hand. When entering the lead track, it will be necessary to operate the DTMF switches.

DTMF code: normal switch DTMF #005811 – reverse switch DTMF #005822.

---END---

US Southern Region Timetable

Station Number	GCOR 4.3	Method of Operation	NORTHWARD ↑	PORT NECHES BRANCH STATION PAGE # Denotes Control Point Or Manual Interlocking	SOUTHWARD ↓	Yard Limits	Siding Length	Continuous Quiet (CQ) or Partial Quiet (PQ) Zone Locations	Trackside Warning Detector Location
			Distance From End of Line		Mile Post Location				
		6.28	0.0	END OF LINE	N-2.97				
				2.97					
			2.97	PORT NECHES JCT WYE (Port Neches belt)	N-0.0				

MAXIMUM SPEED **MPH**
20

Exceptions:

MP N-1.74 – MP N-2.97 10
Switches and Sidings 10

Radio Channels

	AAR	Dispr Call In
Road	013-013	
Yard	076-076	
Disp.	052-013	1
Critical Incident Desk	052-013	3

TrAM Area

The Port Neches Branch is TrAM Area 1.

Rule 6.28 Other than Main Track

Other than Main Track used between Port Neches JCT Wye and End of Line.

Other Tracks Not Shown as Stations (Business Tracks)

Name	DOE	MP	Footage
Lion Elastomer 721	S	N-2.85	IND
Lion Elastomer 718	S	N-2.62	IND
East Port Neches Wyes	S	N-2.03	WYE
West Port Neches Wye	N	N-1.74	WYE
East Port Neches Siding	S	N-1.72	2,569
TPC 705 Lead	N	N-1.31	IND
West Port Neches Siding	N	N-1.15	2,569
Huntsman Chemical Lead	N	N-0.34	IND

---END---

WHO WE ARE

At CPKC, we are a team of railroaders providing superior service to our customers to the benefit of our communities, economy and one another.

HOW WE WORK: Our Values

Our Values drive our actions, foster respect and inspire our journey towards excellence.

WHAT WE DO: Our Foundations

Our Foundations ground us in the principles of Precision Scheduled Railroading.

BUILT ON RESPECT: Our Bedrock

Respect is non-negotiable. It fuels our success and is expected in everything we do.



ACCOUNTABILITY



DIVERSITY



PRIDE



OPERATE SAFELY



OPTIMIZE ASSETS



CONTROL COSTS



PROVIDE SERVICE



DEVELOP PEOPLE



R E S P E C T

Precision Scheduled Railroading: The CPKC way

An unrelenting commitment to moving customers' freight in the safest, most reliable and efficient manner possible.

Our Values

Our Values drive our actions, foster respect and inspire our journey toward excellence.



ACCOUNTABILITY

We are accountable for our commitments and our actions. Together, we provide exceptional service to our customers and communities while never sacrificing safety.



DIVERSITY

We embrace our cross cultural heritage and work to strengthen diversity. We respect and value the unique skills and abilities of everyone.



PRIDE

We honour our history and the railroaders who came before. We lead with integrity, doing what's right even when it's not easy. We are grateful for our CPKC family, past, present and future.

Our Foundations

Our Foundations ground us in the principles of Precision Scheduled Railroading.



OPERATE SAFELY

Protect our people. Protect our customers' goods. Protect our communities. Protect our environment. Safety is an obligation, not an option.



CONTROL COSTS

We always ask if we can safely do it better and more efficiently. We look at every cost, even small items, to improve.



DEVELOP PEOPLE

We are all railroaders. The passion, skills and dedication of our people fuel the engine of our growth and success.



OPTIMIZE ASSETS

We have only the assets we need to provide the service we promised. We intelligently exhaust all other ways to deliver or improve before spending one dollar of capital.



PROVIDE SERVICE

We do what we say we will do, meeting our commitments and always working to do better.





CPKC POLICE DEPARTMENT

24 HOUR COMMUNICATIONS CENTER

TOLL FREE NUMBER 1-800-716-9132 (Canada and USA)

Please call direct or through the Train Dispatcher/Operations Supervisor to report near misses and other incidents which affect the safe operation of the railway.

PSCC@cppoliceservice.com