

Exfiltration

Hydraflow Hydrographs Extension computes exfiltration outflows using the following equation:

$$Q_{ex} = \left(\frac{ER \times SA}{12 \times 3600} \right)$$

Where:

Q_{ex} = outflow (cfs)

ER = exfiltration rate (in/hr)

SA = surface area, wetted or contour (sqft)