

Understanding the Structure HG (Hydraulic Grade)

When you select the multi-stage option, Hydraflow Hydrographs Extension checks the head elevation produced by culvert A. This value is then used as a tailwater elevation against other multi-stage structures. As the head elevation increases, the outflows from the orifices and weirs decrease.

Graph (8) on the stage-discharge graph in [Viewing the Stage-Storage-Discharge Graphs](#) indicates the structure HG. At any given discharge this line shows the elevation of the water at the upstream face of culvert A. When this line merges with the total Q line, culvert A is the controlling structure and the contributing flows from the multi-stage orifices and weirs diminish.

You can:

- Click  (Export) to save the current plot as a bitmap (.bmp) file.
- Click  (Print Pond Report) to print a graphical pond report. See [Printing Reports](#).

See Also

- [Table Tab - Stage/Storage/Discharge Dialog Box](#)