

GM P4 1227165 ECM Simulator

Theory of Operation

CONTROLLED ENGINEERING PUBLICATION

ECM service number 1227165 | Supplied 9340 image
Revision 1.3 | 6 October 2026

Firmware authority: `evidence/firmware/bua-hac.lst`

This publication describes evidence-supported processor-visible behavior and explicitly preserves unresolved custom-device, electrical, mechanical, power, and plant boundaries.

Contents

Document control	3
1. Scope and evidence method	3
1.1 Controlled identity	3
1.2 Evidence order and claim status	3
1.3 Fidelity classes	4
2. System architecture	4
3. MEMCAL and calibration architecture	4
3.1 MEMCAL/U11 bias, configuration, and injection block	5
4. Reset, startup, and retained state	6
4.1 Power rails, reset and retained-power block	6
4.2 LIMP source, output gating and watchdog boundary	7
5. Runtime scheduler and event model	7
6. Input acquisition and signal processing	8
6.1 CTS and MAT temperature-input blocks	8
6.2 TPS and analog MAF input blocks	9
6.3 VOLT and PUMPVOLT divider/filter blocks	10
7. Reference, RPM, dwell, spark, and knock	10
8. Airflow, fuel, and injection	11
8.1 Injector gate drive, current sense and feedback block	11
9. Idle-air control	12
10. Emissions, accessories, and transmission	12
11. Output staging and electrical interfaces	13
12. Diagnostics and communications	13
12.1 DIAG mode selection and dashboard data block	13
13. Key-off, shutdown, and exceptional modes	14
14. C port and embedded boundary	14
15. Simulation and verification	15
16. Explicit unresolved boundaries	15
Appendix A. Consolidated address and register index	16
A.1 RAM and software state	16
A.2 Processor-visible peripheral locations	17
A.3 Executable regions and external boundaries	17
Appendix B. Detailed chapter map	18
Appendix C. Glossary	19
Appendix D. Schematic functional-block coverage	20

Document control

Field	Value
System	GM P4 engine control module (ECM), service number 1227165
Firmware basis	Supplied 9340 image and corrected BUA source/listing provenance
Firmware authority	evidence/firmware/bua-hac.lst
Implementation	Strict-C89 behavioral port and deterministic PC simulator
Revision	1.3 - Step 183, 2026-10-06
Status	Controlled engineering publication
Detailed authority	Linked reference chapters and hardware/firmware cross-reference

This document is the master operational description of the repository's evidence-supported system. It explains how the supplied program image, processor-visible hardware, MEMCAL, portable C implementation, and simulator fit together. It consolidates the sixteen completed theory chapters; it does not replace their detailed address, net, calibration, implementation, and regression records.

The behavioral port is closed against the supplied image at the documented processor-visible boundary. That conclusion does not claim cycle-exact processor emulation, complete custom-device reconstruction, electrical equivalence, a production engine model, or safety qualification for connection to physical hardware.

1. Scope and evidence method

1.1 Controlled identity

The hardware identity is ECM service number 1227165. The program basis is the corrected BUA source family associated with the supplied 9340 material. BUA is retained as source and label text; it is not, by itself, proof that every external artifact represents the same calibration, MEMCAL, or board variant.

The authoritative executable record is ``evidence/firmware/bua-hac.lst``. Its emitted instructions, bytes, addresses, targets, tables, and execution order control firmware claims. `bua-hac.txt` is excluded because its corrected-revision status has not been established. Source provenance and image differences are recorded in the [evidence register](#) and ``BUA_SOURCE_PROVENANCE.md``.

1.2 Evidence order and claim status

When evidence conflicts, this work uses the following order:

- 1 verified emitted instructions, addresses, and bytes;
- 2 calibration data together with its executable use;
- 3 repeatable tests, measurements, and independent cross-checks;
- 4 source labels and comments;
- 5 secondary descriptions and historical research.

Claims use the repository statuses Confirmed, Strongly supported, Provisional, Variant-dependent, Unknown, and Boundary. Status belongs to an individual claim, not to an entire artifact. Observable behavior is established before a functional name is assigned. Missing device documentation remains an explicit boundary rather than being completed by analogy.

1.3 Fidelity classes

Class	Meaning in this repository
F0	Listing-backed firmware state, arithmetic, ordering, branch, table, or raw write preserved by the port.
F1	Directly supported hardware connection, schematic path, physical construction, or MEMCAL relationship.
F2	Raw processor-visible input, event, register state, or output observation at the hardware-abstraction-layer (HAL) seam.
F3	Optional simulation assumption: sensor transfer, electrical response, engine/vehicle dynamics, actuator response, or other plant behavior.
F4	External or unresolved behavior: undocumented custom-device internals, unavailable code, physical power/reset effects, or uncharacterized circuitry.

The governing flow is:

Architecture boundary: Physical system / plant (F3-F4) -> raw HAL boundary (F2) -> firmware behavior (F0) -> raw HAL outputs, with schematic-proven connections retained as F1 evidence.

The simulator may add an F3 plant around the F0 core, but an F3 result never upgrades itself into firmware or hardware evidence.

2. System architecture

The ECM combines a processor, volatile and retained state, external program memory, processor-visible custom peripherals, a serial analog-to-digital (A/D) converter, discrete and event inputs, output drivers, and a removable MEMCAL. The supplied program window is \$8000-\$FFFF; the interface exposes A0-A14, D0-D7, /ROMCS, and /ROMOE. Eight vector words occupy \$FFF0-\$FFFE.

The custom-device boundary is central to the architecture:

- U9 exposes the \$3FC0-\$3FFF processor-visible timing/register window. Firmware use establishes particular addresses for reference, injection, spark, dwell, knock, and status. It does not establish U9's internal timer topology or a complete pin-to-register specification.
- U10 (16034988) is the serial A/D boundary. Firmware supplies a selector and receives an 8-bit raw sample through \$F1BE-\$F1DF.
- U11 receives MEMCAL configuration and participates in oscillator, MAP, injector-limit, and reference-related connections. Its internal transfer functions remain F4.
- U12 participates in distributor reference, cylinder/knock selection, ignition/EST feedback, and injector drive/current-control paths. Its internal thresholds, polarity, phase, and control laws remain F4.

The [processor and custom-peripheral chapter](#), [U9 map](#), and [U11/U12 boundary chapter](#) are controlling references. Unclassified locations in \$3FC0-\$3FFF are not assumed to be unused or reserved.

3. MEMCAL and calibration architecture

The MEMCAL is both program/calibration carrier and physical configuration hardware. Its 66-contact relationship to motherboard connector J4, EPROM, two resistor networks, populated jumpers, and CAL paths are part of the system architecture. Original owner-confirmed resistance measurements control replacement resistance targets. Photographs and direct physical evidence control the earlier as-built reconstruction where legible. KiCad, LTspice, and historical notes provide supporting evidence; discrepancies remain visible.

Step 179 records the owner's confirmation that the preserved workbook contains original NetRes pin-to-pin measurements and defines the resistance target. The earlier hand reconstruction is approximate. New passive DC candidates closely match the measured matrices but still require physical validation. Photographs remain authoritative for the earlier as-built population. See the [reconstruction report](#).

Important established anchors include CAL42 to U11 pin 18 OSC, CAL56 to U12 pin 11 CYL, CAL61 to U11 pin 28 MAP, CAL59 to VIGN, and the CAL45/CAL46 common node. These are connection or configuration statements, not licenses to invent the receiving devices' internal behavior. In particular:

- CAL42/U11 OSC is not automatically the U9 timer clock;
- CAL56/U12 CYL is not a PROM byte and must not be equated with LC009 or LC225;
- CAL29's analog ESC route is distinct from the CAL32/U12/U9 knock-event route;
- resistor-network values or topology that remain visually or electrically ambiguous remain unresolved.

The detailed reconstruction is in [MEMCAL architecture](#), [functional networks](#), and [motherboard/firmware paths](#).

3.1 MEMCAL/U11 bias, configuration, and injection block

Schematic location. Sheets 4 (Ignition-Injection) and 5 (Connectors), U11 16054995, U12 16034984, J4, and both NetRes packages. Original package terminal numbering and complete mappings are in the [Step-180 circuit review](#).

Electrical operation. For the preferred measured-matrix candidate, 375 pin 14 is VCC; pins 4 and 8 are ground. The measured 7-8 link grounds U11 pin 8. The pin-5/6/9 resistor group is a coupled bias network, including the 267-k Ω branch between U11 pins 2 and 13. The motherboard adds 51.1 k Ω from VIGN and 5.49 k Ω to ground at the pin-9/U11-13/26 node, so its voltage is not set by the MEMCAL alone. The 88.7-k Ω branch pulls U11 OSC toward VCC; the 0.033- μ F capacitor is on the separately labeled U11 C terminal. An internal oscillator equation is not established.

The 376 network provides VCC pull-ups, a 150-k Ω /1.4-k Ω divider, a VIGN-derived 24.9-k Ω /130-k Ω divider, and a 7.5-k Ω ground return at U12 CYL. Its 8.25-k Ω resistor is on the MEMCAL side of the series capacitor leading to U11 pin 16. The measured 7-9 link routes conditioned TPS at J4-64 to J4-61/U11 pin 28, labeled MAP. Actual conditioned MAP at J4-63 is isolated inside this package. This is a mapping deduction pending original-hardware continuity confirmation; it does not short external MAP and TPS together.

Firmware operation. The NetRes resistors are fixed electrical configuration, not programmable EPROM tables. Firmware consumes U9 reference occurrence and period state (\$CAC6-\$CAD3, \$CB5A-\$CB5D) and derives RPM at \$CDE6-\$CE41. Cylinder/configuration consistency checks at \$F682-\$F68B compare masked \$002F state with LC225; Error 41 qualification includes \$E6A1-\$E6AA. These paths do not establish U12's analog CYL decoding or equate its resistor with the separate normalization constant LC009. Ordinary firmware load remains VMAF-derived, not a conversion of the NetRes's U11 MAP-labeled terminal.

Complete signal path. MEMCAL configuration and motherboard bias act at U11/U12; engine references and sensors also reach these chips. U11 emits INJ/INJLIMP. U12's reference and injector interfaces connect to U9 and the injector output stage. Firmware commands processor-visible timing state; it does not directly calculate the undocumented U11 analog transfer function.

Fault behavior. Incorrect resistors, missing ground links, or open carrier contacts can alter configuration/bias even with a good EPROM. Isolated resistance matches do not prove loaded voltages, oscillator timing or backup fueling. The ~LIMP net crosses U12, output gating, and power circuitry. ALDL mode, firmware sensor substitutions, and hardware backup operation are separate concepts. A MEMCAL-configured backup injection role is strongly supported by these external connections; exact entry conditions and fueling equations remain unknown. No claim is made that every diagnostic error asserts ~LIMP.

Evidence boundaries. Candidate DC accuracy is established numerically against the owner's original measurements; original hidden topology and powered/dynamic behavior are not. Do not infer a frequency from $1/(RC)$, a cylinder count from 7.5 k Ω alone, or an injector pulse width from unloaded divider voltages.

4. Reset, startup, and retained state

Reset vectors enter the source-ordered power-on path at \$C800-\$C9F3. That path clears the specified volatile state, samples socket/checksum and mode conditions, selects factory or normal operation, handles the optional-ROM decision, validates retained state, performs recovery when required, and enters normal initialization. The port preserves this order rather than replacing it with a generic initialization routine.

Retained validation includes the listing-defined checksum computation at \$F3A7-\$F3B4. Recovery at \$F434-\$F446 stores \$8000 in both save-area marker words and initializes all sixteen block-learn-memory (BLM) cells to \$80. Normal startup then establishes controller state, initial sensor samples, engine-running/reference state, injector and spark state, and initial idle-air control (IAC) positioning before periodic operation.

Factory selection executes a separate listing-backed control and test path. The port preserves its RAM fill, table, checksum, A/D scan, communications, raw output exercises, and restart decisions where emitted code is available. The external factory fixture and FMD exchange remain boundaries.

Physical VIGN/VBATT rail timing, keep-alive supply behavior, processor reset electrical consequences, unavailable optional code at \$5800, and vector targets at external \$6000 remain F4. The simulator exposes decisions and events at F2; it does not claim to reproduce those physical mechanisms.

4.1 Power rails, reset and retained-power block

Schematic location. Sheet 6, U1 16034992, battery-input diodes, input/output capacitors, VIGN bias network and reset pull-up; sheet 1 U8/U9/U12 reset and standby connections; sheet 5 vehicle supply connectors.

Electrical operation. BATT# enters two diode-fed paths: VQUAD feeds output stages, while VBATT feeds U1 VIN1/pin 11 and VIN2/pin 13 through a 3-ohm series resistor and a 4.7-μF bypass capacitor. The diodes provide isolation; the drawn suppression devices and capacitors support transient conditioning. Their unlabeled characteristics do not establish protection limits. These battery-derived rails must not be confused with regulated VCC or switched VIGN.

U1 connection	Net and externally visible use
VCC1, pin 12	VCC; logic, converters and MEMCAL supply connections
VCC2, pin 8	VCC#; vehicle connector reference supply
VCC3, pin 4	VCCSTANDBY; U8 standby connection and decoupling
RESET, pin 1	~RESET, with 3.3-kΩ pull-up; U8, U9 and U12 reset connections
POWERON, pin 2	Node biased from VIGN through 51 kΩ, with capacitor
POWEROFF, pin 15	Connected to ~LIMP from U12 pin 20

U1 pins 3 and 5 have additional bias/filter networks. Feedback/programming resistors connect pins 6, 7, 9 and 10, but their internal roles are undocumented. The schematic establishes separate rail connections, not exact regulation voltages, dropout thresholds, reset pulse duration or standby switching rules. The sheet-6 30-ohm VIGN feed to CAL30 belongs to MEMCAL circuitry and is separate from the sheet-4 100-ohm VIGN feed to CAL59.

Firmware operation. Startup begins at \$C800. The emitted sequence initializes processor-visible registers and clears volatile RAM, selects factory paths before retained-memory recovery, then validates/reinitializes retained error and learning state as necessary. \$F3A7 sums retained error bytes \$0005-\$0009; invalid retained state invokes the established recovery and IAC park initialization. Firmware expects useful retained state across some power cycles; it does not prove the physical supply behavior that preserves it.

The odd 12.5-ms path \$D6D1-\$D769 recognizes ignition-off state and performs housekeeping before terminal shutdown. The even path \$D370-\$D3DB closes and parks IAC while the common 6.25-ms service executes motor steps. At the terminal key-off timer boundary LC012=\$0385, execution reaches SWI at \$D6EA. The vector table and software endpoint do not by themselves specify which rail then switches off or how a physical restart occurs.

Complete signal path. Battery/VIGN and U1 establish rails/reset; reset permits U8 startup; firmware validates RAM and enters the scheduler; ignition-off state starts cleanup and IAC parking; the terminal software endpoint returns

to the unresolved physical power/reset boundary. This layered explanation avoids treating key-off as instantaneous loss of all ECM power.

Fault behavior. Bad input, ground, regulator or reset connections can disturb multiple subsystems together. Loss of retained supply could repeatedly force startup recovery even when normal running power appears acceptable. These are circuit-based troubleshooting hypotheses, not proof of a specific failed part. Check VBATT, VCC, VCC# and VCCSTANDBY separately; compare reset and VIGN timing with the actual startup/shutdown sequence rather than infer them from the names.

Evidence boundaries. Rail routing and software order are established. U1's internal control truth table, undervoltage response, retention voltage, current capacity and relationship between POWEROFF and actual rail removal remain unknown.

4.2 LIMP source, output gating and watchdog boundary

Schematic location. Sheet 1 U12 pin 20 LIMP with inversion bubble and net ~LIMP; sheet 3 U3/U5 gating; sheet 4 U12 repeated LIMP terminal; sheet 6 U1 POWEROFF. U11 does not have a directly drawn ~LIMP input on sheet 4.

Electrical operation. Sheet 1 identifies U12 pin 20 as the source of this external net. The other occurrences of pin 20 are sections of the same U12, not separate chips. The net reaches U3 output-enable/gating circuitry, U5 fan logic and a U5 resistor/capacitor branch, and U1 POWEROFF. U3's drawn gates share the LIMP control for its four driver channels. The fan path combines FAN and ~LIMP through NAND/inverting logic; driver and external load polarity still matter when translating that to a physical fan state.

The U5 delay branch has 365 k Ω and 2.7 μ F, with a parallel 10-k Ω /diode route for asymmetric charging/discharging. Nominal RC products are 0.986 s and 0.027 s; these are component time scales, not validated limp-entry or reset delays. The second gate output is shown without a destination on this sheet, so this branch cannot be assigned a complete shutdown/watchdog function from the drawing alone.

Firmware operation. The listing exposes watchdog-related service boundaries: \$F21A modifies the FMD/SPI control byte, and emitted writes to \$400B include \$F349-\$F34C during checksum work and \$FD23-\$FD28 in factory execution. The literal value is \$FF00. This establishes servicing operations, not the watchdog's timeout, its internal implementation or a proven direct path to U12 LIMP. Vector entries targeting \$C800 establish software restart destinations; exception labels in comments do not independently establish the triggering physics.

Complete signal path. Software service and reset/I/O signals interact with custom peripherals; U12 presents the external LIMP signal; the signal affects output gates and U1. The missing link is the documented U12 rule that turns a lost service sequence, reset event or other condition into an asserted LIMP net. Neither the firmware nor the external schematic alone closes that link.

Fault behavior. A stopped processor/watchdog-service failure is a plausible backup-entry cause, but is not confirmed as the only cause or a quantified trigger in this repository. Sensor diagnostic codes and ALDL mode do not provide proof of an asserted LIMP signal. The owner's DIAG solder repair therefore remains a mode-selection fault rather than a verified hardware-limp episode.

Evidence boundaries. The physical net source and destinations are established. Exact assertion/release conditions, delay, output defaults and power effects remain unknown. Useful next bench evidence is a simultaneous trace of U12-20, ~RESET, the supply rails and injector output during normal startup/key-off and an independently controlled loss of processor service. Do not invent a LIMP register bit or change the simulator to force hardware fallback from every fault.

5. Runtime scheduler and event model

Ordinary IRQ service has a 6.25-ms cadence. The source alternates odd and even minor paths, so each minor path executes every 12.5 ms. A one-of-sixteen major dispatcher selects one segment per IRQ; each particular major segment recurs every 100 ms. Common service ordering, including the 6.25-ms IAC motor executor, is preserved.

Execution domain	Established cadence or trigger	Principal role
Common IRQ	6.25 ms	common acquisition/service, IAC one-step execution, shared state

Execution domain	Established cadence or trigger	Principal role
Odd minor	12.5 ms	airflow/load/fuel-oriented work
Even minor	12.5 ms	reference/spark/O2-oriented work
Major segment	one of 16 per IRQ; 100 ms per segment	slower state machines, diagnostics, outputs, accessories
Reference event	external engine event	occurrence/period/counter state for RPM, injection, dwell, and spark

Reference events are not scheduler ticks. A host or target supplies raw engine events/state through the HAL; firmware consumes them in the established source order. Collapsing both domains into one periodic host loop changes observable firmware behavior. The detailed order is documented in [Interrupt and scheduler architecture](#).

6. Input acquisition and signal processing

Firmware explicitly selects U10 channels and receives an 8-bit sample. Normal operation does not perform one continuous universal scan; cadence depends on common, minor, major, startup, or factory execution context.

Selector	Channel/net	Supplied-image role
\$00	AN0 MAP2	factory scan; no explicit normal request found
\$10	AN1 VOLT	voltage/battery-related processing
\$20	AN2 O2	oxygen acquisition and filtering
\$30	AN3 MAP	factory scan; no explicit normal request found
\$40	AN4 CTS	coolant conversion
\$50	AN5 TPS	throttle acquisition, learning, normalization
\$60	AN6 PUMPVOLT	pump-voltage diagnostics
\$70	AN7 DIAG	mode selection
\$80	AN8 MAT	air-temperature processing
\$90	AN9 ESC	factory scan; no explicit normal request found
\$A0	AN10 VMAF	analog mass-airflow path
\$B0	unresolved	factory scan only; channel identity unresolved

Raw counts, learned references, filtered state, and engineering-unit or plant interpretation remain separate. Representative states include TPS raw \$0081 and normalized \$0082, VMAF raw \$00ED and airflow \$00EA:\$00EB, voltage \$007E, pump voltage \$007F, MAT \$012B/\$0060, and current load \$0063.

The supplied image's principal load path is VMAF-derived airflow multiplied by reference period \$0095:\$0096 at \$D769-\$D7A0. Physical MAP/MAP2 resources and the CAL61/U11 terminal labeled MAP exist (the measured 376 jumper routes TPS to that terminal), but the evidence does not make them the ordinary producer of \$0063. Vehicle speed and distributor reference are discrete/event paths, not A/D channels.

6.1 CTS and MAT temperature-input blocks

Schematic location. Sheet 2 CTS#/CTSHI/CTS and MAT#/MAT networks; sheet 1 U12 CTSHI output/pin 49 and U10 AN4/pin 5, AN8/pin 9.

Electrical operation. MAT# is biased toward the logic supply through 1.00 kΩ, then reaches MAT through 10 kΩ with a capacitor to ground. Assuming a passive sensor resistance R to ground, negligible input loading and a stiff supply, $V_{MAT} = V_{SUPPLY} \cdot R / (1000 + R)$. The series resistor has negligible unloaded DC drop but isolates the input and contributes to filtering. For an NTC sensor, heating lowers resistance and voltage. The sensor curve, ground offset and input leakage must be measured or specified before assigning temperatures to voltages.

CTS# joins a 348-ohm resistor to CTSHI; CTSHI itself has a 3.65-kΩ pull-up and rail-clamp diodes. CTS# reaches the analog CTS node through 10 kΩ and a filter capacitor, then U10 and U11. When CTSHI is high impedance, the

visible pull-up path is approximately $3.65k + 348 = 3.998\text{ k}\Omega$. If CTSI is actively held near the supply, the effective pull-up approaches $348\text{ }\Omega$. The second case depends on U12's output behavior; the schematic alone does not specify output resistance. Changing bias changes the voltage for the same thermistor and improves useful conversion range. A voltage step at a range change need not mean a temperature step. Do not replace both ranges with one universal sensor-to-count formula.

Firmware operation. Segment 6 requests \$40 at \$F3B9-\$F3BB. At \$F3BF-\$F3EA, selection depends on \$0030 bit 0 and \$003C bit 7; the emitted paths use tables \$FEA7 and \$FEB8. One path adds ten counts with saturation before lookup. The result goes to \$005D. A result greater than 120 sets \$0030 bit 0; a result at most 106 clears it; 107 through 120 retain it. These exact byte boundaries establish hysteresis. Comments associate the thresholds with temperature, but the count/table arithmetic controls the claim. The software selection bit is carried through the existing FMD/SPI boundary; it is not itself a measurement of CTSI's electrical level.

MAT acquisition at \$EBB3 requests \$80; firmware complements the sample, stores the complemented byte at \$012B, produces \$0060 and qualifies Error 23/25. CTS processing updates coolant state \$005B-\$005F and Error 14/15 qualification. Complemented MAT, raw A/D and processed temperature are different representations. Coolant state participates in commanded idle, warm-up fueling, startup enrichment and other temperature gates; MAT enters temperature-dependent control. Actual physical engine temperature remains outside the firmware model.

Complete signal path. Thermistor and ground -> bias/filter -> U10 -> sample and range-dependent conversion -> temperature state -> fuel/idle/control and diagnostics. CTS adds a return path from firmware range selection through U12 CTSI to the sensor bias circuit. Sensor conversion is therefore a coupled hardware/software function, rather than an isolated lookup table.

Fault behavior. An open sensor tends toward the bias rail and a short tends toward ground under the passive-sensor assumptions. A poor ground shifts the reading; a stuck CTS range output makes the voltage inconsistent with the table selected by software. Incorrect coolant state can alter idle or fueling without proving hardware LIMP activation. Fault substitution and qualification must follow the emitted diagnostic paths, not an assumed universal default temperature.

Evidence boundaries. Visible resistor values, table selection and byte hysteresis are established. Thermistor tolerance, CTSI drive strength, capacitor values where unlabeled, voltage-to-count transfer and actual sensor temperatures remain electrical boundaries. Verify both range voltages and learned firmware state together when troubleshooting.

6.2 TPS and analog MAF input blocks

Schematic location. Sheet 2 TPS#/TPS and VMAF#/VMAF; sheet 1 U10 AN5/pin 6 and AN10/pin 12; sheet 4 U11 TPS; sheet 5 MEMCAL routing. FMAF through U12 is a separate digital/event interface, not the analog VMAF input.

Electrical operation. TPS# has a 220-k Ω ground return and feeds conditioned TPS through 10 k Ω and a capacitor to ground. It is a potentiometer/sensor-voltage input, not a passive temperature divider. The weak pull-down biases an open external source toward ground, subject to chip loading. U10 receives conditioned TPS; U11 pin 20 also receives it, and the measured 376 jumper routes it to U11's pin 28 labeled MAP. The analog MAF input VMAF# instead has a 1.00-k Ω pull-up and a 10-k Ω series/filter path to VMAF. Source impedance matters: the pull-up can load a weak sensor output, so an open VMAF input need not produce the same fault polarity as an open TPS input.

Firmware operation. Startup \$C999 and common acquisition \$CC24 request TPS selector \$50. Raw counts go to \$0081; learned closed-throttle state is maintained at \$0086/\$0087, normalized throttle at \$0082, and transient/history state at \$00DD/\$00DE. Learning means raw voltage and normalized throttle are not interchangeable. TPS affects throttle-following idle demand, transient fuel, mode gates and Error 21 qualification.

At \$F7AC-\$F7B6, analog MAF acquisition requests \$A0, stores raw \$00ED, multiplies by seven, and stores the intermediate at \$00EF. Subsequent table and filter processing produces airflow \$00EA:\$00EB; \$D769-\$D7A0 combines airflow with reference period to produce load \$0063. Multiplication by seven is an internal scaling step, not a direct grams-per-second conversion. Key-off burn-off diagnostics also sample \$A0 at \$EB05; Error 33/34 qualification uses the established MAF diagnostic paths. Do not equate an ordinary airflow sample with a direct measurement of burn-off current.

Complete signal path. TPS voltage -> filter -> raw count -> learned/normalized throttle and transient state -> idle/fuel/gates. Analog MAF voltage -> filter -> raw/intermediate -> airflow -> reference-period-dependent load -> fuel calculation. The supplied image's main load path is VMAF, while MAP/MAP2 A/D channels have no explicit normal conversion request found in the existing listing audit.

Fault behavior. TPS noise can appear as throttle motion; incorrect learned closed-throttle state can change normalized throttle even with a repeatable raw sample. MAF wiring/pull-up faults can corrupt computed airflow and fueling. Those mechanisms support troubleshooting hypotheses, not a claim that every high idle is TPS-related or every MAF fault invokes U11 fallback. Compare raw counts, processed state, mode flags and the actual sensor voltage separately.

Evidence boundaries. Firmware storage and scaling are established. Exact sensor curves, filter constants with unlabeled capacitors and internal U11 sensor use remain unknown. Physical MAP and TPS must not be shorted together when reconstructing the measured MEMCAL selection jumper.

6.3 VOLT and PUMPVOLT divider/filter blocks

Schematic location. Sheet 2 VIGN-to-VOLT and PUMPVOLT#-to-PUMPVOLT networks; sheet 1 U10 AN1/pin 2 and AN6/pin 7. These measure separate external sources.

Electrical operation. Both use 33.2 kΩ above the node and 8.06 kΩ below it. With negligible converter loading, $V_NODE = V_SOURCE * 8.06 / (33.2 + 8.06)$, or approximately $0.195347 * V_SOURCE$. At an illustrative 12 V source this is 2.344 V; it is not a measured operating voltage or an A/D calibration. The Thevenin resistance is approximately 6.485 kΩ. VOLT has 1.0 μF to ground, giving nominal RC time constant 6.485 ms; PUMPVOLT has 4.7 μF, giving 30.481 ms. Component values imply PUMPVOLT responds more slowly under the ideal divider assumptions. Capacitor/resistor tolerance, leakage and source impedance affect the real result.

VOLT derives from VIGN on the schematic, even when firmware calls its stored value battery voltage. PUMPVOLT derives from the separate vehicle PUMPVOLT# connection; it is not the fuel-pressure measurement or automatically the PUMP# driver output. Supply/ground drops can make the two channels disagree legitimately.

Firmware operation. Selector \$10 samples VOLT during startup and Segment E and stores \$007E. Consumers include voltage qualification, injector voltage compensation, dwell/feedback handling and diagnostics. \$E816-\$E81B requests \$60 and stores PUMPVOLT at \$007F; later Error 54 and MAF-diagnostic gates use that separate state. Factory entry independently compares battery, pump and DIAG samples, so replacing one voltage channel with the other changes behavior.

Complete signal path. VIGN or pump-monitor source -> individual divider/RC -> U10 -> channel-specific RAM -> compensation or diagnostic/state gates. Divider voltage, A/D count and the resulting timing compensation are separate quantities; the firmware's tables establish the last transformation, not the first two.

Fault behavior. An open lower resistor or faulty ground can raise the node; an open upper resistor can make it low under the ideal input assumptions. Leakage or a failed capacitor can bias or slow the reading. A bad VOLT reading can distort compensation despite healthy battery terminals. A bad PUMPVOLT reading can affect pump/MAF diagnostics without proving a failed pump. Check both external source and divided node before treating the firmware byte as a verified supply voltage.

Evidence boundaries. Ideal divider gain and RC products are computed from printed component values. U10 reference accuracy, leakage, filter tolerances, actual harness voltages and real transient response are not established here.

7. Reference, RPM, dwell, spark, and knock

Conditioned distributor activity reaches U12 REF; U12 presents reference- related connections to U9/U11, and U9 makes occurrence and timing state processor-visible. Firmware qualifies reference state, derives RPM using the image's supported V8 geometry, and maintains no-reference and engine-running state. Four distributor reference pulses per crankshaft revolution are strongly supported; a reference interval represents 90 crank degrees.

Spark production combines calibrated main and coolant terms, startup behavior, mode terms, limits, hot-restart effects, and knock retard. At \$D20C-\$D267, the firmware converts desired angle to timing relative to reference period and stages U9 state. Important processor-visible locations include \$3FC8 current period state, \$3FDC dwell

period, \$3FE4/\$3FE6 next-dwell state, \$3FE8 fire/fall delta, \$3FEC last-reference counter, \$3FF6 reference-to-fire offset, and \$3FFC control/status.

Knock is a separate event path. CAL32/external KNOCK# reaches U12 and U9; firmware consumes changes in \$3FCA at \$D0D1-\$D157, accumulates retard in \$00A5, applies it to spark, and recovers it in Segment A at \$EB3A-\$EB59. Error 43 uses the associated activity checks. CAL29/U10 AN9 remains a distinct analog ESC observation and is not inserted into this event path.

U9/U12 physical edge generation, timer scaling, EST and bypass polarity, ignition-coil current, and exact feedback transformation remain F4. Error 42 establishes firmware feedback-consistency behavior, not the undocumented electrical implementation.

8. Airflow, fuel, and injection

Normal airflow begins with U10 selector \$A0. \$F7AC-\$F7B6 stores VMAF raw state at \$00ED; subsequent processing produces airflow \$00EA:\$00EB. \$D769-\$D7A0 combines airflow with reference period to produce load \$0063, while shifting prior values through \$0061/\$0062.

The fuel path then selects cranking or normal operation and applies the listing-defined commanded air/fuel relationship, startup and power enrichment, oxygen feedback, BLM correction, acceleration enrichment, deceleration fuel cutoff (DFCO), battery-related compensation, pulse-width shaping, and service gates. The sixteen-cell BLM uses a four-by-four airflow/RPM selection for this image (LC017=0) and remains distinct from the faster closed-loop correction.

The established command chain is:

VMAF -> airflow -> load/fuel terms -> corrected pulse width -> permitted injector service -> U9 \$3FD0

U9 \$3FCE is independently exercised as EFI delay. U9 INJS/INJA, U12 injector drive/current control, U11 INJ/INJLIMP, Q1, and the external injector circuit form the hardware envelope. Firmware calculation and raw commands are F0/F2; phase, current limiting, waveform, opening delay, fuel pressure, flow, and combustion are F3/F4.

8.1 Injector gate drive, current sense and feedback block

Schematic location. Sheet 4 U12 injector section, Q1, INJ#, INJGND#, INJSENSE#, charge/boost network and INJLOOP; sheet 1 U8/U9 command connections; sheet 5 vehicle injector/ground/sense terminals.

Electrical operation. Q1 is drawn as a low-side switching transistor: its load terminal joins INJ#, and its source-side return joins INJGND#. U12 INJOUT pin 2 drives its gate through 1.2 kΩ with clamp/filter components. A separate INJ#-to-gate diode/clamp branch includes another 1.2-kΩ resistor. These support protected inductive-load switching; clamp voltages and exact avalanche/energy behavior cannot be calculated from the unlabeled devices.

U12 connection	Electrical role visible on sheet 4
INJS pin 47	Command from U9 pin 8
INJA pin 46	Command from U9 pin 9 and U8 port connection
INJOUT pin 2	Q1 gate drive
ISENSE+ pin 5 / ISENSE- pin 6	Differential connection across 0.103-ohm current-sense resistor
ESENSE pin 3	INJ# voltage feedback through 68.1-kΩ/20.0-kΩ divider
DBL pin 30 / VDBL pin 4	VIGN-fed diode/capacitor boost network
INJLOOP pin 52 (sheet 1)	Conditioned injector-output feedback
INJLIMP pin 48	Named terminal; no external connection drawn on sheet 4

The 0.103-ohm, 2-W resistor produces 0.103 V per ampere and dissipates $0.103 \cdot I^2$ watts if all measured current passes through it. The 2-W marking does not establish the regulated peak/hold current or allowable pulse duty.

The actual return routing must also be checked at the vehicle harness.

With negligible ESENSE loading, the 68.1-k Ω /20.0-k Ω divider gives $V_{\text{ESENSE}} = V_{\text{INJ}} * 20/(68.1+20)$, approximately 0.227* V_{INJ} . It observes the switched injector node, not fuel pressure or fuel flow. The lower INJLOOP branch uses 27 k Ω , a diode to VIGN and 180 k Ω into U12; its logic thresholds and input bias are undocumented, so a simple unloaded divider equation is insufficient.

The two 1.0- μ F capacitors, steering diodes and 1.8-k Ω VIGN feeds are consistent with boosted gate-drive supply circuitry. The drawing's DBL/VDBL names do not prove an exact doubled voltage, switching frequency or regulation law. Current sense plus a boosted gate supply supports an active injector-driver interpretation, but a specific peak-and-hold waveform remains unestablished.

Firmware operation. Common injector bookkeeping at \$F67B-\$F768 is gated by bit 6 in status sampled from \$3FFA, separately from distributor-reference bit 3. The synchronous fuel path \$F9D2-\$F9E4 limits and writes pulse width to \$3FD0. Asynchronous enrichment includes the \$3FF2 write at \$E4D3 and control operations through \$F4C3/\$F4CE. These are processor-visible commands; they are not a software reconstruction of U12's current-control loop. Factory writes provide an independent cross-check on the injector-timing register roles.

Complete signal path. Sensor/reference acquisition -> firmware fuel calculation and permitted timing command -> U9 INJS/INJA interfaces -> U12 gate/current control -> Q1 -> injector load and ground return. Voltage/current feedback returns to U12, while conditioned INJLOOP reaches its discrete-input interface. Electrical pulse shape, injector opening delay and fuel delivery remain downstream of the firmware timing command.

Fault behavior. A good \$3FD0 command does not establish a working output. A failed Q1, gate path, return connection or sense circuit can prevent or distort actuation while the processor still computes fuel. Feedback faults can make the chip see a different electrical state from the commanded state. Injector-open, short-load and clamp-failure responses require custom-chip or bench evidence; no automatic diagnosis or protection threshold is asserted here.

Evidence boundaries and backup path. U11 emits INJLIMP, which sheet 5 routes to J3; U12 pin 48 is labeled INJLIMP but has no drawn connection on sheet 4. Do not silently connect these names in a replacement schematic or claim the fallback handoff is electrically closed by this drawing. A shared net name on a wired terminal would be evidence; an unconnected pin label is not sufficient. The external evidence supports MEMCAL-configured auxiliary/backup injection, but exact selection, missing interconnection and internal U12 routing remain unresolved. Verify original-board continuity before choosing a reconstruction.

9. Idle-air control

Firmware builds a coolant- and mode-dependent target idle, applies minimum- position and anticipation state, and runs the established feedback regulator every 50 ms. The regulator preserves source-specific proportional, derivative, deadband, residual, and fractional-step behavior. It produces a packed direction/magnitude request; a separate 6.25-ms motor service consumes at most one step and updates phase and position bookkeeping.

Throttle follower and A/C, fan, and calibrated auxiliary load anticipation add feed-forward demand without replacing feedback regulation. Startup establishes initial position state. During key-off, \$D370-\$D3DB requests closure to the hard stop, initializes the software counter, then reopens toward calibrated park LC62F=144 through repeated ordinary motor services.

The \$002C HAL observation is software position bookkeeping, not measured pintle position. Winding current, direction at the connector, missed steps, hard-stop mechanics, airflow per step, and engine response remain F3/F4.

10. Emissions, accessories, and transmission

The major loop qualifies secondary-air (AIR), exhaust-gas-recirculation (EGR), canister-purge/CCP, cooling-fan, and air-conditioning requests using calibrated thresholds, delays, and hysteresis. A/C and fan state also feed the IAC anticipation path. Subsystem request state remains distinct from common output staging and from the physical valve, relay, fan, or compressor state.

Transmission logic combines selector/transmission state, vehicle speed, and Segment-E torque-converter-clutch (TCC) qualification. Three stages must remain distinct: firmware TCC request, raw ECM output, and actual powered/hydraulic clutch state. The external brake series-power path is not silently rewritten as an ECM software input. Gear ratios, converter slip, and vehicle dynamics in the optional PC drive model are F3 assumptions; driver, solenoid, and hydraulic behavior not directly established remain F4.

11. Output staging and electrical interfaces

Major Segment 1 \$EDA3-\$EF03 is the common raw output-staging block. It preserves battery qualification, ordinary and field-diagnostic engine-off patterns, normal subsystem selection, Mode-4 pulse-width-modulation overrides, and direct writes to \$3FCC, \$3FD2, \$3FD4, \$3FD6, \$3FD8, and \$4004. The output regression freezes the integrated raw-stage signature FAADF8A6.

A register value is not automatically a voltage, current, relay state, valve position, or actuator force. The supported output sequence is:

firmware request (F0) -> raw processor-visible write (F0) -> proven connection (F1) -> HAL observation (F2) -> optional plant interpretation (F3)

Undocumented driver or custom-device transformation stays F4. This applies to injectors and ignition as well as IAC, TCC, AIR, EGR, purge, fan, A/C, service lamp, and factory-test outputs. Raw values such as 0, 1, \$D000, or \$DFFF do not establish active-high/low, sourcing/sinking, or energized-load semantics by themselves.

12. Diagnostics and communications

Diagnostics separate current qualification, stored history, service-lamp request, and physical lamp behavior. Fault-specific counters and state qualify conditions before history is latched or cleared. Field-service mode sequences flash codes through firmware state; electrical lamp polarity remains at the output boundary.

The normal 160-baud asynchronous link is a pulse-width-coded display stream. The completed raw HAL retains its diagnostic and factory managers, processor- visible timing/state, and output observations without claiming external wire voltage or scan-tool presentation.

The 8192-baud path uses the sole device \$80 serial core initialized at \$C9F4 and implemented through \$FA58-\$FC71. Firmware validates receive state/checksum, constructs Modes 0-4 responses, and advances transmit state. Mode 4 becomes active only through the scheduler-facing lifecycle at \$CB67-\$CB72; entry-only commands and exit cleanup retain their source order.

External ALDL transceiver voltage, polarity, collision behavior, precise physical bit timing, unavailable memory reads, and scan-tool formatting remain F3/F4. Protocol state is not evidence of those electrical properties.

12.1 DIAG mode selection and dashboard data block

Schematic location. Sheet 2 DIAG# input, sheet 1 U10 AN7/pin 8, sheet 3 U2 ALDL transceiver, and sheet 5 DIAG#/ALDL# connector paths. DIAG# and ALDL# are separate electrical nets: one requests mode; the other carries serial data.

Electrical operation. DIAG# has a 10-k Ω pull-up to the logic supply and a 10-k Ω series path to DIAG/U10 AN7, with a capacitor at the converter node. Ignoring converter leakage, an external 10-k Ω resistor to ground makes the connector voltage approximately half the pull-up rail. The input series resistor and capacitor condition the signal; they do not halve its unloaded steady-state voltage again. An open solder joint at U10 pin 8 can disconnect the internal converter input from the correctly biased external trace. Its resulting reading is not predictable without leakage/internal-device information.

Firmware operation. The common A/D routine is \$F1BE-\$F1DF. Segment 3 at \$EA28-\$EA47 requests selector \$70, clears \$0035 bits 4/5, and compares the sample with literal counts 40, 100 and 152. A count below 40 sets bit 4. Counts 100 through 151 set bit 5 unless \$0046 bit 3 is already set. Other counts leave these two bits clear. These are verified count thresholds, not measured voltages. Startup also samples DIAG and has additional factory/exceptional paths.

At \$F8B6-\$F8E8, bits 4/5 select the serial table: ordinary operation uses \$C6FE, whereas diagnostic selection uses \$C70D. The ordinary table points to LC009, \$011A, \$011E, and LC70C; it carries configuration/scaling and fuel/distance-related data rather than the ordinary scan-tool list. Emitted additions into \$011A at \$E4EE-\$E4F3 and \$F733-\$F739 independently support its fuel accumulation role. Table comments alone do not define engineering units. The ordinary record is commonly observed as five bytes including its mode byte; the diagnostic record is the longer 25-byte stream.

Complete signal path. DIAG voltage -> U10 sample -> mode flags -> serial payload selection and control-mode consumers -> U2/ALDL line -> dashboard or scanner. The dashboard needs the normal economy-related record. Replacing it with the diagnostic record can remove or corrupt the expected economy updates. Range can consequently be affected through the dashboard's economy estimate; the dashboard's precise parsing and range algorithm are not in this ECM image.

Fault behavior. A false ALDL request can cause high idle alongside an invalid MPG display. \$D448-\$D450 tests bit 5 and substitutes \$50 (80) into the RPM/25 target path; this is 2000 RPM in that particular command path, not proof that a faulty engine must physically idle at that speed. Other gates, IAC state, and engine airflow determine the resulting speed. Do not describe the observed 1000-RPM symptom as an unconditional calibrated 1000-RPM ALDL target.

Reported repair example. In the owner's June 2023 [CorvetteForum repair thread](#), posts under dldavis describe roughly 1000-RPM idle, MPG stuck at 1.2, and an unrequested change from the short record to the diagnostic record. The June 24 post reports resoldering A/D pin 8 (DIAG); the June 28 follow-up reports three days of correct operation. The owner confirmed the recollection in this session. This is firsthand repair history, not a reproduced electrical test. A disconnected pin causing erroneous mode samples is an explanation consistent with the repair; its actual disconnected voltage was not measured here. This episode is not proof of hardware limp-mode activation or an incorrect NetRes.

Evidence boundaries. Instructions establish mode selection and payload switching. Exact line voltages, dashboard error handling, and the failed joint's internal electrical behavior remain hardware or external-document boundaries.

13. Key-off, shutdown, and exceptional modes

The live lifecycle composes reset-vector power-on, ordinary IRQ operation, the \$D6D1-\$D769 ignition/key-off transition, retained-state work, IAC homing, and the terminal \$D6EA software-interrupt (SWI) powerdown request. BLM commit via LF447 occurs in its documented order. If ignition returns while the software still executes, restart follows the established path rather than a host-created shortcut.

The vectors at \$FFF0-\$FFFE target \$6000, \$C9F4, \$F27B, \$6000, and four copies of \$C800; \$F27B is an immediate return-from-interrupt. What the processor, power supply, keep-alive circuitry, or external \$6000 target does after SWI/reset is outside the supplied image. The HAL reports the software request; it does not simulate physical loss of power as an F0 fact.

14. C port and embedded boundary

The implementation is intentionally a single strict-C89 translation unit: `main.c` includes the fragments under `src/`, `simulation/`, and `tests/`. Exact-width assumptions are enforced with compile-time checks, and explicitly encoded byte/word operations preserve big-endian processor-visible behavior. The code fragments are not intended to compile independently.

`src/hal_interface.inc.h` is the explicit raw seam. It supplies A/D, reference, discrete, communications, power/startup, and factory stimuli and observes U9, parallel-I/O, injector, IAC, and common output state. Target-specific timers, vectors, A/D and capture peripherals, serial transceivers, output drivers, retained memory, watchdog, and physical power behavior belong behind that seam.

An embedded port must retain F0 order and widths while replacing F2 mechanics. It must not migrate the PC's F3 engine/vehicle plant into firmware or fill F4 U9/U11/U12 behavior for convenience. The controlled sequence and exit criteria are in the [embedded and HIL roadmap](#).

15. Simulation and verification

Verification has three complementary layers:

- focused regressions preserve individual arithmetic, state machines, tables, and raw interfaces;
- scheduler and lifecycle regressions prove source-order composition;
- deterministic PC scenarios exercise closed-loop interaction with explicitly assumed F3 engine and transmission plants.

`make test` compiles only `main.c` using `gcc -std=c89 -Wall -Wextra -pedantic`, runs the complete regression program, checks every Makefile-gated result and signature, and rejects genuine `FAIL` output. Frozen signatures include the normal-operation signature `4BA6B7C6`, transmission-aware signature `9732D09B`, Segment-D diagnostic signature `F357A5F2`, Segment-1 output signature `FAADF8A6`, and ignition-lifecycle signature `16D17C9C`. Later raw-HAL and lifecycle signatures are documented by the verification chapter and audits.

Signatures are broad deterministic change detectors. They do not replace explicit assertions, prove untested paths, or establish physical truth. A change that preserves a signature can still be wrong; a deliberate behavior change requires source evidence, focused checks, integration checks, and a reviewed baseline update.

16. Explicit unresolved boundaries

The following are intentionally unresolved or external to the supplied image:

- undocumented internals, transfer functions, phase, polarity, thresholds, timer scaling, and current-control behavior of U9, U11, and U12;
- unclassified U9 `$3FC0-$3FFF` locations and unproven pin/register mappings;
- U10 selector `$B0`, analog reference/accuracy details, and variant-specific normal use of MAP2, MAP, or ESC channels;
- exact physical relationships among `OSC`, `CYL`, distributor reference, ignition, EST/bypass feedback, and knock events beyond established paths;
- injector and ignition waveforms, driver protection, coil/injector current, output polarity, and load electrical behavior;
- IAC mechanics and airflow, relay/solenoid/valve/fan/compressor response, TCC hydraulics, sensor transfer functions, and engine/vehicle dynamics;
- optional code at `$5800`, external vector targets at `$6000`, the factory fixture/FMD implementation, and unavailable external memory contents;
- physical reset, rail timing, standby/keep-alive power, watchdog, and processor consequences after SWI or power transition;
- variant applicability of external photographs, MEMCAL networks, calibrations, and historical artifacts not directly tied to this unit.

These are engineering work items, not gaps to be closed by plausible guesses. New evidence should update the evidence register and cross-reference first, then the affected detailed chapter and this synthesis.

Appendix A. Consolidated address and register index

This index collects the principal processor-visible locations used in the system narrative. Functional names describe established executable use; they do not imply undocumented electrical or custom-device behavior.

A.1 RAM and software state

Address/range	Established role	Detailed reference
\$002C	IAC software position bookkeeping	Idle-air control
\$005B-\$005F	coolant conversion and diagnostic state	Sensor acquisition
\$0061-\$0063	prior and current load state	Airflow/fuel/injection
\$0064	common temporary A/D result	A/D acquisition
\$006F/\$0071/\$0073	oxygen acquisition/filter state	Sensor acquisition
\$007E	persistent VOLT sample	Sensor acquisition
\$007F	persistent PUMPVOLT sample	Sensor acquisition
\$0081/\$0082	raw and normalized TPS state	Sensor acquisition
\$0086/\$0087	learned closed-throttle state	Sensor acquisition
\$0095:\$0096	reference-period state used by load/fuel processing	Airflow/fuel/injection
\$00A5	accumulated knock-retard state	ESC/knock chain
\$00DD-\$00DE	transient TPS state	Sensor acquisition
\$00EA:\$00EB	processed airflow word	Airflow/fuel/injection
\$00ED/\$00EF	raw and intermediate VMAF state	Airflow/fuel/injection
\$012B/\$0060	complemented raw and processed MAT state	Sensor acquisition
\$0152/\$0153/\$0156/\$0157	Mode-4 raw PWM override state	Output staging
\$017B-\$0186	factory-test sequential A/D snapshot	A/D acquisition

A.2 Processor-visible peripheral locations

Address/range	Established role	Detailed reference
\$3FC8	current spark/reference-period state	U9 register map
\$3FCA	knock-event quantity consumed by firmware	ESC/knock chain
\$3FCC	Segment-1 raw MPU output word	Output staging
\$3FCE	EFI delay state	Ignition/injection chain
\$3FD0	synchronous injector command	Airflow/fuel/injection
\$3FD2/\$3FD4/\$3FD6/\$3FD8	Segment-1 raw MPU output words	Output staging
\$3FDC	dwelling-period value	Reference/RPM/dwelling/spark
\$3FE4/\$3FE6	next-dwelling timing and update state	Reference/RPM/dwelling/spark
\$3FE8	current fire/fall delta	Reference/RPM/dwelling/spark
\$3FEC	counter value at last reference	Reference/RPM/dwelling/spark
\$3FF6	reference-to-fire offset	Reference/RPM/dwelling/spark
\$3FFC	control/status word used by EST/bypass and other modes	U9 register map
\$4004	parallel-I/O byte modified by Segment 1	Output staging

A.3 Executable regions and external boundaries

Address/range	Established role	Detailed reference
\$5800	optional-ROM boundary; code unavailable	Startup/shutdown
\$6000	external vector destination; behavior unavailable	Startup/shutdown
\$8000-\$FFFF	supplied program window	Processor/memory architecture
\$C800-\$C9F3	reset and power-on sequence	Startup/shutdown
\$C9F4, \$FA58-\$FC71	device \$80 SCI core	Diagnostics/ALDL
\$CB67-\$CB72	scheduler-facing Mode-4 activation	Diagnostics/ALDL
\$D0D1-\$D157	knock-event consumption and retard	ESC/knock chain
\$D20C-\$D267	spark angle-to-time staging	Reference/RPM/dwelling/spark
\$D370-\$D3DB	IAC reset/homing state machine	Idle-air control
\$D6D1-\$D769	key-off transition and adjacent lifecycle path	Startup/shutdown
\$D769-\$D7A0	airflow/reference-period load producer	Airflow/fuel/injection
\$D6EA	terminal SWI software-powerdown request	Startup/shutdown
\$EDA3-\$EF03	Segment-1 raw output staging	Output staging
\$F1BE-\$F1DF	common U10 A/D transaction	A/D acquisition
\$F3A7-\$F3B4	retained checksum computation	Startup/shutdown
\$F434-\$F446	retained-state recovery initialization	Startup/shutdown
\$FFF0-\$FFFE	emitted vector table	Startup/shutdown

The complete function-to-listing, RAM/register, calibration, schematic, C, and test mapping remains in the [hardware/firmware cross-reference](#).

Appendix B. Detailed chapter map

Chapter	Controlling reference
1	System overview and evidence method
2	Power, reset, retained power, startup, and shutdown
3	Processor, memory, and custom peripherals
4	MEMCAL architecture and reconstruction
5	Interrupt and scheduler architecture
6	Reference, RPM, dwell, and spark
7	Sensor acquisition and filtering
8	Airflow, fuel, and injection
9	Idle-air control
10	Emissions and accessory control
11	Transmission and TCC
12	Diagnostics and ALDL
13	Output staging and electrical interfaces
14	Startup, shutdown, and exceptional modes
15	C port and embedded migration
16	Simulation and verification

The [theory-of-operation index](#) retains the acceptance criteria and supporting signal-chain references for the sixteen-chapter source set.

Appendix C. Glossary

Term	Meaning
A/C	Air conditioning.
A/D	Analog-to-digital conversion.
AE	Acceleration enrichment.
AFR	Air/fuel ratio.
AIR	Secondary-air management system.
ALDL	Assembly Line Diagnostic Link.
BLM	Block-learn memory; retained adaptive fuel-correction state.
CCP	Canister-control purge; used here for the canister-purge function.
CTS	Coolant temperature sensor.
DFCO	Deceleration fuel cutoff.
ECM	Engine control module.
EGR	Exhaust-gas recirculation.
ESC	Electronic spark control; the analog observation path is distinct from the knock-event path.
EST	Electronic spark timing.
FMD	Factory-mode data/exchange boundary used by the factory-test path.
HAL	Hardware abstraction layer; the raw processor-visible F2 seam.
HIL	Hardware-in-the-loop verification.
IAC	Idle-air control.
IRQ	Interrupt request; ordinary periodic firmware service in this document.
MAF	Mass airflow.
MAP	Manifold absolute pressure.
MAT	Manifold air temperature.
MEMCAL	Removable memory/calibration and configuration carrier.
MPU	The custom processor-visible peripheral/register resource named by the source material.
PROM	Programmable read-only memory containing program and calibration data.
PWM	Pulse-width modulation.
RPM	Revolutions per minute.
SCI	Serial communications interface used by the 8192-baud path.
SWI	Software interrupt; used by the terminal powerdown request path.
TCC	Torque-converter clutch.
TPS	Throttle position sensor.
VIGN	Ignition-switched supply/sense domain.
VMAF	Analog mass-airflow voltage net presented to U10.
VSS	Vehicle-speed signal.

Appendix D. Schematic functional-block coverage

The theory retains subsystem chapters, with an electrical-to-firmware block structure: schematic location, electrical operation, firmware operation, complete signal path, fault behavior, and evidence boundaries. Sections 3.1, 4.1, 4.2, 6.1-6.3, 8.1 and 12.1 are the expanded treatments. The index below covers all six schematic sheets and identifies where further component-level expansion is still needed. A row is a coverage entry, not a declaration that the custom chip is fully explained.

Sheet / block	Electrical boundary	Firmware relationship / chapter	Coverage state
1: U8 processor, crystal, memory bus	Clock, reset, address/data and J4 EPROM interface	Startup and execution; 2, 4, 5	Existing overview; expand physical timing
1: U9 timing/output peripheral	Reference, MAF, VSS, timing and output pins	Register window and event scheduling; 5, 7, 8, 11	Firmware established; internal circuitry bounded
1: U10 A/D and SPI	Analog channels, reference rails, MOSI/MISO/SCK/select	Sensor acquisition; 6	Channel map established; electrical expansion pending
1: U12 SPI/discrete I/O	Digital inputs, CTS range output, reset and LIMP	Input/output state and exceptional modes; 4, 6, 11, 13	4.2 LIMP source traced; internal logic bounded
2: discrete input conditioning	Pull-ups/downs, series resistors and capacitors	Switch/accessory states; 10	Existing subsystem coverage; expand each input
2: VOLT and PUMPVOLT	33.2-kΩ/8.06-kΩ dividers and filtering	Voltage state/diagnostics; 6, 12	6.3 divider/RC and consumers expanded
2: MAP/MAP2 and TPS	Series filtering and bias paths	TPS learning; MAP factory channels; 6	6.2 TPS learning and routing expanded
2: CTS and MAT	Bias, filtering and CTSHI range circuit	Temperature conversion; 6, 9	6.1 bias and range hysteresis expanded
2: O2 and U4	Differential sensor amplifier and reference supply	O2 filtering/closed-loop fuel; 6, 8	Existing firmware; amplifier transfer bounded
2: ESC and KNOCK	Separate analog ESC and U12 digital KNOCK paths	Factory ESC versus U9 knock counter; 6, 7	Separation established; filter internals bounded
2: VSS and FMAF	U12 signal conditioning with input bias/filtering	Speed/events and MAF interfaces; 6, 8, 10	Existing firmware; conversion details bounded
2/1: DIAG	Pull-up, series resistor, AN7	Mode decoding and data-table selection; 12.1	Expanded with firsthand repair example
3: U13 pump driver	PUMP command to PUMP#	Pump request; 10, 11	Existing output boundary; driver expansion pending
3: U7 IAC driver	IACA/IACB/IACEN to four winding connections	Step sequencing and regulator; 9, 11	Existing firmware; winding/load behavior bounded
3: U3/U6 quad drivers	Output protection, fault feedback and limp gating	Accessory outputs and SES; 10, 11	Existing staging; expand gate/polarity mapping
3: U5 fan/limp gates and RC branch	LIMP-conditioned fan/output logic and delay network	Output and exceptional-mode boundaries; 11, 13	4.2 RC scales reviewed; destination incomplete
3: U2 ALDL transceiver	TX/RX/enable and shared ALDL# line	160-baud and 8192-baud protocols; 12	12.1 payload path; physical transceiver bounded
4: distributor/reference and EST	Differential conditioning, REF, EST and BYPASS feedback	Reference, RPM, spark and Error 42; 7	Existing firmware; comparator/feedback expansion pending
4: U11/MEMCAL configuration	Fixed bias, OSC, sensors and INJLIMP	Auxiliary injection/custom-chip boundary; 3.1, 8	Expanded; analog equations unknown
4: U12/Q1 injector output	Gate drive, protection, sense resistor, INJLOOP	Injector timing and feedback; 8, 11	8.1 expanded; loaded driver behavior bounded
5: J1/J2 vehicle and J3/J4 interfaces	Physical routing, supplies, programming and MEMCAL	Cross-reference for all chapters	Routing index; orientation check still physical

Sheet / block	Electrical boundary	Firmware relationship / chapter	Coverage state
6: U1 power/reset and retained rails	VBATT/VIGN, VCC, standby, reset and LIMP connections	Reset, retention, key-off; 4, 13	4.1/4.2 expanded; internal sequencing bounded

Detailed chapter destinations and register anchors remain in Appendix B and the [hardware/firmware cross-reference](#). Next expansions should cover the remaining analog conditioning and output-driver blocks using this same structure. U1/U12 internal LIMP activation remains an evidence gap rather than a completed electrical explanation.