

KITCHEN EQUIPMENT CONNECTION SCHEDULE

| FS ITEM | EQUIPMENT                                   | VOLTAGE / PHASE                                   | CIRCUIT | DISCONNECT         |
|---------|---------------------------------------------|---------------------------------------------------|---------|--------------------|
| 1       | Walk-in cooler with remote condensing unit  | 208V 3PH (condensing unit); 115V 1PH (evaporator) | KP-1    | Fused, by 26 28 16 |
| 2       | Walk-in freezer with remote condensing unit | 208V 3PH (condensing unit); 208V 1PH (evaporator) | KP-3    | Fused, by 26 28 16 |
| 3       | Reach-in refrigerator                       | 115V 1PH                                          | KP-5    | Cord and plug      |
| 4       | Convection oven                             | 208V 3PH                                          | KP-7    | Fused, by 26 28 16 |
| 5       | Combi oven                                  | 208V 3PH                                          | KP-9    | Fused, by 26 28 16 |
| 6       | Tilting skillet                             | 208V 3PH                                          | KP-11   | Fused, by 26 28 16 |
| 7       | Steam kettle                                | 208V 3PH                                          | KP-13   | Fused, by 26 28 16 |
| 8       | Fryer battery                               | 120V 1PH (controls); gas                          | KP-15   | Cord and plug      |
| 11      | Exhaust hood                                | 115V 1PH (lights, controls)                       | KP-21   | Cord and plug      |
| 12      | Hood fire suppression system                | 120V 1PH (release, shunt)                         | KP-23   | Cord and plug      |
| 13      | Dishmachine                                 | 208V 3PH                                          | KP-25   | Fused, by 26 28 16 |
| 14      | Booster heater                              | 208V 3PH                                          | KP-27   | Fused, by 26 28 16 |
| 15      | Food waste disposer                         | 208V 3PH                                          | KP-29   | Fused, by 26 28 16 |
| 16      | Ice machine with bin                        | 208V 1PH                                          | KP-31   | Cord and plug      |
| 19      | Pot washer                                  | 208V 3PH                                          | KP-37   | Fused, by 26 28 16 |

RIVERSIDE HIGH SCHOOL CENTRAL KITCHEN

KITCHEN EQUIPMENT CONNECTION SCHEDULE

SHEET NUMBER

E-601