
H U S H

HOME · MODEL H-20

Quick Start Guide


Private time for your connected home.



READ BEFORE SETUP

EN · 2046 EDITION

What's in the box




HUSH Home
Wi-Fi router with 10.9" display

Power adapter
USB-C, 30 W

Network cable
1.5 m

This guide
Keep it near your router

Meet your screen



1 **Private Hours remaining**
One balance for the whole home.

2 **Start / Pause**
One tap for every connected device.


3 **Plan, price and renewal**
Tap *Change* to compare plans.

4 **Live status**
What is blocked, or active, right now.

Protection active · Paused · time saved · Unavailable · 0 hours

SET UP · ABOUT 5 MINUTES

Get started



01

Connect

Plug the network cable into your wall socket and the power adapter into the back of HUSH. The screen lights up in about a minute.



02

Join HUSH Wi-Fi

Scan the code on the screen with your phone to join HUSH Wi-Fi and download the HUSH app.

Mobile data and other networks are not covered.



03

Choose a plan

Private Hours are only available with an active plan. Choose one in the app and confirm payment. Until then, the screen shows *Choose a plan to start* and the start button stays locked.

	HUSH Personal	HUSH Home	HUSH Home+
Private Hours / month	10	20	40
Devices covered	up to 10	up to 20	up to 40
Monthly price	$9.99	$19.99	$29.99

All plans: additional Private Hours $3.99 each · change or cancel anytime in the app.

EVERYDAY USE

Use your hours



04

Start a Private Hour

Tap ▶. The household timer starts counting down. App tracking, browser profiling, identifiable data sharing and ad personalisation are blocked on participating services, for every device on HUSH Wi-Fi.



05

Pause to save time

Tap **II** when you are done. Unused time stays in this month's allowance. Someone else still browsing? See *Sharing with your household*, next page.



06

Check your monthly report

Tap the HUSH logo on the screen to see hours used, tracking requests detected and advertising profile updates across your home.


BEFORE YOU START A SESSION

Is this worth an hour? One Private Hour is 60 minutes for the whole home, not for each device. Most households save their hours for:

Health questions · Banking · Job searching · Personal messages · Gifts & surprises

ONE HOME, ONE TIMER

Sharing with your household



Private Hours belong to the whole home. While protection is on, every device on HUSH Wi-Fi is covered and the household balance counts down — whether one person is using it or five.

A

Pause requests

If you tap Pause while other members are still active, they receive a request: "*Someone at home wants to pause Private Protection.*" If nobody answers within 30 seconds, the home pauses.

B

Keep me private

Any active member can tap **Keep me private**. Protection stays on for the whole home and the timer keeps running for everyone.

C

Step out

Done, but don't want to stop anyone else? Tap **Step out** in the app. Your device leaves the session and is no longer protected. The household timer keeps running.

D

Member limits

The account holder can set a monthly limit for each member in *Settings › Household*, so one person can't use the family's hours.

HOUSEHOLD TIP

Agree on a routine. A session someone else keeps open still counts against everyone's hours.

When your hours run out



00:00

- The status light turns coral: *Private Protection Unavailable*.
- Wi-Fi keeps working. Nothing switches off.
- Each service returns to its normal tracking and sharing settings.
- Add 1 Private Hour for $3.99, change plan, or wait for renewal.

Troubleshooting

The start button is greyed out.
Your household has no active plan, or your last payment didn't go through. Check *Plans & Billing* in the app.

My phone says "Hush Disconnected" but the screen says protection is active.
Your phone is on mobile data or another network, or you tapped *Step out*. HUSH only covers devices in the current session on HUSH Wi-Fi.

My phone and the router show different hours remaining.
Displays sync every few minutes. The router screen shows your household's official balance.

I paused, but the timer is still running.
Another member tapped *Keep me private*. Use *Step out* to leave the session yourself.

My job recommendations changed after one search.
Activity outside a Private Hour is shared under each service's normal settings. Starting a session later does not remove profiles that were already updated.

A website still knew who I was during a session.
Information you choose to send — logins, bookings, payments, messages — still reaches that service. Protection is not anonymity.

GOOD TO KNOW

The small print

— Private Hours are available only with an active HUSH plan. Plans are billed monthly in advance to the household payment method and renew automatically. Unused Private Hours expire at renewal.

— HUSH Personal: 10 Private Hours, up to 10 devices, $9.99/month. HUSH Home: 20 Private Hours, up to 20 devices, $19.99/month. HUSH Home+: 40 Private Hours, up to 40 devices, $29.99/month.

— Additional Private Hours: $3.99 each (60 minutes, whole home). Additional hours start immediately.

— One Private Hour is counted once for the whole household, however many devices or members are in the session. Time keeps counting while any member keeps protection on.

— Pause requests expire after 30 seconds. A member who steps out of a session is not protected for the remainder of it.

— Protection applies to new tracking, profiling and identifiable data sharing by participating services on HUSH Wi-Fi during an active session. Participating services are listed at hush.home/participating and may change monthly.

— Previously collected data and existing profiles are not removed by starting a session, buying additional hours or changing plans.

— HUSH does not listen to your home and does not read the content of your activity. Session start and end times are retained for billing and service improvement.

— Emergency services may access your connection at any time, including during a Private Hour.

SPECIFICATIONS

Model
HUSH Home H-20

Wireless
Wi-Fi 9 · tri-band

Power
30 W adapter included

Display
10.9" touch, always on

Ports
2 × 10 GbE · USB-C power

Use
Indoor only. Do not cover the display.

H U S H

PRIVACY STARTS AT HOME

Your apps know enough. Give them some time off.

Manage your plan, hours and household at hush.home

© 2046 HUSH Home Pty Ltd, Sydney NSW. HUSH and Private Hours are trademarks of HUSH Home Pty Ltd. Printed on recycled paper.
Part no. QSG-H20-EN-03

CE RCM Wi-Fi 9 ♻ 05