





Lights on charge station indicate charging status.



Car will **automatically** stop charging when it is fully charged.



To manually stop charging, disconnect the connector.

