


every pad can have its own delay input level










* so a triggered pad can be sent to the delay line without being heard in the main mix

(hold K1 to set thru for all pads in the bank)



each delay line has its own main output level