midi + OP-Z

[setup]

all pads can be called via MIDI notes
from an attached keyboard, sequencer, or OP-Z

navigate to PARAMS	te to PARAMS enable MIDI control PARAMETERS / MIDI note/OP-Z		specify port		
delays >			(see PARAMS > DEVICES > MIDI)		
OSC setup >			enable MIDI control?	yes	
MIDI note/OP-2 setup >	enable MIDI control?	yes	MIDI control device	port 3	
MIDI encoder setup >	MIDI control device	port 1	enable MIDI echo?	no	
	enable MIDI echo?	no	channel		
	channel		bank (a) pad channel:	1	

a successful connection:		an unsuccessful connection:			
cheat code	s	(AKM320)	cheat codes	(no midi	device!)
> loops	filters	euclid		ilters	euclid
levels pans	delays timing	arp rnd		lelays iming	arp rnd

defaults:

- bank (a): channel 1
- bank (b): channel 2
- bank (c): channel 3:
- pads start at note 53 (chromatic)
 - eg. F3 = pad 1, D4 = pad 11
- edit in PARARMS > MIDI note/OP-Z setup

if using an OP-2, you can control + display pad values via

the OP-Z's on-board encoders:

- PARAMS > MIDI note/OP-2 setup > enable MIDI echo?: yes
- enc 1: start point
- enc 2: end point
- enc 3: filter cutoff
- enc 4: level

nb. this will affect synth parameters on the OP-Z